

ORACLE LIGHTING

DYNAMIC COLORSHIFT

WIRING CONNECTION DIAGRAM WITH BLUETOOTH CONTROLLER

BLUETOOTH LED CONTROLLER

NOTICE
DO NOT CONNECT
POWER DIRECTLY
TO THE CONTROLLER

ORACLE
LIGHTING
Bluetooth CONTROLLER

GND ●
DAT ●
GLK ●
VCC ●

TO SPLITTER

INSTALLATION:

- (STEP 1) CONNECT RED RING TERMINAL TO BATTERY +
- (STEP 2) CONNECT BLACK RING TERMINAL TO GROUND
- (STEP 3) INSTALL APP TO OPERATE THE LIGHTS.

TO BLUETOOTH
CONTROLLER

SIGNAL SPLITTER
DATA HUB

CONNECT TO:

HALO #1
HALO #2
HALO #3
HALO #4

VOLTAGE REGULATOR

YELLOW
BLACK
BLACK
RED

20A FUSE

BLACK TO BATTERY (-)

RED TO BATTERY (+)