



INSTALLATION INSTRUCTIONS

Failure to follow these instructions can severely shorten the life of this part and may void the part's warranty.

Installation Process

1. Lock cylinder is shipped ready for installation. Do not rotate the key clockwise until lock cylinder is installed into steering column.

Models Covered:

ILC174

IS 23-7-29-09