

## POWERTRAIN LIFTS



**5285**  
**1,650-LB POWERTRAIN LIFT**

- Air/hydraulic operation with foot control pump
- Scissor design to access all 4 sides of powertrain



**1595A**  
**2,500-LB POWERTRAIN LIFT**

- Air/hydraulic operation with foot control pump
- Scissor design to access all 4 sides of powertrain



**5295**  
**1,760-LB SPLIT TOP POWERTRAIN LIFT**

- Sliding split-top helps separate powertrains, differentials, axles and more
- High ground clearance for floor crane access when collapsed
- Air/hydraulic lifting mechanism smoothly lifts and lowers components
- Large, tilting tabletop to access all sides of components
- Air/hydraulic operation with foot control pump



**5130**  
**1,000 LB DRIVELINE LIFT**

- Includes 553516 differential adapter
- Pivoting pump handle to raise/lower from multiple positions
- For removal of differentials, light-duty transmissions, auxiliary boxes, drive shafts and more



**1585A**  
**1,250 LB POWERTRAIN LIFT**

- Ideal for engine and transaxle service
- Moves easily around the shop with compact design and swivel casters
- Air/hydraulic operation

Lift Spec.	Capacity (lbs)	Table size	Tilt side/side	Tilt front/back	Min height	Max height	Caster size
5285	1,650	20" x 32"	15°	15°	31.5"	74.5"	8"
1595A	2,500	20" x 32"	15°	15°	29"	80"	8"
5295	1,760	36" x 42"	N/A	N/A	21.5"	70"	8"
5130	1,000	N/A	15°	15°	7"	30"	4"
1585A	1,250	20.5" x 30.5"	17°	22°	29.5"	68.5"	4"

## TRANSMISSION JACKS



### 5019A 2,200 LB TRANSMISSION JACK

- Includes 540231 adapter for Eaton Fuller RoadRanger transmissions
- Pivoting pump handle to raise/lower from multiple positions



### 5078 2,000 LB HIGH-LIFT TRANSMISSION JACK

- Air/hydraulic operation with foot control pump
- Includes adapter for Allison 500 and 600-series transmissions



### 1793A 1,000 LB HIGH-LIFT TRANSMISSION JACK

- Universal mounting head and adjustable brackets for easy transmission alignment
- Foot-operated pump to control height when raising or lowering transmissions



### 1522A 2,000 LB LOW-LIFT TRANSMISSION JACK

- Includes 220492 adapter for Eaton Fuller RoadRanger transmissions
- Pump handle rotates 360° to raise/lower from multiple positions



### 1521A 1,000 LB LOW LIFT TRANSMISSION JACK

- Universal mounting head and adjustable brackets for easy transmission alignment
- Pump handle rotates 360° to raise/lower from multiple positions



### 1794A AIR-ASSIST 1,000 LB HIGH LIFT TRANSMISSION JACK

- Universal mounting head and adjustable brackets for easy transmission alignment
- Air-assist for faster raising via foot pedal

Lift Spec.	Capacity (lbs)	Min height	Max height	Tilt, forward	Tilt, backward	Tilt, side/side
5019A	2,200	8.25"	36.5"	15°	20°	12°
5078	2,000	41.5"	65"	50°	38°	14°
1793A	1,000	35"	71.625"	24°	19°	20°
1522A	2,000	6.875"	35.25"	24°	18°	11°
1521A	1,000	7.5"	29.75"	67°	17°	30°
1794A	1,000	37.625"	76.5"	42°	46°	12°
5237	1,000	34.5"	75"	50°	20°	10°
1728	1,000	34.5"	72"	40°	20°	10°

## TRANSMISSION JACKS









### 5237 1,000 HIGH LIFT TRANSMISSION JACK

- Universal mounting head and adjustable brackets for easy transmission alignment
- Folding foot pedal for precise control for raising, lowering and positioning
- 34-1/2" min height, 75" max height
- Tilts 50° forward, 20° backward and 10° side-to-side










### 1728 AIR-ASSIST 1,000 LB HIGH LIFT TRANSMISSION JACK

- Air-assist with foot pedal control raises components quickly
- Four ratcheting brackets fit a wide range of transmissions
- 34-1/2" min height, 72" max height
- Tilts 40° forward, 20\* backward and 10\* side-to-side

COMPATIBILITY ADAPTER	POWERTRAIN LIFTS				DRIVELINE	LOW-LIFT TRANS JACKS			HIGH-LIFT TRANS JACKS				
	5285	1595A	5295	1585A	5130	5019A	1522A	1521A	5078	1793A	1794A	1728	5237
 <b>558382</b> Auxiliary box adapter					Yes	Yes	Yes		Yes				
 <b>561949</b> Light duty transmission adapters					Yes	Yes	Yes		Yes				
 <b>528150</b> Eaton lightning adapter						Yes							
 <b>543284</b> Roadranger transmission						Yes							
 <b>49611</b> Eaton Fuller Roadranger auxiliary housing						yes							
 <b>553516</b> Differential mounting adapter					Yes, included with lift purchase	Yes	Yes		Yes				



COMPATIBILITY ADAPTER	POWERTRAIN LIFTS				DRIVELINE	LOW-LIFT TRANS JACKS			HIGH-LIFT TRANS JACKS				
Adapters	5285	1595A	5295	1585A	5130	5019A	1522A	1521A	5078	1793A	1794A	1728	5237
 <p><b>314729</b> Allison 5/0600 series adapter</p>									Yes, included with lift purchase				
 <p><b>540231</b> Eaton Fuller Roadranger transmission adapter</p>						Yes, included with lift purchase							
 <p><b>540232</b> Mack transmission mounting brackets</p>						yes							
 <p><b>5091</b> HD spindle adapter</p>					Yes	Yes	Yes						
 <p><b>1870</b> Universal transmission adapter</p>									Yes	Yes		Yes	
 <p><b>223196</b> Transmission jack mounting adapter set</p>									Yes	Yes	Yes	Yes	
 <p><b>1758</b> Fuel tank handler</p>	Yes	Yes	Yes	Yes					Yes	Yes	Yes	Yes	