

THROTTLE POSITION SENSOR RESETTING 2003-2007 DODGE VEHICLES

PLEASE READ THOROUGHLY BEFORE STARTING RESET PROCEDURE

- Step 1** Turn the key to the RUN position (but not started)
- Step 2** Slowly depress the throttle pedal all the way to the floor, slowly release to idle (remove your foot from the pedal @ idle), slowly depress to the floor and back to idle 2 more times so you have gone 3 times in each direction.
- Step 3** After the 3rd time to idle, Turn the key off.
- Step 4** Start the truck and allow it to idle for 3-5 minutes. (DO NOT TOUCH THE THROTTLE)
- Step 5** After it has idled for 3-5 min. Turn the truck off, then restart it and go for a test drive.

Note it may be necessary to do this more than one time to get it reset.

- **PACBRAKE** SERVICE