



# 40027

## **CERAMIC VOLTAGE REDUCER INSTALLATION INSTRUCTIONS**

THIS CERAMIC VOLTAGE REDUCER IS DESIGNED TO DROP 12 VOLTS TO 6 VOLTS FOR VEHICLES USING A 12 VOLT SYSTEM BUT KEEPING SOME 6 VOLT ACCESSORIES (BLOWER MOTOR, RADIO, ETC.).

**NOTE!      THIS UNIT IS NOT FOR USE WITH GAUGES.**

**CAUTION:    VOLTAGE REDUCER IS DESIGNED FOR 1.5 OHMS RESISTANCE AT FOUR (4) AMPS. MAXIMUM LOAD. OVERLOADING WILL DAMAGE REDUCER AND/OR ACCESSORY. VOLTAGE REDUCER BECOMES HOT DURING OPERATION. MOUNT REDUCER IN AN OPEN SPACE AWAY FROM WIRING, HOSES, ETC.**

1. CHECK AMP. RATING OF ACCESSORY TO BE INSTALLED. YOU MUST HAVE THIS INFORMATION BEFORE INSTALLING ACCESSORY.
2. SELECT THE DIAGRAM WHICH MATCHES THE AMP. RATING OF ACCESSORY. **DAMAGE TO THE REDUCER AND/OR ACCESSORY WILL RESULT IF WRONG DIAGRAM IS USED.**
3. CONNECT ONE OR MORE VOLTAGE REDUCERS IN SERIES OR PARALLEL AS SHOWN IN DIAGRAM.

