



60116

Vehicle Speed Sensor
Installation Instructions

This vehicle speed sensor puts out a signal that is for use with 60103 and 60203 kits.

1. Connect one wire from the sensor to the purple wire from the (TPI) kit that is labeled VSS.
2. Connect the other wire to the yellow wire coming from the (TPI) kit. The wire polarity does not matter because the VSS puts out an AC signal.

Painless Performance Limited Warranty and Return Policy

Chassis harnesses and fuel injection harnesses are covered under a lifetime warranty. All other products manufactured and/or sold by Painless Performance are warranted to the original purchaser to be free from defects in material and workmanship under normal use. Painless Performance will repair or replace defective products without charge during the first 12 months from the purchase date. No products will be considered for warranty without a copy of the purchase receipt showing the sellers name, address and date of purchase. You must return the product to the dealer you purchased it from to initiate warranty procedures.