



Part #80152


GM Style Headlight Switch Wire Connections

| | |
|-----------|-----------------------------------|
| Wire #928 | battery input from the fuse block |
| Wire #930 | wire going to the dash lights |
| Wire #907 | wire going to the dimmer switch |
| Wire #927 | wire going to the park lights |
| Wire #929 | wire going to the tail lights |

NOTE: On some switches, wire terminal #927 is omitted. The terminal next to #929 (without a part number) will then become the park light output.

Dome light ground is the terminal to activate the dome light when the knob is turned to the left.

CAUTION: This is a grounding terminal only.



Painless Performance Limited Warranty and Return Policy

Chassis harnesses and fuel injection harnesses are covered under a lifetime warranty.

All other products manufactured and/or sold by Painless Performance are warranted to the original purchaser to be free from defects in material and workmanship under normal use. Painless Performance will repair or replace defective products without charge during the first 12 months from the purchase date. No products will be considered for warranty without a copy of the purchase receipt showing the sellers name, address and date of purchase. You must return the product to the dealer you purchased it from to initiate warranty procedures.