How to Install a Cattle Siren



By Pierce Team

The PIERCE Cattle Siren is easily mounted to your car, truck, SUV, ATV, UTV or tractor (not recommended for bicycles;). This handy siren does the work of calling in cattle for feeding time.

How to Install a Cattle Siren:

- 1. Keep the PIERCE cattle calling siren away from tires. During rain the tires kick up water and may damage the siren.
- 2. Mount it away from places where low lying trees or brush could damage it.
- 3. Ideally mount the siren to any flat surface. For example, the headache rack or in the engine bay compartment.
- 4. The livestock siren can be mounted using 1/4" bolts or #10 self tapping screws.
- 5. Bolt or screw through the mount to the surface you are attaching the siren to.

How to Wire a Cattle Siren:

Heavy Duty Cattle Siren (PCH324)

- Blue wire to the negative side of the battery.
- 2. Red wire to a switch in the dash.
- 3. Run a 12v+ with inline 40 amp fuse from the battery to the other side of the switch in the dash.

Standard Cattle Siren (PS092BE)

- 1. Black wire to the negative side of the battery.
- 2. Red wire to a switch in the dash.
- 3. Run a 12v+ with inline 40 amp fuse from the battery to the other side of the switch in the dash.