

Installation Instructions:

Mirror is configured for driver side out of box.

- Turn mirror head to horizontal position
- Loosen all 5 knobs to allow mirror to conform to vehicle mirror
- Determine whether mirror will be used on driver or passenger side of vehicle. Follow instructions on how to change to passenger side configuration.
- Place mirror on vehicle mirror housing with bottom of clamp bracket fitting between vehicle mirror housing and mirror glass.
- Slide brackets on mirror rod to obtain best alignment. Slightly tighten the four bracket knobs.
- Continue to adjust brackets until you have achieved the best fit.
- Tighten all 5 knobs (be careful not to over tighten) and adjust mirror to best viewing position.



Passenger side configuration

Changing from driver side to passenger side configuration:


Remove and rotate clamps to change from driver to passenger side mirrors Remove mirror head with Phillips screw driver to remove and rotate inside clamp

Warning!

Do not over tighten.

Check frequently to make sure mirror is secure.

Remove when not towing.



Clamp-On Mirror with patent pending rod end