



Color Adapt POD Remote

RF Controlled

A= CYCLE COLOR

15 Solid Colors +
Rainbow Strobe &
Rainbow Fade

C= SOLID FADE (ON)

(CHANGE COLOR TO CANCEL STROBE)

C= Speed (-) (Rainbow Strobe/
Fade)



B= SOLID STROBE (ON)

(CHANGE COLOR TO CANCEL STROBE)

B= Speed (+) (Rainbow Strobe/
Fade)

D= ON/OFF (POWER)

(Unit retains last pattern when powered off)

Battery Type = 27A 12V