## **DK188 Rhino-Rack** VA, Aero, Euro & HD <u>crossbar</u> instruction











	VA crossbar AER						AERO	<u>crossbar</u>		EURO crossbar		HD crossbar		
				FRONT CROSSBAR					REAR CROSSBAR					
					CID VA	AERO EURO	HD				VA	AERO EURO	₩ HD	
Vehicle	Date	Crossbar	Front Right Pad/ Clamp	Front Left Pad/ Clamp	Measurement strip length per side	Measurement strip length per side	Measurement Distance ( x )	Foot plate arrow direction	Rear Right Pad/ Clamp	Rear Left Pad/ Clamp	Measurement strip length per side	Measurement strip length per side	Measurement Distance ( x )	Foot plate arrow direction
Ford Flex 5dr 2008 W/O rails on	2008 on	1500mm / 59,1/16"			138mm	83mm	1164mm / 45,53/64"	OUT	M3 SUB(	)259	130mm	75mm	1148mm / 45,13/64"	OUT
		,	Arr FORV				·		Arrow FORWARD				.,	





## **DK188 Rhino-Rack** VA, Aero, Euro & HD crossbar instruction

**Measurement A**: CENTRE of door jamb to CENTRE arrow of leg foot plate.

**Measurement B**: CENTRE of Front leg foot plate arrow to CENTRE of Rear leg foot plate arrow.

Carrying capacity: Roof rack is rated to 75kg. Please refer to manufacturers handbook for your vehicles maximum roof load capacity. Always use the lower of the two figures.





VEHICLE	Date	Measurement A	Measurement B	Load Rating (includes racks 5kg/ 11lbs)
Ford Flex 5dr W/O rails	2008 on	250mm / 9,27/32"	800mm / 31,1/2"	75kg / 165lbs