


Pulley Mounting Bracket


part number 8700-PBC

Installation Instructions


The pulley can be rotated in three different ways.



Use any of the eight mounting holes for the four self-tapping screws, based on the application.



A minimum of three selftapping screws must be used.



The bracket can be bent to fit around obstructions.

Parts list

- (1) pulley mounting bracket
- (4) machined screws with nuts
- (4) self-tapping screws

Product description: the bracket is intended to facilitate installation of the InvisiBrake pulley in those vehicles without a pulley mounting location due to recesses or obstructions in the firewall.

Installation instructions

- 1. Position the pulley and bracket under the brake pedal arm so that the pulley will be directly in line with the cable.
- The pulley can be rotated on the bracket in one of three ways, as shown above.
- Choose a mounting location for the bracket that will allow you to attach it with at least three of the four selftapping screws, as shown above.

- If necessary, any part of the bracket can be bent, as shown above.
- **2.** Attach the pulley to the bracket with the four machined screws and nuts, with the nuts at the top of the bracket.
 - 3. Attach the bracket with the self-tapping screws.



Read and follow all installation instructions included with your InvisiBrake before installing the pulley – it is imperative that the pulley be in proper alignment with the brake pedal. Failure to properly install the pulley could cause property damage, personal injury or even death.

IMPORTANT NOTICE!

Safety Definitions

Statements in these instructions identified as follows are of special significance.



WARNING indicates a potentially hazardous situation which, if not avoided, could result in property damage, serious personal injury or even death.



CAUTION indicates a potentially hazardous situation which, if not avoided, may result in property damage, or minor or moderate personal injury.

CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

NOTE

Refers to important information and is placed in italic type. It is recommended that you take special notice of these items.