

Installation Instructions for Toyota A341E Transmission Solenoids

1. Remove the old solenoids from transmission.
2. Insert new solenoids. Refer to **Figure** at right for proper location of solenoid/bracket assembly.
3. Insert mounting bolt making sure to attach solenoid ground wire.
4. Plug in wiring harness.

Note: Be aware that solenoid may rotate during normal operation. Position lead wires away from any moving parts.

