Table Of Contents

Acknowledgments

Preface

Introduction

Chapter 1:

Tools and Equipment

Safety Equipment

Sockets and Wrenches

Snap Ring Pliers

Screwdrivers

Measuring Devices

Spring Compressors

Case Holding Fixtures

Workbench

Shop Vise

Lathe

Pans for Small Parts

Case Cleaners

Bushing Removers and Installers

Heli-Coils and Bolt Extractors

Air Tools

Punches, Chisels and Files

Lip Seal Installation Tools

Oil Pump Band

Alignment Studs

Slide Hammer

Special Tools

Chapter 2:

Transmission Fundamentals

Do It Yourself

Torque Converter

Transmission Oil Pump

Clutch Packs

Bands and Servos

Accumulators

Planetary Gears

Roller and Sprag Clutches

Torque Converters

Valve Body

Chapter 3:

Transmission Removal

Support the Vehicle

Prep for Removal

Lower the Transmission

Chapter 4:

TH350 Disassembly

Oil Pan and Valve Body Removal

Servo Assembly Removal

Support Plate, Separator Plate, Check Balls and Filters Removal

Manual Shaft and Linkage Removal

1-2 Accumulator Removal

Vacuum Modulator and Modulator Valve Removal

Oil Pump Removal

Intermediate Clutch Pack and Intermediate Band Removal

Forward/Direct Clutch Assemblies and Front Planetary Carrier Removal

Governor Removal

Tail Housing and Speedometer Gears Removal

Front Planetary and Sun Gear Assembly Removal

Center Support and Low/Reverse Roller Clutch Assembly Removal

Output Shaft and Low/Reverse Clutch Pack Removal

Low/Reverse Apply Piston Removal Case Cleaning and Rebuilding Preparation Chapter 5: TH350 Assembly Case Bushing Removal and Replacement Low/Reverse Apply Piston Installation

Output Shaft Front Bushing Removal and Replacement

Component Installation

Forward Clutch Drum Rebuild

Direct Drum Rebuild

Oil Pump Assembly Rebuild

Torque Convertor Bushing Installation

Speedometer Installation

Governor Installation

Accumulator Seals Removal and Replacement

1-2 Accumulator Installation

Intermediate Servo Installation

Manual Shaft Installation

Vacuum Modulator Installation

Valve Body Installation

Chapter 6:

Shift Kits and Performance Modifications

Application Types

Custom Mods

TransGo Kits

Shift Kit Installation

Tuning Shift Points

High-Performance Modifications

Chapter 7:

Transmission Installation

Troubleshooting Guide

Source Guide