


Features

MagicMount™ is the award-winning magnetic mounting system for securely mounting mobile devices and more to a wide variety of surfaces. These 3 simple steps make your Original PopSockets® grip compatible with the MagicMount™ system.

- Pop out your grip
- Remove Plastic cap. Stick MagicPlate™ on the backside of the cap. Replace cap onto grip
- Now you are MagicMount™ compatible.



100% Safe Powerful Earth Magnets That Are 30% More Powerful

These powerful earth magnets hold your device securely in place even on the bumpiest roads and are 100% safe for Smartphones Tablets GPS and other mobile devices* How strong are they? Strong enough that we trust them holding a GoPro Session when take out our Can-Am Maverick 1000XRS. Don't believe us? Just watch the video.

*Does not work with iPod Classic or other hard drive devices. The strong magnetic fields produced by these Neodymium magnets is enough to damage hard drive devices.



Mounting Your Device Is Easy

Once the MagicPlate™ is applied as shown further down this page just hover your device near the magnetic surface and it instantly locks securely in place. The sleek cradle-free design works perfectly with larger devices and allows you to position your screen for optimal viewing.

Interchangeable Trim Rings For An Element of Fashion Flair

The MagicMount PRO brings the mobile device mounting system to a whole new level with interchangeable trim rings. A Silver and Black trim ring is included with your purchase. Not your colors? Apple device color match trim rings Space Gray Gold Rose Gold as well as Carbon Fiber will be available for purchase.



360° Swivel Mount

Being able to angle your smartphone just how you want it is easy. With a 360° swivel mount and soft rubber locking nut adjust your MagicMount precisely to the angle of display that works best for you to view. Whether on your car dashboard work desk or nightstand get the perfect position.

*PopSockets® is a registered trademark of PopSockets LLC ("PopSockets"). PopSockets® is not affiliated with Scosche nor does it endorse use of PopSockets® grips with Scosche products including MagicPlate. Use of MagicPlate with PopSockets® grips could result in damage to the grip and/or decreased functionality.

MAGICPLATE™ Placement Options

MAGICPLATE™, non-magnetic, adhesive-backed, metal plates, are an integral component of the MagicMount™ Magnetic Mount System for mobile devices. Just apply the Scosche replacement plates as shown to the right and you are ready to use any one of the many MagicMount products available in this growing family of magnetic mounts. MagicPlates come in a variety of sizes and shapes depending upon which MagicMount you buy and replacement kits are also available.

There are several ways to apply the Scosche replacement plates to your device.

- Directly to the back of the case
- Directly to the mobile device
- Between the device and case - either with or without using the adhesive




INSTRUCTIONS FOR APPLYING THE MAGICPLATE THAT CAME WITH YOUR MAGICMOUNT™

Wireless Charging Devices

It is important to mount the MagicPlate in the proper location to avoid interfering with wireless charging functionality. We have created a MagicPlate Template Guide to assist wireless phone users who plan to use their device with our MagicMount Charge products or other Scosche wireless chargers.

* The MagicMount is not recommend with use of a wallet case.



Protect your device when directly applying MagicPlate to your device

MagicMounts come with a protective plastic film sticker in the box. This film should ALWAYS be used when you are applying the MagicPlate directly to your mobile device using the adhesive based MagicPlate. Doing this will aid in the ease of removal of the MagicPlate should you wish to do that in the future. We have created a short video to show you how to properly apply the plastic film followed by the MagicPlate.

