INSTALLATION & CARE



2019-UP DODGE RAM 1500 DRL LIGHT BAR WITH LIGHTING EFFECT HEADLIGHT

BEFORE INSTALLATION:

- If you experience any difficulties that the instructions did not cover, please seek assistance at a local automotive shop.
- · Please wear proper protective equipment before you work on any vehicle.
- An assistant is recommended when removing the front bumper from your vehicle.
- · Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.
- Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.


TOOLS AND SUPPLIES REQUIRED

10 mm Socket 8 mm Socket Trim Pad Remover 6" Socket Extension 10 mm Wrench

PRODUCT NUMBER

2LH-RAM1915-G3-RS 2LH-RAM1915G-G3-RS 2LH-RAM1915JM-G3-RS 2LH-RAM1915SM-G3-RS

LET'S START THE INSTALLATION



Remove the twelve plastic fasteners on the radiator upper support cover



Remove the radiator upper support cover



Remove the eight 10mm bolts at the top of the upper grille trim



Remove the upper grille trim



Remove the four 8mm bolts on the fender liner



Pull away the fender liner



Remove the 10mm bolt



Grab the edge and pull forward to unseat the filler panel



Grab the other end and pull out to remove the filler panel, repeat for the opposite side



Remove the three 10mm bolts at the bottom of the front grille for both side



Remove the four 10mm bolts at the top of the front grille



Unseat the front grille upper leg for both side



Remove the front grille



Remove the 10mm bolt at the bottom of the headlight



Remove the 10mm bolt at the top of the headlight



Unseat the factory headlight housing



Disconnect the headlight harness and remove the factory headlight housing




Remove the signal light socket, parking light socket, and high&low beam light bulbs from the factory headlight housing



Remove the signal light socket, parking light socket, and high&low beam light bulbs from the factory headlight housing



Remove the signal light bulb from the signal light socket



Reinstall the signal light bulb to the signal light socket on the new headlight housing



Reinstall the high beam light bulb to the new headlight housing



Reinstall the low beam light bulb to the new headlight housing



Reinstall the parking light socket to the new headlight housing



Connect the headlight harness




Seat the new headlight assembly in place



Reinstall the 10mm headlight bolt at the top of the headlight



Reinstall the 10mm headlight bolt at the bottom of the headlight



Please repeat the steps from 14 to 27 for the opposite side



Remove the fuse box cover



Locate the #35 fuse



Remove the #35 fuse



Install the ACC wire fuse to the #35 fuse spot



Install the ACC wire fuse to the #35 fuse spot



Reinstall the fuse box cover



Connect the ACC wire to the LH headlight connector



Connect the ACC wire to the RH headlight connector



Start the car to make sure the LED light bar is working before reinstall the front grille



Cable tie the loose wires



Cable tie the loose wires



Reinstall the front grille



Reinstall the four 10mm bolts at the top of the front grille




Reinstall the three 10mm bolts at the bottom of the front grille for both side



Reinstall the filler panel



Pull away the fender liner and reinstall the 10mm bolt



Reinstall the fender liner and the four 8mm bolts



Reinstall the upper grille trim



Reinstall the eight 10mm bolts at the top of the upper grille trim



Reinstall the radiator upper support cover



Reinstall the twelve plastic fasteners on the radiator upper support cover



Close the hood to complete the installation





