

SPEC-D *Tuning*

2000-2005 TOYOTA CELICA LED TAIL LIGHTS INSTALLATION INSTRUCTIONS

*If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.

*Please wear protection before you work on your vehicle.

*An assistant is useful when removing the front bumper from your vehicle.

*Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.

*Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



TOOLS AND SUPPLIES REQUIRED

¼" Drive Ratchet

10mm Socket

Phillips Screwdriver

Trim Pad Remover

Product Part Numbers:

LT-CEL00GLED-TM

LT-CEL00CLEL-TM

LT-CEL00JMLED-TM



2000-2005 TOYOTA CELICA LED TAIL LIGHTS INSTALLATION INSTRUCTIONS

- *If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.
- *Please wear protection before you work on your vehicle.
- *An assistant is useful when removing the front bumper from your vehicle.
- *Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.
- *Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



1. (3) Plastic clips and the (2) 10mm bolts location



2. Remove the (3) plastic clips



3. Remove the (2) 10mm bolts



4. Remove the trunk rear inner panel



5. Remove the plastic cover



6. Remove the phillips head screw



7. Pull the trunk side inner panel to the access the (3) 10mm nuts



8. Remove the (3) 10mm nuts



9. Remove the tail light



10. Disconnect the tail light harness



11. Connect the tail light harness to the LED tail light
Please see the " L.E.D. tail lights installation instructions"
If your tail lights don't have L.E.D. you can skip the installation instructions.

12. Place the LED tail light in the stock location



13. Tighten the (3) 10mm nuts

14. Replace the trunk inner panel and tighten the phillips head screw



15. Replace the plastic cover

16. Replace the inner trunk panel



17. Tighten the (2) 10mm bolts and replace the (3) plastic clips



18. Please repeat the steps in order from 1 to 17 for the opposite side



19. The installation is now complete