




| part | description | part number | qty. |
|------|----------------------------------|-------------|------|
| | | | |
| Α | Horizon Cargo Box SR7011 | SR7011 | 1 |
| В | Horizon Cargo Box SR7016 | SR7016 | 1 |
| C | Horizon Cargo Box SR7017 | SR7017 | 1 |
| - | Master Parts Bag - Quick Release | 04952 | 1 |
| D | Saddle Quick Release | 04106 | 4 |
| E | Interior Plate - 5 Hole | 03918 | 4 |
| F | Reinforcing Plate | 10378 | 4 |
| G | Carrige Bolt | 04852 | 8 |
| н | Threaded Knobs | 04877 | 8 |
| 1 | Mask, Vinyl Hole Covers | 10171 | 1 |
| J | Кеу | ~ | 2 |





• With the help of another person place box on roof rack.




Mount box towards the rear of the vehicle to minimize wind resistance.











• When you are ready to mount the carrier to the vehicle's roof rack crossrails,slide each saddle until it separates from the carriage bolt and drops down.



Make sure that loads are evenly distributed inside the roof box. Do not exceed the maximum
permitted load of 110 lbs./50 kg for the box or the maximum permitted load for the roof as
recommended by the vehicle manufacturer, as well of the maximum load of the load carrier.

UNLOCKING/LOCKING THE BOX



UNLOCKING: Insert the key and turn clockwise to the unlocked position. The key can only be removed when the box lid is closed and locked. LOCKING: To close, press down on the lid at the front and rear of the box. Turn the key counter-clockwise to lock. Remove key.


9


EXCHANGING LOCK CORES

• In order to change the existing lock core to a different lock core number, follow steps 1–9 below.

11

L





 This box is designed with a patented single opening system, allowing you to open the box from either side and providing easy access to each pair of Easy-Snaps during installation and removal. MAINTENANCE

- The roof box should be carefully cleaned and maintained, particularly in the winter months (see step 11).
- The locks should be lubricated with graphite or similar dry lubricant.
- Box should be protected from exposure to the elements during prolonged periods of storage.
- Box and fittings should be inspected periodically for damage.



GENERAL CLEANING

- Clean with mild soap and lukewarm water.
- Use a soft damp cloth or chamois. Wipe
- surface gently.
- Dry by blotting with damp cloth or chamois.
 Becommended cleaners:
- Recommended cleaners: Mr. Clean Joy Detergent Windex (ammonia or vinegar) Fantastic - all purpose 409 - all purpose
- TO RESTORE ORIGINAL LUSTER:
- Recommended spray polish & waxes: Simonize Professional "One Step Instant Polish" Turtle Wax Platinum Series "Ultra Gloss Detailer" Meguiar's "NXT Generation Spray Wax"
- Use as instructed by the manufacturer.

TO REMOVE MINOR SCRATCHES

- Recommended scratch removers: Novus plastic polish
 No. 2 - Fine scratch remover
 Use as instructed by the manufacturer.
- AVOID: wiping with cloths that may contain grit or abrasives.
- AVOID: using powdered cleaners.
- AVOID: using cleaning solutions, polishes or waxes which contain petroleum distillates or strong solvents.
- NOTE: Any product not recommended should be tested on a small inconspicuous area first. Wash off immediately if surface starts to soften or degrade in any manner.