
FUEL SYSTE SERVICE INSTRUCTION WORKSHEET

TO REPAIR

ROCHESTER CARBURETOR 2 BARREL--- Models 2G, 2GC, 2GV

- 1. Carefully read the text in the following pages to become familiar with the contents of this worksheet before performing carburetor overhaul.
- 2. The exploded view shown is typical of the model carburetor this kit will service. The view may differ slightly from the actual carburetor being overhauled.
 - PARTS LIST SHOWN DOES NOT REFLECT THE CONTENTS OF THE KIT.



- Use the exploded view as a guide. The numerical sequence may generally be fol-lowed to disassemble the carburetor far enough to permit cleaning and inspection.
- Parts list shown DOES NOT reflect the contents of the kit.
- Kit may contain extra parts intended for other carburetors within this group: Substitute identical replacement parts for original worn parts found in carburetor.

DISASSEMBLY - ASSEMBLY HIGHLIGHTS

- 1. UPON DISASSEMBLY, MARK LOCATION & NOTE POSITION OF ALL SPRINGS WHICH HAVE TO BE REMOVED.
- RETAIN ALL OLD GASKETS FOR MACHING PURPOSES.

 SOME MODELS: REMOVE LIMITER CAPS (69) BY TURNING IN #8 SHEET METAL SCREW IN CENTER OF CROSS SLOTS FORCING LIMITER CAPS OFF.
- WHEN REMOVING MIXTURE SCREWS (70) MARK POSITION, TURN IN UNTIL LIGHTLY SEATED, COUNTING NUMBER OF TURNS, TURN OUT TO INDEX MARK, RECORD NUMBER OF TURNS FOR RE-ASSEMBLY AND THEN RE-MOVE, IF MIXTURE SCREWS WERE REMOVED WITHOUT INDEXING, TURN IN UNTIL LIGHTLY SEATED, TURN OUT TWO TURNS.
- COVER OPENING ON INTAKE MANIFOLD AFTER CARBURETOR IS REMOVED.
- TO PREVENT LOSS OF COOLANT, DO NOT DISCONNECT HOSE FROM CHOKE STAT (21).
- INSTALL CHOKE HOUSING SEAL (20) WITH LIP FACING OUTWARD. LIGHTLY LUBRICATE PISTON ASSEMBLY CUP (43) BEFORE INSTALLING. DO NOT ALLOW VITON NEEDLE (39) TO BE PRESSED INTO SEAT (40).
- CHECK THROTTLE LINKAGE FOR FREEDOM OF MOVEMENT BEFORE & AFTER
- INSTALLATION OF CARBURETOR ON ENGINE. WHEN RE-INSTALLING POWER VALVE PISTON (44) IN AIR HORN ASSEMBLY (35), LIGHTLY STAKE UNIT IN PLACE.
- 12. TURN IN IDLE AIR SCREW (64, WHERE USED) UNTIL SEATED THEN TURN

CLEANING

Cleaning must be done with carburetor disassembled. Use spray cleaner and a stiff bristle brush to remove dirt and carbon deposits. Do not use abrasives and wires to clean parts and passageways. Wash off in suitable solvent, and clear all passageways with compressed air.

Caution: When cleaning with solvent do not soak or spray parts containing rubber, leather, plastic and electrical components.

PARTS LIST

- 1. Adapter, Fuel Inlet
- 2. Gasket, Adapter
- Gasket, Fuel Filter
- Filter, Fuel Inlet
- 5. Spring, Overide, Filter
- Clip, Pump Rod Lower Rod, Pump Piston
- Screw, Fast Idle Cam
- Cam. Fast Idle
- 10. Screw, Lever, Trip
- 11. Lever, Trip
- 12. Lever, Engaging Choke
- 13. Rod, Connecting, Choke
- 14. Screw, Retainer, Choke Cover
- 15. Retainer, Serrated, Choke Cover
- 16. Retainer, Choke Cover
- 17. Cover, Choke Stat Assembly 18. Gasket, Choke Cover
- 19. Deflector, Heat, Choke Cover
- 20. Seal, Choke Housing (Not Shown)
- 21. Choke Stat Cover Assembly #
- 22. Holder, Filter #
- 23. Filter, Intake Air #
- "E" Clip, Choke Pull-Off Link #
- 25. Link. Choke Pull-Off #
- Screw, Choke Shaft Slotted Lever #
- Lever, Choke Shaft Slotted # 28. Screw, Choke Pull-Off Mounting #
- 29. Choke Pull-Off Assembly #
- Screw, Vent Valve Cover #
- 31. Cover, Vent Valve #
- 32. Valve, Vent #
- 33. Screw, Air Horn Mounting (Short) 34. Screw, Air Horn Mounting (Long)
- 35. Air Horn Assembly
- 36. Rod, Float Hinge
- 37. Float Assembly
- 38. Gasket, Air Horn

- 39. Needle, Fuel Inlet
- 40. Seat, Fuel Inlet
- 41. Gasket, Seal
- 42. Clip, Pump Pisten
- 43. Piston Assembly, Pump
- 44. Piston Assembly, Power Valve
- 45. Spring, Piston Return
- 46. Ball Check, Pump Intake (small)
- 47. Screw, Center, Venturi Assy.
- 48. Gasket, Center Screw
- 49. Screw, Mounting, Venturi Assembly 50. Venturi Assembly
- 51. Gasket, Venturi
- 52. Tube, Main Well (2)
- 53. Retainer, Spring, Pump Discharge
- 54. Spring, Pump Discharge Ball
- 55. Ball Check, Pump Discharge (Large)
- 56. Jet, Main (2)
- 57 Power Valve
- 58. Gasket, Power Valve
- Screw, Hot Idle Compensator Cover
- 60. Cover, Hot Idle Compensator
- Screw, Bi-Metallic Valve
- 62. Bi-Metallic Valve. Hot Idle Compensator
- 63. Gasket, Bi-Metallic Valve
- Screw, Idle Air Adjusting (By-Pass Idle System)
- Spring, Idle Air Adjusting Screw
- Screw, Throttle Body to Main Body
- Main Body 67
- Gasket, Throttle Body to Main Body (Match up old Gasket)
- 69. Cap, Limiter #
 - 70. Screw, Idle Mixture
- Spring, Idle Mixture Screw
- 72. Throttle Body Assembly
- 73. Gasket, Flange

ADJUSTMENT DATA

FIG. A FLOAT LEVEL ADJUSTMENT

- 1. WITH GASKET IN PLACE, INVERT AIR HORN
- GAUGE AS SPECIFIED FROM AIR HORN GASKET TO TOP OF FLOAT (NOT ON SEAM)
- 3. BEND HERE TO ADJUST FLOAT LEVEL

NOTE 1: TO AVOID DAMAGING FLOAT NEEDLE, DO NOT PRESS NEEDLE INTO SEAT.

NOTE 2: CHECK FLOAT FOR CORRECT ALIGNMENT.




FIG. B FLOAT LEVEL ADJUSTMENT

- 1. INVERT AIR HORN WITH GASKET IN PLACE
- MEASURE SPECIFIED DISTANCE
 OPPOSITE HINGE END FROM OUTWARD BOTTOM EDGE OF SEAM
 TO AIR HORN GASKET.
- 3. BEND HERE TO ADJUST FLOAT LEVEL

NOTE 1: TO AVOID DAMAGING FLOAT NEEDLE, DO NOT PRESS NEEDLE INTO SEAT. NOTE 2: CHECK FLOAT FOR CORRECT ALIGNMENT.




FIG. C FLOAT LEVEL ADJUSTMENT

- 1. INVERT AIR HORN & POSITION GASKET ON PARTING SURFACE
- 2. MEASURE AS SPECIFIED FROM AIR HORN GASKET TO NOTCH AT FLOAT AS SHOWN
- 3. BEND HERE TO ADJUST FLOAT LEVEL

NOTE: TO AVOID DAMAGING FLOAT NEEDLE, DO NOT PRESS NEEDLE INTO SEAT.




FIG. D FLOAT DROP ADJUSTMENT

- POSITION AIR HORN UP RIGHT TO ALLOW FLOAT TO HANG FREE. GASKET MUST BE IN PLACE
- 2. MEASURE SPECIFIED
 DISTANCE FROM BOTTOM OF
 FLOAT TO GASKET SURFACE
- 3. TO ADJUST, BEND FLOAT TANG

NOTE: BE SURE NEEDLE DOES NOT WEDGE AT MAXIMUM DROP




FIG. E FLOAT DROP ADJUSTMENT

- 1. POSITION AIR HORN UP RIGHT TO ALLOW FLOAT TO HANG FREE. GASKET MUST BE IN PLACE
- 2. MEASURE SPECIFIED
 DISTANCE FROM NOTCH AT
 FLOAT TO GASKET SURFACE
- 3. BEND TANG TO ADJUST FLOAT DROP

NOTE: BE SURE NEEDLE DOES NOT WEDGE AT MAXIMUM DROP




FIG. F PUMP ROD ADJUSTMENT

- BACK OUT IDLE SPEED
 SCREW SO THAT THROTTLE
 VALVES ARE FULLY
 CLOSED.
- 2. MEASURE SPECIFIED DISTANCE FROM TOP OF PUMP ROD TO TOP OF AIR HORN RING
- 3. TO ADJUST, BEND ROD




FIG. G IDLE VENT ADJUSTMENT

- ADJUST IDLE TO SPECIFIED
 RPM. NOTE: IDLE STOP
 SOLENOID MUST BE
 ACTIVATED (WHERE USED)
- 2. POSITION CHOKE VALVE WIDE OPEN WITH FAST IDLE SCREW OFF STEPS OF FAST IDLE CAM
- 3. GAUGE AS SPECIFIED BETWEEN VALVE & SEAT AT WIDEST POINT
- 4. TO ADJUST, BEND TANG

MODELS PRIOR TO 1968 - OPEN THROTTLE UNTIL VENT VALVE JUST CLOSES. PLACE GAUGE ON TOP OF AIR HORN RING. DIMENSION TO TOP OF PUMP ROD SHOULD BE AS SPECIFIED. ADJUST BY BENDING TANG ON PUMP LEVER.





FIG. H AUTO CHOKE ADJUSTMENT

- 1. LOOSEN 3 HOLD-DOWN SCREWS
- 2. ALIGN INDEX MARK ON CHOKE COVER WITH SPECIFIED NOTCH ON HOUSING



ADJUSTMENT DATA (Cont'd)

FIG. I CHOKE COIL ROD ADJUSTMENTS

- FROM CHOKE LEVER, REMOVE UPPER END OF ROD & HOLD CHOKE VALVE FULLY CLOSED
- LIFT UPWARD ON ROD AGAINST STOP.
- END OF ROD SHOULD FIT GAUGE NOTCH.
- BOTTOM OF ROD EVEN WITH TOP OF HOLE.
- 5. TO ADJUST, BEND ROD.





FIG. J CHOKE ROD (FAST IDLE CAM) ADJUSTMENT

IMPORTANT: BEFORE MAKING ADJUSTMENTS 1-2-3 READ NOTE AND PARAGRAPHS "PROCEDURE 1" AND "PROCEDURE 2" BELOW.

- PLACE LOW IDLE SPEED SCREW ON 2ND STEP OF FAST IDLE CAM AGAINST SHOULDER OF HIGH STEP.
- 2. MEASURE AS SPECIFIED BETWEEN UPPER EDGE OF CHOKE VALVE AND WALL OF AIR
- 3. TO ADJUST, BEND TANG AS NECESSARY (SEE INSERT FOR

NOTE: IT IS REQUIRED THAT BOTH SLOW IDLE AND FAST IDLE SCREWS BE POSITIONED AS FOLLOWS BEFORE INITIATING A CHOKE ROD ADJUSTMENT.

ADJUSTMENT:
PROCEDURE 1 - MODELS USING
SINGLE IDLE STOP SCREW
ONLY - ROTATE STOP SCREW
CLOCKWISE UNTIL IT JUST
TOUCHES BOTTOM STEP OF
FAST IDLE CAM THEN TURN
SCREW IN ONE FULL TURN,
MODELS USING BOTH A SLOW
IDLE AND A FAST IDLE SCREWTURN SLOW IDLE SCREW IN
UNTIL IT JUST CONTACTS STOP.



THEN TURN THIS SCREW IN ONE FULL TURN FROM THIS POINT. NEXT, TURN THE FAST IDLE SCREW IN UNTIL IT TOUCHES BOTTOM STEP OF FAST IDLE CAM.

PROCEDURE 2 - ALL MODELS-POSITION FAST IDLE SCREW ON SECOND STEP OF FAST IDLE CAM AGAINST SHOULDER OF HIGH STEP, WHILE HOLDING SCREW IN THIS POSITION, CHECK CLEARANCE BETWEEN UPPER EDGE OF CHOKE VALVE AND WALL OF AIR HORN. ADJUST TO SPECIFIED DIMENSION BY BENDING TANG ON CHOKE LEVER AND COLLAR ASSEMBLY.

FIG. L VACUUM BREAK ADJUSTMENT

- USING OUTSIDE VACUUM SOURCE SEAT DIAPHRAGM PLUNGER
- 2. POSITION CHOKE VALVE CLOSED WITH ROD IN BOTTOM OF SLOT
- 3. MEA SURE AS SPECIFIED BETWEEN UPPER EDGE OF CHOKE VALVE AND WALL OF AIR HORN
- 4. TO ADJUST, BEND ROD




FIG. M

CHOKE UNLOADER ADJUSTMENT

- MAINTAIN THROTTLE
 VALVES IN WIDE OPEN
 POSITION
- 2. GAUGE AS SPECIFIED BETWEEN WALL OF AIR HORN AND UPPER EDGE OF CHOKE VALVE
- 3. TO ADJUST, BEND TANG
 (See Insert I), NOTE: ON
 SPLIT LINKAGE MODEL
 2GC, BEND TANG ON
 DECHOKE LEVER ON
 CHOKE SIDE OF
 CARBURETOR (See Insert II).





FIG. K CHOKE ROD ADJUSTMENT (SPLIT CHOKE)

NOTE: ADJUST SLOW & FAST IDLE SCREWS AS PER PROCEDURE 1, FIG. IJ

- LOCATE FAST IDLE SCREW ON SECOND STEP OF FAST IDLE CAM AGAINST HIGH STEP
- 2. ROTATE LEVER COUNTERCLOCKWISE SO RODS ARE IN END OF SLOTS
- 3. MEASURE AS SPECIFIED BETWEEN WALL OF AIR HORN AND UPPER EDGE OF CHOKE VALVE.
- 4. TO ADJUST, BEND ROD



SPECIFICATIONS BY APPLICATION

Year	Application	Float Level	Fig.	Float Drop	Fig.	Pump Rod Fig. F	Idle Vent Fig. G	Auto Choke	Fig.	Choke Rod Fig. J	Vac. Break Primary Fig. L	Unloader Fig. M
	ER — SPECIFICATION I.DA		i ig.		1 1 1g. 1	1 tg. 1	rig. u		It ig.	119.0	1 114. L	1 119.111
1968-67	283. 307. 327 Eng.	3/4	С	1-3/4	Е	1-1/8	.025	2		.060	.1001	.200
1962	283 Eng.	3/4	В	1-3/4	D	1-1/8	1	2	Ti	.060	.090	.200
HEVR				1							1	1200
1969	307 Eng.	27/32	В	1-3/4	D	1-1/8	.020	2		.060	.100	.215
1968	307. 327 Eng.	3/4	В	1-3/4	D	1-1/8	.025	2	+	.060	.100	.200
1967	283, 327 Eng.	3/4	C	1-3/4	E	1-1/8	1	2	+	.060	.1103	.200
1966-64	283 Eng.	07.		- 1	-	,0	<u> </u>			.000		.200
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Carb. No. 7024100, 102. 106, 108 Carb. No. 7036110, 112; 7024101, 110, 112 Carb. No. 7036101, 103 Carb. No. 7025103	3/4 3/4 3/4 3/4	8 8 8	1-3/4 1-3/4 1-3/4 1-29/32	0000	1-1/8 1-1/8 1-1/8 1-1/8	1 1 1 1-1/32	2 2 2 2	1	.070 .060 .060 .070	.090 .110³ .130	.200 .200 .200 .360
1963-62	283 Eng. Carb. No. 7023007, 008, 018 Carb. No. 7020007, 008, 018	3/4 1-11/32	B A	1-29/32 1-29/32	D D	1-1/8 1-1/8	1	Index4 Index4	Н	.090 .090		.350 .375
1961-56	265. 283 Eng. Exc. Carb. No. 7013652; 7012133, 451, 452, 500 Carb. No. 7019007, 008, 018;	1-1/4 1-9/32	A	1-29/32 1-29/32	D	1-1/8 1-1/8	1	Index Index	H	.090 .090	_	.375 .375
	7013007, 008, 018, 082	1-11/32	А	1-29/32	D	1-1/8	1	Index⁴	Н	.090		.375
CHRIS-				4								
	283 Eng.	1-3/8	А	1-29/32	D	29/32	**************************************	1NL	Н	.090		.350
GM TRU	icks											
1969-56	265, 283, 307 Eng. Exc. Carb. No. 17054657, 7028100, 105, 106, 107,	3/4	В	1-29/32	D	1-1/8	5		-		-	_
	111; 7027100, 105, 106 Carb. No. 7029105	3/4 27/32	B	1-3/4 1-3/4	DDC	1-1/8		2	1	.095	.130	.215
	Carb. No. 17054656; 7028125, 127 Carb. No. 7012453, 455	3/4 1-5/16	B	1-3/4 1-29/32	D	1-5/32 1-5/32	.020	Manageria Manageria				
	Carb. No. 7011132, 135; 7010649; 716, 718; 7008383, 389, 706	1-1/4	A	1-29/32	D	1-5/32			-			_
TUDE	BAKER									L		
1965	283 Eng.	3/4	В	1-3/4	TD	1-1/8	1	2	Ti	.060	.1201	.200
	AC — SPECIFICATION I.DB					Mile in the same	of 1945 1	179909-12				
1958	365 EngFront & Rear Carb.	23/32	В	1-29/32	D	1-3/16	I		T			
CHECK				1 /				L				
1965	327 EngFront & Rear Carb.	3/4	В	1-29/32	TD	1-1/8			T			1
CHEVR		0,4		1 20/02	10	11/0						
1961-58	265, 348 EngFront & Rear Carb.	1-5/166	ΙΛ	1-29/32	TD	1-3/16	1	I			T	T
1901-30	-Center Carb.	1-5/167	A	1-29/32	D	1-3/16		Index	Н	.090		375
1955	265 Eng.	1-5/32	Α	1-29/32	D	1-3/16		Index	Н	.090		.375
GM TRU	ICKS						L					
1968-56	Carb. No. 7008393, 394; 7010717; 7011143, 155 Carb. No. 7012233, 457	1-1/4 1-5/16	A	1-29/32 1-29/32	D	1-5/32 1-5/32	1		_			
	Carb. No. 7013013, 353; 7015019; 7020109; 7023027	3/4	В	1-29/32	D	1-1/8	1					
1955	Carb. No. 7006770; 7007171; 7008399	1-5/32	A	1-29/32	D	1-3/16		-	_			—
OLDSM		1 2 /0	TA	1 20/22	In	1 2/16	Т	Т		T	T	
	Front & Rear Carb.	1-3/8	A	1-29/32	D	1-3/16						
PONTIA										Т		т
1966-57	389, 421 Eng. Center Carb. Exc. Carb. No. 7011350, 500, 706, 709	23/32 ⁸ 1-9/32 ¹⁰	ВА	1-3/4 1-29/32	D	1-1/8 1-1/8	1-1/329	Index Index	Н	.055	_	.160
1958-57	347, 370 Eng. Front & Rear Carb.	1-13/3210	A	1-29/32	D	1-3/16			_	_		
WHITE												
_	327 Eng.	3/4	С	1-29/32	E	1-1/8	-					
1967												-
	- SPECIFICATION I.DC			1	D	1-11/3211	_	2NR	Н	.040		.085
	— SPECIFICATION I.DC 300 EngA/T -M/T	1/2 1/2	B	1-29/32 1-29/32	D	1-11/3211		Index	Н	.040	_	.085
1964	300 EngA/T -M/T	1/2 1/2	B B	1-29/32		1-11/3211	8			.040	1	
BUICK 1964 OLDSM	300 EngA/T -M/T	1/2	B B	1-29/32		1-11/3211	8	Index	Н		1	.085
1964 OLDSM 1964	300 EngA/T -M/T IOBILE 330 Eng.	1/2 1/2	В	1-29/32 1-29/32 1-13/16	D	1-11/3211				.040		
1964 DLDSM 1964	300 EngA/T -M/T	1/2	В	1-29/32	D	1-11/3211		Index	Н			.085

SPECIFICATIONS BY APPLICATION (Cont'd)											***************************************	
Year	Application	Float Level	Fig.	Float Drop	Fig.	Pump Rod Fig. F	Idle Vent Fig. G	Auto Choke	Fig.	Choke Rod Fig. J	Vac. Break Primary Fig. L	Unloade Fig. M
BUICK -	- SPECIFICATION I.DD							d				1 3
1969-66	300, 340, 350 Eng. Carb. No. 7026146; 7036146, 248 Carb. No. 7027044, 45, 46, 49; 7037034 Carb. No. 7028140, 141 Carb. No. 7029140, 141 Carb. No. 7026046 Carb. No. 7026047 Carb. No. 7026047 Carb. No. 7036046, 048	15/32 15/32 15/32 15/32 1/2 15/32 1/2 1/2	CCCCBCBB	1-9/32 1-9/32 1-9/32 1-7/32 1-27/32 1-9/32 1-27/32 1-27/32	EEEEDEDD	1-5/32 ¹³ 1-5/32 1-11/32 1-11/32 ¹⁵ 1-5/32 ¹³ 1-11/32 ¹¹ 1-11/32 ¹¹ 1-5/32 ¹³	1-1/16 31/32 .025 .020 1-1/16	Index Index I4 Index Index Index Index Index Index Index	エエフつエエエエ	.055 .055 .050 .050 .055 .055	120 .110	.140 .140 .140 .140 .140 .140 .140
1967-66	225 Eng. Carb. No. 7026144 Carb. No. 7026145 Carb. No. 7027050, 041, 042 Carb. No. 7036144	1/2 1/2 1/2 1/2	B B B B	1-27/32 1-27/32 1-9/32 1-27/32	0000	1-5/32 ¹³ 1-11/32 ¹¹ 1-1/16 ¹⁶ 1-1/16 ¹³	31/32 31/32	Index Index Index Index	1111	.055 .055 .055 .055		.140 .140 .140 .140
AMC, JE	EEP — SPECIFICATION I.DE											
1971	225 EngCarb. No. 7041185 -Carb. No. 7041186	1-5/32 ¹⁷ 1-5/32 ¹⁷	CC	1-7/8 1-7/8	E	1-1/6 1-1/6		Index	— Н	.055		.140
1968	350 Eng.	1-11/32	C	1-3/4	E	1-1/6	.025	14	J	.035	.065	.140
1967-66	225 Eng. Carb. No. 7026082; 7027082 Carb. No. 7026086 Carb. No. 7026089; 7027089	1-5/32 ¹⁷ 21/32 1-5/23 ¹⁷	A B A	1-3/4 1-27/32 1-3/4	DDD	1-5/32 1-5/32 1-5/32		Index	_ H	.055		.140
BUICK		***************************************		A				<u> </u>				
1965	300 Eng.	19/32	В	1-29/32	D	1-5/3213	-	Index	Н	.055	T	.140
1963-62	198 Eng. Exc. Carb. No. 7023048, 049	21/32 21/32	B B	1-29/32 1-29/32	D D	1	*****	1NR 1NR ¹⁸	H	.050 .055	_	.180
1963-61	215, 300 Eng. Exc. '62 LeSabre Carb. No. 70019042	21/32 11/16	B B	1-29/32 1-29/32	D D	1-11/32 1-1/8	access and a second	Index 1NR	H	.050 .035	3-	.160
CHECK	ER		aller services and the services are the services and the		-		10111011	1,80,	100	en in		
1962	226 Eng.	5/8	В	1-29/32	D	1-11/32		Index	TH	.050	T -	.160
GRAY N	MARINE			Annes de la constante de la co		A		L				
11 28/4-248 21 28/11-2	215 Eng.	5/8	В,	1-29/32	D	1-11/32		Index	Н	.050		.160
DLDSM	OBILE					f		*****	andaman da			
63-61	215 Eng. Exc. Carb. No. 7023056, 058	9/16 25/32	B B	1-13/16 1-13/16	D	1-3/16 1-3/16	and the same of th	19 Index	H	.080		.260
PALME	RMARINE				3 4	Maria					***************************************	
	215 Eng.	5/8	В	1-29/32	D	1-11/32			T-T		_	
PONTIA	C					**************************************					-	
62-61	215 Eng.	21/32	В	1-29/32	D	1-11/32		Index	Н	.050	T	.160
CRUSA	DER MARINE — SPECIFICATION I	.DF		Name of the last o	A			L			A	
	153 Eng. Carb. No. 7025082	5/8	В	1-29/32	D	1-5/32		Index	Н	.040		.160
KIEKHA	EFER MARINE						1.7					
	153 Eng.	5/8	В	1-29/32	D	1-5/32	-	Index	H	Andrews .		.160

FOOTNOTES:

- 1 Carb. No. 7037080, 7024110 set .110".
- ² Bottom of rod even with top of hole.
- 3 Carb. No. 7024101, 7027101, 103; 7037101, 103 set .120".
- ⁴ Carb. No. 7023007 set 1NL. Carb. No. 7020007; 7019007 set 1NR.
- ⁵ Carb. No. 7015015; 7013009, 011 set 1"
- 6 Carb. No. 7013015, 017, 973, 975 set 1-13/32".
- 7 Carb. No. 7011952; 7012503 set 1-1/4".
- 8 Carb. No. 7024074, 75, 173, 175; 7025070, 74, 75, 173, 175, 177 set 11/16".
- ⁹ Carb. No. 7024074, 75, 173, 175 do not set idle vent.
- 10 Carb. No. 7011350, 351, 352, 500 set 1-5/16".
- 11 Install pump rod in outer hole.
- 12 Carb. No. 7024057, 059 set 17/32".
- 13 Install pump rod in inner hole.
- ¹⁴ Rod in gauge notch.
- 15 Carb. No. 17054649 set 1-15/32".
- 16 Carb. No. 7027042 set 1-5/32".
- 17 From gasket to top of float at toe.
- 18 M/T set index.
- 19 1961 models set 1NL; 1962 models set Index.

ABBREVIATIONS:

A/T - Automatic Transmission

Cal. - California Exc. - Except

M/T - Manual Transmission

N/L - Notch Lean N/R - Notch Rich