

# Installation Instructions

## TAIL LIGHT GUARD

### 04-08 FORD F150 (EXCL. HERITAGE EDITION)

**Step 1:** Locate hardware and check contents with hardware listed below.

QTY	DESCRIPTION
1	Taillight Guard (Left & Right)
4	#14 x 1 ¼" Sheet Metal Screws
4	#14 Flat Washers

**Step 2:** Remove the two mounting screws that support the taillight to the vehicle as shown in Figure 1. Carefully unfasten clips and remove taillight.

Step 3: Orient Taillight Guard onto taillight light housing. Make sure that the support bracket hooks to the taillight housing (Figure 2).

Step 4: Locate (2) #14 x 1 ¼" Sheet Metal Screws and (2) # 14 Flat Washers. Take the Taillight Guard assembly and align holes on the guard with mounting holes on the vehicle. Secure the guard to the vehicle by using the hardware listed in this step (Figure 3).

**Open and close the tailgate slowly, to be certain that the Guard does not interfere with tailgate. NOTE:** During shipping Brackets may loose their shape. In order to get a proper fit Bracket might need to be re-shaped slightly.

Step Five: Repeat steps 2-4 for opposite side.

Remove  
Factory  
Screws




Figure 1



Figure 2



Figure 3

#14 x 1 ¼" Sheet  
Metal Screw,  
#14 Flat Washers