



STREET SCENE EQUIPMENT, INC.

950-77820 SATIN FINISH
&
950-78820 CHROME FINISH
2004
FORD RANGER
SPEED GRILLE INSERT

INSTALLATION INSTRUCTIONS


VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
4	11" Cable Ties	1	Instruction Sheet	1	Right Speed Grille Insert
1	Care For Grilles	1	Street Scene Emblem	1	Center Speed Grille Insert
8	Installation Clips # 71099			1	Left Speed Grille Insert

TOOL LIST	
Flat Blade Screwdriver	


1. Remove the grille shell assemble from the vehicle by removing the four fasteners across the top and pulling gently to release the bottom clips.
2. Set the grille shell on a covered table or bench. Remove the " FORD " logo. Take care not to break the pins and tabs if you would like to re-install over the Speed Grille.
3. Install the right and left side Speed Grilles with two cable ties for each side. Refer to photos below for installation.

PHOTOS



4. Install the center Speed Grille into the opening. Fasten from the back side using four installation clips across the top and four across the bottom. Refer to illustration for clipping procedure.

ILLUSTRATION



5. If you would like to install the "FORD" emblem insert the mounting studs through the Speed Grille and into tabs on grille shell. Adjust Speed Grille to align holes.
6. Install grille back on vehicle. NOTE: if the metal mounting clips did not come out when removing the grille remove them and install on grille shell before installing grille on vehicle.