# SUMITOMO TIRES2022 Medium Truck Tires





## **Medium Truck Tires**

Sumitomo medium truck tires are known for outstanding performance in the toughest applications. Innovative design and fantastic quality control make the difference.

Built for long tread life, casing durability and multiple retreads, these tires are available in one of the widest ranges of sizes and tread designs.

Sumitomo **Premium Series** medium truck tires include a collection of advanced features we call S-Tech Design. The technology in these tires is remarkable. They share a technical architecture that delivers high mileage, inhibits irregular wear, improves driver satisfaction, and retains casing integrity through multiple retread cycles.



Sumitomo's new Premium Series medium truck tire lines reinforce the company's reputation for precision engineering, innovative technology, and craftsmanship.



The company's Medium Truck Tire line reinforces Sumitomo's reputation for precision engineering, innovative technology and craftsmanship.

## **The Sumitomo Brand**

Sumitomo is the premium export brand of Sumitomo Rubber Industries, Ltd., one of the largest tire manufacturers in the world. Within the tire industry, Sumitomo enjoys a well-earned reputation for innovative design, precision engineering and superior quality. It's the Sumitomo difference.

With a reputation for quality, service and leading edge technology, Sumitomo Tire is a premium tire brand offering a unique mix of 1st tier quality and 2nd tier value.

Sumitomo is backed by the reputation and resources of the Sumitomo Group, one of the most influential business groups in the world. Sumitomo Tire is a global brand that competes on the basis of product quality and real-world performance.



## **Sumitomo manufactures EPA SmartWay™ verified technologies**

Tires are an integral link in the transmission of energy from the engine to the road. Tires that meet EPA SmartWay criteria for reduced rolling resistance help save fuel and reduce vehicle emissions. That's good for everybody. Components manufactured with SmartWay Verified technologies can lower the cost of operating trucks and lower the impact on the environment.

Based upon data provided by tire manufacturers and EPA testing and research, EPA determined that certain tire models can provide a reduction on NOx emissions and an estimated fuel savings of 3% or greater, relative to the "best selling" new tires for line haul trucks, when used on all five axles on long haul class 8 trucks.

Sumitomo has enhanced the value of its three best long haul patterns by engineering them for lower rolling resistance. S-Tech casing design PLUS less rolling resistance equals long mileage to removal, excellent durability, multiple retread cycles and reduced fuel cost.

Sumitomo offers a full range of high-quality medium truck tires that are designed for hard work and manufactured to precise standards.

# More miles to removal. Great handling for safety. Built to be retreaded. Sumitomo tires give you a competitive edge.

## **SmartWay Technology**

Sumitomo has incorporated SmartWay Verified technology into its Premium Series Long Haul patterns for all three axle positions. Coupled with the proven benefits of Sumitomo S-Tech casing architecture, these tires are the right choice for operators who care about long term value, and improving the environment.

Sumitomo tires with SmartWay Verified technology are designated with the suffix SE.




# ST788 SE

## Premium Series | Long Haul Steer

- Unique teardrop shaped decoupling groove to reduce shoulder strain and prevent tearing.
- Micro edge sipes to reduce irregular wear resulting in dramatically improved treadwear.
- Stone ejectors in the base of the tread groove to promote casing integrity.
- Wide shoulder elements and improved tread compounds deliver superior mileage.
- Built with SmartWay Verified Technology.







The new ST788SE is Sumitomo's most advanced S-Tech Design steer tire for long haul operations. With the latest design elements, the ST788SE provides exceptional mileage with advanced compounding properties. For extended service life, the tire features robust shoulder elements to ensure long, even wear and stone ejectors to help promote casing integrity. Exceptional performance and low rolling resistance offer peace of mind and savings for fleets.

## ST788SE Featuring SmartWay Verified Technology

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5533252	11R22.5	146/143L	H/16	8.25	7.50	6,610	6,005	120	41.4	11.3	12.5	18	19.3	502	75
5533259	11R24.5	149/146L	H/16	8.25	7.50	7,160	6,610	120	43.1	11.4	12.5	18	20.2	482	75
5533275	295/75R22.5	146/143L	H/16	9.00	8.25	6,610	6,005	120	40.0	11.4	13.2	18	18.7	519	75
5533278	285/75R24.5	147/144L	H/16	8.25	7.50	6,780	6,175	120	41.2	10.8	12.5	18	19.4	504	75

## ST-7-3+SE

## **SUMITOMO TIRES**

## Long Haul Series | Steer

- Flat Contact Technology reduces potential for irregular wear by controlling the shape and pressure distribution of the tire footprint.
- Shoulder grooves work with the wide, flat tread radius to control irregular wear.
- Micro sipes protect the interior ribs from punch wear.
- Even longer wearing tread compound on the outside, cool running base rubber compound on the inside.
- Stone ejectors protect the casing in base of the tread groove.
- Built with SmartWay Verified Technology.





The ST778+ SE is a SMARTWAY Verified long haul steer tire. Incorporating a collection of features, the ST778+ SE delivers superior miles to removal, excellent handling for safe operation and dependable retreadability of the Sumitomo casing.

## ST778+ SE Featuring SmartWay Verified Technology

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5532852	11R22.5	146/143L	H/16	8.25	7.50	6,610	6,005	120	41.5	11.3	12.5	18	19.3	501	75
5532859	11R24.5	149/146L	H/16	8.25	7.50	7,160	6,610	120	43.2	11.3	12.5	18	20.2	481	75
5532875	295/75R22.5	144/141L	G/14	9.00	8.25	6,175	5,675	110	40.1	11.5	13.2	18	18.8	518	75
5532878	285/75R24.5	144/141L	G/14	8.25	7.50	6,175	5,675	110	41.3	11.0	12.5	18	19.4	503	75

# ST948SE

## Premium Series | Long Haul Drive

- Extra-deep 30/32 skid depth for long mileage with features designed in the base of the shoulder grooves to resist stone drilling.
- Wide tread blocks minimize tread squirm to lower rolling resistance and promote long, even tread wear.
- Equipped with a wider footprint to distribute weight over a wider contact patch.
- Micro sipes in the tread blocks provide increased traction.
- Built with SmartWay Verified Technology.







The new ST948SE is Sumitomo's highest mileage and most fuel efficient drive tire. Equipped with the latest advancements in S-Tech Design to maximize original tread life and lower rolling resistance, the ST948SE is best suited for long distance, coast-to-coast operations. A unique combination of superior compounding and deep tread design give the ST948SE better fuel efficiency to improve your fleets operating costs.

## ST948SE Featuring SmartWay Verified Technology


Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5533152	11R22.5	146/143L	H/16	8.25	7.50	6,610	6,005	120	42.1	11.4	12.5	30	19.6	493	75
5533159	11R24.5	149/146L	H/16	8.25	7.50	7,160	6,610	120	44.3	11.3	12.5	30	20.7	468	75
5533175	295/75R22.5	144/141L	G/14	9.00	8.25	6,175	5,675	110	40.8	11.1	13.2	30	19.1	509	75
5533178	285/75R24.5	144/141L	G/14	8.25	7.50	6,175	5,675	110	42.2	10.7	12.5	30	19.8	492	75



## Long Haul Series | Drive

- Extra deep 30/32nds tread depth promotes extended mileage wear.
- Closed-shoulder tread design provides long, even wear while providing excellent traction.
- Heavy-duty casing provides stability and promotes retreading.
- Stone drilling buttons protect casing for long life.
- Increased base rubber dissipates heat while running at high speeds in long haul operations.





The ST938 is a closed shoulder DEEP TREAD drive tire. Incorporating a collection of advanced features, the ST938 delivers remarkable mileage, excellent handling and dependable retreadability you've come to expect with Sumitomo casings.

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5532452	11R22.5	146/143L	H/16	8.25	7.50	6,610	6,005	120	42.3	11.3	12.5	30	19.7	489	75
5532459	11R24.5	149/146L	H/16	8.25	7.50	7,160	6,610	120	44.3	11.4	12.5	30	20.7	470	75
5532475	295/75R22.5	144/141L	G/14	9.00	8.25	6,175	5,675	110	40.8	11.5	13.2	30	19.0	508	75
5532478	285/75R24.5	144/141L	G/14	8.25	7.50	6,175	5,675	110	42.1	11.0	12.5	30	19.7	493	75

My the second section of the second s

# ST710 SE

## **Premium Series** | Trailer

- Sumitomo four steel belt casing construction resists punctures, increases trailer stability and contributes to more retread cycles.
- Shoulder grooves control migration of irregular wear.
- A wide footprint enhances vehicle stability and delivers long mileage.
- Pyramid shaped ribs put more rubber on the road as the tire wears.
- Stone ejectors protect the casing from damage in the base of the groove.







The SMARTWAY-Verified ST710SE merges the advantages of an advanced concept low-skid tread pattern with the long-term durability of a premium Sumitomo casing. Its high quality construction yields years of service. It wears long and smooth when new and is designed for multiple retread cycles.

## ST710SE Featuring SmartWay Verified Technology

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5532651	11R22.5	144/142L	G/14	8.25	7.50	6,175	5,840	105	41.0	11.2	12.5	12	18.7	507	75
5532658	11R24.5	146/143L	G/14	8.25	7.50	6,610	6,005	105	43.0	11.1	12.5	12	19.8	483	75
5532675	295/75R22.5	144/141L	G/14	9.00	8.25	6,175	5,675	110	39.8	11.3	13.2	12	18.3	522	75
5532678	285/75R24.5	144/141L	G/14	8.25	7.50	6,175	5,675	110	41.1	10.5	12.5	12	19.0	506	75

# ST719SE


## **SUMITOMO TIRES**

## Premium Series | Regional Steer

- Deep 21/32" tread depth for maximum mileage in the steer position.
- Stone ejectors in the base of the tread groove to promote casing integrity.
- Wide solid shoulders evenly dispense contact pressure for long, even wear with high wear performance tread compound to boost resistance to tread scrubbing.
- Wavy tread groove design to resist tread groove strain while slightly stiffening shoulder rigidity for improved handling.
- Built with SmartWay Verified technology.







The ST719SE is Sumitomo's newest deep regional steer tire designed to deliver high mileage in regional applications. With a variety of the latest S-Tech Design features, this tire delivers excellent traction, even wear, better fuel efficiency and ride comfort. With improved high-scrub compounding properties, the ST719SE provides the performance you require.

## ST719SE Featuring SmartWay Verified Technology

	duct de	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5533	3352	11R22.5	146/143L	H/16	8.25	7.50	6,610	6,005	120	41.6	11.3	12.5	21	19.4	499	75
5533	3359	11R24.5	149/146L	H/16	8.25	7.50	7,160	6,610	120	43.4	11.4	12.5	21	20.3	479	75
5533	3375	295/75R22.5	146/143L	H/16	9.00	8.25	6,610	6,005	120	40.3	11.7	13.2	21	18.8	516	75
5533	3378	285/75R24.5	147/144L	H/16	8.25	7.50	6,780	6,175	120	41.3	10.9	12.5	21	19.4	503	75

# ST709SE

## Regional Series | Steer

- Beefy 20/32" tread depth applied to a wide, flat casing for much longer life in high scuff applications.
- Chevron block center ribs with lateral sipes effectively cut water on wet roads for enhanced traction and safety.
- Thick curbing ribs help shield casing from sidewall damage.
- Stone ejectors protect the casing from damage in the base of the tread groove.
- An innovative design helps control irregular wear during on-highway use.
- Built with SmartWay Verified Technology.





The ST709SE is a regional steer tire that's durable enough when there's serious work to be done, but versatile enough to display on-highway manners.

## ST709SE Featuring SmartWay Verified Technology

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5532952	11R22.5	146/143L	H/16	8.25	7.50	6,610	6,005	120	41.5	11.1	12.5	20	19.4	500	75
5532959	11R24.5	149/146L	H/16	8.25	7.50	7,160	6,610	120	43.5	11.1	12.5	20	20.4	477	75
5532975	295/75R22.5	144/141L	G/14	9.00	8.25	6,175	5,675	110	40.2	11.3	13.2	20	18.8	517	75
5532978	285/75R24.5	144/141L	G/14	8.25	7.50	6,175	5,675	110	41.6	10.6	12.5	20	19.5	500	75



## Premium Series | Open Shoulder Drive

- Deep shoulder blocks for increased traction.
- Significantly wider tread face offers more consistent retreadability.
- Stone ejectors protect the casing from damage in the base of the tread groove.
- Advanced Y-shape groove design improves stone ejection, traction, and contributes to long tire life.







The new ST909 is Sumitomo's most advanced S-Tech Design drive tire for regional applications. With the latest design elements, the ST909 provides superior traction, more miles per 32nd and an extra wide tread face for increased vehicle stability. Exceptional performance and outstanding retreadability are strengths of the line.

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5533082	225/70R19.5	128/126N	G/14	6.75	6.00	3,970	3,750	110	32.3	8.7	10.0	22	14.3	644	87
5533086	245/70R19.5	136/134N	H/16	7.50	6.75	4,940	4,675	120	33.5	9.5	11.0	22	15.6	620	87
5533048	10R22.5	141/139L	G/14	7.50	6.75	5,675	5,355	115	40.6	10.0	11.4	24	19.0	511	75
5533052	11R22.5	146/143L	H/16	8.25	7.50	6,610	6,005	120	42.1	11.1	12.5	28	19.6	493	75
5533055	12R22.5	152/149L	H/16	9.00	8.25	7,830	7,160	123	43.0	12.0	13.5	28	20.0	486	75
5533059	11R24.5	149/146L	H/16	8.25	7.50	7,160	6,610	120	44.2	11.1	12.5	28	20.7	470	75
5533075	295/75R22.5	146/143L	H/16	9.00	8.25	6,610	6,005	120	40.7	11.4	13.2	28	19.0	511	75
5533087	255/70R22.5	140/137M	H/16	7.50	6.75	5,510	5,070	120	36.9	9.9	11.3	26	17.3	562	81
5533078	285/75R24.5	144/141L	G/14	8.25	7.50	6,175	5,675	110	42.1	10.8	12.5	28	19.7	495	75

# ST 908

## Value Series | Open Shoulder Drive

- A continuous center rib delivers long life and highway stability, while shoulder lugs bite for excellent traction on soft surfaces.
- 26/32" tread depth promotes long life and year round service.
- Four steel belt casing construction resists punctures, increases vehicle stability, and contributes to more retread cycles.





## The ST908 open shoulder drive tire has an excellent reputation among fleets.

	Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
į	5531217*	10.00R20	146/143K	H/16	7.50	7.00	6,610	6,005	120	41.8	10.9	12.5	26	19.5	498	68
	5531252	11R22.5	146/144L	H/16	8.25	7.50	6,610	6,005	120	41.9	10.9	12.6	26	19.6	495	75
	5531263	315/80R22.5	154/151M	J/18	9.00	9.00	8,270	7,610	120	42.8	12.3	13.8	25	19.8	486	81
	5531275	295/75R22.5	144/141L	G/14	9.00	8.25	6,175	5,675	110	40.7	10.7	13.2	26	19.0	512	75
	5531287	255/70R22.5	140/137M	H/16	7.50	6.75	5,510	5,070	120	36.9	9.9	11.3	25	17.2	578	81

<sup>\*</sup> Includes tube and flap

# ST 718

## Metro Series | Rib

- Sumitomo all steel casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.
- Application specific tread compound resists the effects of scuffing from sharp turns and promotes long mileage.
- Curbing ribs help shield the casing from sidewall damage.





## An excellent commercial rib tire for urban and metro fleet operations.

1	Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
	5530045*	8R19.5	124/122L	F/12	6.00	5.25	3,525	3,305	110	33.7	7.8	9.2	16	15.8	616	75

<sup>\* 4-</sup>rib pattern design

## Metro Series | Drive

- Radical shoulder ribs act like traction bars and stabilize the tread for long life in commercial service.
- Center island tread elements for traction during wet or dry maneuvers. Reinforcing "bridges" of rubber tie together the tread package for vehicle stability and resistance to irregular wear.
- Multi-phase shift tread pattern minimizes tire noise.
- Curbing ribs help shield the casing from sidewall damage.
- Sumitomo all-steel casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.







Engineered for the rough metro environment, the ST918 gives the traction needed to get the job done in bad weather. Its computer designed tread pattern and application specific compounds deliver long mileage, great traction, and vehicle stability.

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5531781	225/70R19.5	125/123M	F/12	6.75	6.00	3,640	3,415	95	32.1	8.8	10.0	20	14.9	647	81
5531782	225/70R19.5	128/126M	G/14	6.75	6.00	3,970	3,750	110	32.1	8.8	10.0	20	15.0	647	81
5531785	245/70R19.5	133/131M	G/14	7.50	6.75	4,540	4,300	110	33.4	9.5	10.0	21	15.6	612	81



# ST 719

## Premium Series | All Position Rib

- Wide tread face for increased vehicle stability.
- Anti Scrub tread compounds.
- Advanced casing design for improved retreadability.
- Stone ejectors in the base of the tread groove to promote casing integrity.















The all-new ST719 is designed to meet the demands of regional and urban delivery service. Driven by advanced design features, including a wider tread width and high tread wear performance compounds, the ST719 delivers more miles per 32nd.


Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5533466*	215/75R17.5	135/133L	H/16	6.00	6.00	4,805	4,540	123	30.4	8.3	9.4	16	14.0	683	75
5533471*	235/75R17.5	143/141L	J/18	6.75	6.75	6,005	5,675	127	31.6	9.4	10.3	17	14.8	658	75
5533473*	245/70R17.5	143/141L	J/18	7.50	6.75	6,005	5,675	127	31.2	10.0	11.0	16	14.3	666	75
5533472	225/70R19.5	125/123N	F/12	6.75	6.00	3,640	3,415	95	31.9	8.7	10.0	16	15.0	651	87
5533482	225/70R19.5	128/126N	G/14	6.75	6.00	3,970	3,750	110	31.9	8.7	10.0	16	15.0	651	87
5533485	245/70R19.5	133/131N	G/14	7.50	6.75	4,540	4,300	109	33.1	9.4	11.0	16	15.4	628	87
5533486	245/70R19.5	136/134N	H/16	7.50	6.75	4,940	4,675	120	33.1	9.5	10.6	16	15.4	628	87
5533489	265/70R19.5	140/138M	H/16	7.50	7.50	5,510	5,205	112	34.2	10.1	11.6	16	15.9	608	81
5533462	315/80R22.5	157/154L	L/20	9.00	9.00	9,090	8,270	130	42.2	12.4	13.8	18	19.6	492	75
5533469	245/75R22.5	134/131L	G/14	7.50	6.75	4,675	4,300	110	37.3	9.6	11.0	18	17.6	557	75
5533487	255/70R22.5	140/137M	H/16	7.50	6.75	5,510	5,070	120	36.5	9.8	11.3	19	17.1	569	81
5533496	275/70R22.5	148/145M	J/18	8.25	7.50	6,940	6,395	130	37.9	10.9	12.2	18	17.7	548	81

<sup>\*</sup> For free rolling service in normal highway use

## **Utility Series** | All Position Rib

- Sumitomo four steel belt casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.
- Application specific tread compound resists the effects of scuffing from sharp turns and promotes long mileage.
- 5-rib design provides better vehicle stability in all weather conditions.





These lines offer many hard to find sizes and ply ratings. Every tire is engineered to be Sumitomo tough.

ST727															
Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5530504*	8.25R15	130/128K	G/14	6.50	6.00	4,080	3,860	120	33.1	9.3	10.6	14	15.5	627	68
5530507*	10.00R15	137/135K	G/14	7.50	7.00	5,070	4,805	105	36.1	10.7	12.5	16	16.5	566	68
5530540	10R17.5	134/132L	H/16	7.50	6.75	4,675	4,410	115	33.9	9.8	11.4	16	15.8	615	75
5530510*	8.25R20	136/134K	G/14	6.50	6.00	4,940	4,675	120	37.9	9.1	10.6	16	17.8	546	68
5530513*	9.00R20	138/136K	F/12	7.00	6.50	5,205	4,940	100	40.1	10.0	11.7	17	18.8	518	68
5530517*	10.00R20	146/143L	H/16	7.50	7.00	6,610	6,005	120	41.2	10.9	12.5	17	19.2	506	75
5530520*	11.00R20	150/147L	H/16	8.00	7.50	7,390	6,780	120	42.5	11.5	13.0	18	19.9	490	75
5530523*	12.00R20	154/151K	J/18	8.50	8.00	8,270	7,610	120	44.1	11.8	14.2	19	20.6	473	68
5530546	9R22.5	136/134L	G/14	6.75	6.00	4,940	4,675	120	38.1	8.9	10.3	16	17.8	545	75
5530548	10R22.5	141/139L	G/14	7.50	6.75	5,675	5,355	115	40.2	10.0	11.4	16	18.9	515	75
5530552	11R22.5	146/143L	H/16	8.25	7.50	6,610	6,005	120	41.2	10.9	12.6	17	19.3	504	75
5530555	12R22.5	150/147M	H/16	9.00	8.25	7,390	6,780	120	42.5	11.3	13.5	18	19.8	491	81
5530559	11R24.5	149/146L	H/16	8.25	7.50	7,160	6,610	120	43.4	11.0	12.6	17	20.3	479	75
														-	

ST717															7
5530438	9R17.5	129/127K	G/14	6.75	6.00	4,080	3,860	120	33.1	8.9	10.3	16	15.4	632	68
5530442	11R17.5	137/135K	G/14	8.25	7.50	5,070	4,805	105	36.4	11.7	12.6	17	16.7	582	68
5530426*	13/80R20	153/149K	J/18	9.00	8.50	8,050	7,160	110	41.2	12.5	14.5	19	19.2	506	68
5530429*	14/80R20	157K	J/18	10.00	9.00	9,090	-	120	43.0	13.5	-	20	19.8	491	68

<sup>\*</sup> Includes tube and flap

# ST 528

## **SUMITOMO TIRES**

## Heavy Series | Premium All Purpose

- Deeper tread depth increases time in service and provides more traction at all wheel positions.
- Application specific tread compounds resist tread chipping in high-scuff on and off-road applications.
- Rust inhibitor compounds coat all interior steel belts and body ply components.
- Thick curbing ribs help shield the casing from sidewall damage.
- Stone ejectors protect the casing from damage in the base of the groove.
- Extra thick layer of undertread rubber protects the belt package.
- Sumitomo four steel belt casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.











With its class-leading 26/32" tread depth on the standard sizes and the 10,200lbs. load carrying capacity on size 315/80R22.5, the ST528 is a Premium On and Off-Highway Mixed Service All-Position Tire.

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5532052	11R22.5	146/143K	H/16	8.25	7.50	6,610	6,005	120	42.0	11.1	12.6	26	19.6	494	68
5532059	11R24.5	149/146K	H/16	8.25	7.50	7,160	6,610	120	44.1	11.1	12.6	26	20.5	471	68
5532063	315/80R22.5	161/157K	L/20	9.00	9.00	10,200	9,090	130	42.7	11.2	13.8	24	19.7	491	68

# ST 518

## Heavy Series | All Position

- Sumitomo four steel belt casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.
- Application specific tread compound resists cutting and chipping.









## Durable all-position tires for mixed service use.

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5531116*	10.00R20	146/143K	H/16	7.50	7.00	6,610	6,005	120	41.5	11.0	12.5	20	19.5	502	68
5531120*	11.00R20	150/147K	H/16	8.00	7.50	7,390	6,780	120	42.8	11.7	13.2	21	19.9	488	68
5531155	12R22.5	150/147K	H/16	9.00	8.25	7,390	6,780	120	42.8	12.0	13.5	21	20.0	488	68

## **Heavy Series** | All Position

- Sumitomo four steel belt casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.
- Application specific tread compound resists cutting and chipping.









Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5531023*	12.00R20	154/151K	J/18	8.50	8.00	8,270	7,610	120	44.1	12.1	14.2	21	20.5	474	68
5531032*	11.00R22	150/146K	H/16	8.00	7.50	7,830	7,160	120	44.7	11.7	13.0	20	21.1	462	68
5531035*	11.00R24	154/151K	H/16	8.00	7.50	8,270	7,610	120	46.9	11.5	-	20	21.8	276	68

<sup>\*</sup> Includes tube and flap



# ST520

## **SUMITOMO TIRES**

## Heavy Series | Premium Wide Base

- Deeper tread depth for more traction and in-service time.
- Stone ejectors protect the casing from damage in the groove base.
- Application specific tread compound resists cutting and chipping.
- Four steel belt casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.
- Premium series featuring S-Tech Design.











The ST520 is the Premium Wide Base Mixed Service All-Position Line that has 40% more usable tread depth than many of our competitors.

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5531990	385/65R22.5	158L	J/18	11.75	11.75	9,370	-	120	42.5	14.9	-	24	19.7	484	68
5531993	425/65R22.5	165K	L/20	12.25	12.25	11,400	-	125	44.5	16.6	-	24	20.4	473	68
5531996	445/65R22.5	168K	L/20	13.00	13.00	12,300	-	120	45.6	17.8	-	24	20.8	464	68

# ST720

## **Heavy Series** | Value Wide Base

- Wide shoulder ribs stabilize the vehicle in turns and at highway speeds.
- Application specific tread compound resists cutting and chipping.
- Four steel belt casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.









Wide base tire with a reputation for high mileage and vehicle stability in mixed service applications.

1	Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width	Min Rim Width	Single Max Load	Dual Max Load	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius	Revs Per Mile	Max Speed (mph)
1	5531490	385/65R22.5	158L	J/18	(inch) 11.75	(inch) 11.75	(lbs) 9,370	(lbs)	120	42.2	14.9	-	18	(inch) 19.4	502	68
	5531493	425/65R22.5	165K	L/20	12.25	12.25	11,400	-	125	44.2	16.5	-	19	20.4	478	68
3	5531496	445/65R22.5	168K	L/20	13.00	13.00	12,300	-	120	45.3	17.6	-	20	20.7	470	68



## **SUMITOMO TIRES**

## Heavy Series | Free Rolling Wide Base

- Notches in solid shoulder ribs reduce effects of scuffing during turns.
- Application specific tread compound resists cutting and chipping.
- Four steel belt casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.







## A wide-base tire specially designed for spread-axle trailer service.

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Rim Width	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5531590	385/65R22.5	158L	J/18	11.75	11.75	9,370	-	120	42.2	14.8	-	18	19.5	498	68

# ST900

## Heavy Series | Extra Deep Lug

- 31/32" tread depth provides more traction and longer wear.
- Application specific tread compound resists cutting and chipping.
- Sumitomo four steel belt casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.
- Special liner compound helps keep moisture from entering the casing.









A rugged drive tire designed for off-highway operations. From the rust inhibitors on its internal steel components to its deep 31/32" tread depth, ST900 is built from the inside-out to be durable and long wearing.

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5530717*	10.00R20	146/143G	H/16	7.50	7.00	6,610	6,005	120	42.3	11.1	12.5	31	19.8	490	55
5530752	11R22.5	146/143G	H/16	8.25	7.50	6,610	6,005	120	42.2	11.2	12.6	31	19.9	489	55
5530755	12R22.5	150/147G	H/16	9.00	8.25	7,390	6,780	120	43.4	11.9	13.5	31	20.3	479	55
5530759	11R24.5	149/146G	H/16	8.25	7.50	7,160	6,610	120	44.4	10.9	12.6	31	20.8	458	55

<sup>\*</sup> Includes tube and flap

# ST 901

## **Heavy Series** | Extra Deep Traction

- 32/32" tread depth gives priority to off-road traction.
- Spacing of lugs allows for placement of chains when even more traction is needed.
- Application specific tread compounds resist tread chipping in high-scuff on and off-road applications.
- Rust inhibitor compounds coat all interior steel belts and body ply components.
- Thick curbing ribs help shield the casing from sidewall damage.
- Stone ejectors protect the casing from damage in the base of the groove.
- Extra thick layer of undertread rubber protects the belt package.
- Sumitomo four steel belt casing construction resists punctures, increases vehicle stability and contributes to more retread cycles.





## A tough traction tread for the most rugged logging and off-highway applications.

Product Code	Tire Size	Service Desc.	Load Range / Ply	Pref Rim Width (inch)	Min Rim Width (inch)	Single Max Load (lbs)	Dual Max Load (lbs)	I.P. (psi)	Overall Diameter (inch)	Section Width (inch)	Min Dual Spacing (inch)	Tread Depth (X/32")	Static Loaded Radius (inch)	Revs Per Mile	Max Speed (mph)
5531852	11R22.5	146/143K	H/16	8.25	7.50	6,610	6,005	120	42.5	11.4	12.5	32	19.7	489	68
5531859	11R24.5	149/146K	H/16	8.25	7.50	7,160	6,610	120	44.4	11.1	12.6	32	20.7	468	68






## **Premium Series** | S-Tech Design

Engineering

S-Tech Design is a collection of the most advanced features Sumitomo has to offer in the new medium truck lines. It is the optimal combination of specific features in each line working together for maximum performance and durability. All Sumitomo tires are designed with a four belt package.



## **Flat Contact Technology**

Sumitomo's sophisticated new technology minimizes irregular wear by controlling the contact pressure in the tire footprint. Flat Contact Technology delivers uniform contact pressure from shoulder to shoulder. The contact length of the shoulder rib in the tire footprint is almost equal to that of the center rib, so the contact patch is kept square while in contact with the ground. This leads to a uniform contact pressure distribution and significant resistance to irregular wear.

## Technical Data

## **Tube-Type Mounting And Demounting**

Any inflated tire mounted on a rim contains explosive energy. The use of damaged, mismatched or improperly assembled tire/rim parts can cause the assembly to burst apart with explosive force. If you are struck by an exploding tire, rim part or air blast, you can be seriously injured or killed.

#### **Demounting Tube-Type Tires**

- If a tire has been running under-inflated or if any damage to the tire or wheel is suspected, the valve core should be removed prior to removing the tire/wheel assembly from the vehicle axle. This is to prevent a possible accident.
- 2. Before unlocking any side ring or lock ring, remove the valve core and allow the tire to deflate completely.
- 3. Remove all rim or wheel parts.
- 4. Inspect the tire for damages.

### **Mounting Tube-Type Tires**

- Insert the proper size tube into the tire and partially inflate (3 psi) to round out the tube (with larger sizes it may be necessary to use bead spreaders – see the next two sections for mounting instructions).
- Insert the valve through the flap valve hole. (Make sure the reinforced patch which is directly over the flap valve hole is facing outwards.) Then insert the remainder of the flap into the tire.
- 3. Check the flap wings to insure against folding. This is easily accomplished by placing your hand into one tire side, then the other, then running your hand along the entire flap wing.
- 4. Inflate the tube until the flap is secure against the tire wall and the beads start to spread apart, making sure not to exceed 3 psi.
- Apply a proper tire lubricant to both beads and the exposed flap. Make sure that excess lubricant does not run down into the tire.
- 6. Place tire, tube and flap on the wheel or rim, taking care to center the valve in the slot.
- 7. Fit side ring and lock ring, insuring that they are properly positioned, locked and are correct for the "fitment."

## Mounting Tube-Type Tires Using Manual Spreaders:

- Follow steps 1 through 3 of the "mounting of Tube-Type Tires". However, before inserting the flap into the tire, position two bead spreaders in the following manner:
  - a. Place the first at a 90° angle to the valve.
     (Flap is positioned between the spreader and the tube.)
  - b. Place the second directly opposite the first.
  - c. Spread the beads and insert the flap.
  - d. Close the beads, remove spreaders.
- 2. Follow steps 4 through 7 of the "Mounting of Tube-Type Tires".

#### Mounting Tube-Type Tires Using Automatic Spreaders:

- 1. Spread the beads.
- 2. Inflate the tube to approximately 3 psi.
- 3. Insert the tube into the tire.
- 4. Insert the valve through the flap hole. (As mentioned, the flap reinforced valve area must face outwards.)
  Insert the remainder of the flap into the tire.
- 5. Close the beads.
- 6. Follow steps 4 through 7 of the "Mounting of Tube-Type Tires".

## **Inflation of Tube-Type Tires**

 An air line with an extension (30" minimum), in-line gauge and clip-on valve chuck should be used for inflation. Remove valve core and lay the assembly flat on the ground. Using an OSHAapproved restraining device, inflate to 5 psi to seat beads.

- While the tire is still in the restraining device, make sure all rim components are centered and locked properly. If not, the tire must be deflated, broken down, relubricated and reinflated.
- 2. Deflate the tire by removing the air line. This allows the tube to relax, thus eliminating any wrinkles or uneven stretching that may have occurred during primary inflation.
- 3. Install the valve core and, using a safety cage or other OSHAapproved restraining device, reinflate the tire to the pressure shown on the sidewall in order to ensure proper bead seating, then adjust the tire to the proper operating pressure.
- 4. Reinspect the assembly for proper positioning of all components.
- 5. Check for leaks and install a metal or hard plastic valve cap.
- Do not reinflate any tires that have been run under-inflated or flat without careful inspection for damage.

## **Tubeless Tire Mounting and Demounting**

Reinflation of any type of tire/rim assembly that has been operated in a run-flat or under inflated condition (80% or less of recommended pressure) can result in serious injury or death. The tire may be damaged on the inside and can explode while you are adding air. The rim parts may be worn, damaged or dislodged and can explosively separate.

#### **Demounting Tubeless Tires**

- 1. Before loosening any nuts, deflate the tire by removing the valve core.
- 2. With the tire assembly lying flat, unseat the bead seat of both beads with a bead breaker tool. Do not use hammers of any type.
- Apply a proper tire lubricant to the tire beads, rim ledges and flanges.
- 4. Beginning at the valve, remove the tire using tire irons designed for this purpose. Starting here will minimize chances of damaging the bead. Make certain that the flange with the tapered ledge that has the shortest span to the drop center is facing up. Always attempt to keep the bead not being worked by the irons in the full depth of the drop center cavity.

#### **Mounting Tubeless Tires**

- Replace valve stem grommet and inspect valve stem for damage and wear. Replace valve stem if necessary.
- 2. Apply lubricant
- With the wheel/rim short ledge up, lay the tire over the rim at the valve side and work it on with proper tubeless tire tools, making full use of the drop center well.
- Do not use any kind of hammer. Bead damage may occur leading to tire destruction and serious or fatal injury to you, or your customer.

## **Inflating Tubeless Tires**

Reinflation of any type of tire/rim assembly that has been operated in a run-flat or under inflated condition (80% or less of recommended pressure) can result in serious injury or death. The tire may be damaged on the inside and can explode while you are adding air. The rim parts may be worn, damaged or dislodged and can explosively separate.


- Lay tire/wheel assembly horizontally and inflate to no more than 5 psi to position the beads on the flanges.
- 2. To complete the seating of the beads, place the assembly in an OSHA-approved safety cage and inflate to 25 to 30 psi. Check the assembly carefully for proper bead seating and for any signs of distortion or irregularities from the run-flat.
- 3. If beads are properly seated, and if no damage is detected, continue to inflate to the maximum air pressure marked on the sidewall. If beads do not seat, deflate tire, relubricate the bead seats and reinflate.
- After beads are properly seated, adjust tire pressure to recommended operating pressure. Check valve core for leakage, then install a metal or hard plastic valve cap.

## **Drive Axle Alignment**

Drive axle alignment is very important. Tandem drive axles that are not parallel to each other have a definite effect on steer-tire wear.

Fig. 1 shows a model of a tandem-drive axle tractor with both drive axles in proper alignment. In this case, the driver simply steers the truck straight ahead and neither fast wear nor irregular wear would be expected as a result of the driving axles.

A more severe case is shown in Fig. 2. Here, the drive axles are neither parallel to each other nor perpendicular to the chassis center line. The drive axle tires are trying to force the vehicle to turn left and the driver must compensate by turning to the right. This will result in fast and irregular wear and, as recent tests have shown, in a much more severe way than the previous case. Tests also indicate that the steer tire on the same side of the truck, on which the drive tires are closest together, will wear into an out-of-round condition.



## **Vehicle Alignment**

For best vehicle handling and tire life, proper vehicle alignment is required. For best readings on alignment settings, vehicle should be loaded. However, many vehicle manufacturers also have tolerances for alignment settings when vehicle is unloaded. Before starting, correct any air pressure differences in tires and make sure vehicle is on a level surface, with brakes off.

## **Drive Axle Recommendations**


Irregular wear patterns on steer axle tires may come from misaligned drive axles and trailer axles, not to mention the obvious loss of tire mileage, vehicle handling and fuel economy. Drive and trailer axle alignment is normally set before stee-axle corrections are made.

## DRIVE AXLES SHOULD BE ALIGNED IN THE FOLLOWING MANNER:

- 1. Position the drive axles perpendicular to the chassis center line.
- 2. For tandem drives, the drive axles should be positioned parallel to one another.

  Trailer axles should be aligned to the center line of the trailer pin at the start of settings.
- 3. Position axles to be perpendicular to the trailer center line and parallel to each other.

## **Front Axle Recommendations**




### **TOE-IN**

Toe-in-set close to zero as vehicle manufacturer's recommendations allow in loaded condition. Do not set beyond zero as a toe-out condition will develop.



## CASTER

Caster-set to the maximum positive setting that vehicle manufacturer's recommendations allow.



## CAMBER

Camber-set as close to zero degrees as the vehicle manufacturer's recommendations allow in loaded condition.

WARNING: There is a danger in installing a tire of one rim diameter on a rim of a different diameter. Always replace a tire on a rim with another tire of exactly the same rim diameter designation and suffix letters. For example a 16" tire goes with a 16" rim. Never mount a 16" size diameter tire on a 16.5" rim. While it is possible to pass a 16" diameter tire over the lip or flange of a 16.5" size diameter rim, it cannot be inflated enough to position itself against the rim flange. If an attempt is made to seat the tire bead by inflating, the tire bead will break with explosive force and could cause serious injury or death. Rims of different diameters and tapers cannot be interchanged.

## Technical Data

## **Recommendations For Long Tire Life**

Tire Maintenance

Inspect tire conditions regularly. Look for signs of sidewall bulges, cracking, cuts and stone retention in grooves. If you have a question or concern, consult your Sumitomo Tire dealer.

## Tire Replacement

By Department of Transportation regulations, any trailer or drive axle tire is to be removed from service when there are only 2/32" of tread left (or 4/32" on steer axle tires) in any tread groove. Sumitomo advises that, as a rule of thumb, tires should be removed at 4/32" remaining tread to allow better casing recovery for retreading.

## Proper Tire Inflation

It is advisable to check all tire inflation pressures before each trip, or at least weekly. The best time to obtain accurate readings is when tires are cool to the touch, before any distance is traveled. Consult the air pressure guidelines in this book, or refer to the tire sidewall or pressure charts from the Tire and Rim Association. When speeds are constantly above 70 m.p.h., it is recommended to use maximum air pressure for good wear and performance. For safety and ease of checking air pressure, metal flow-through valve caps should be used.

#### Tire Rotation

Because of vehicle specifications (wheelbase, horsepower, gears, suspension) and terrain, most tires used on drive axles wear faster on the rear-drive axle than on the front-drive axle. By cross rotating rear-axle tires to front-axle position, and front-axle tires moved to rear axle position, wear can be equally controlled on all drive positions, resulting in longer miles in service.

## Practice Good Driving Habits

- Avoid fast starts and sudden stops.
- Avoid using only trailer brakes to slow vehicle.
- Avoid potholes and debris (safely).
- Avoid hitting curbs.
- Do not exceed speed limit.

## **Determining Correct Tire Pressure**

A tire requires proper air pressure to adequately carry the load placed on it. The tires also provide traction for braking and steering. Since the loaded vehicle weight determines tire inflation pressure, all tire manufacturers offer a load/inflation table to help determine the proper pressure.

These tables reflect values taken from the Tire and Rim Association. In general, use these steps to determine correct air pressure:

- Always check air pressure when ambient temperature is cold.
- 2. Confirm if tire will be used in a single or dual wheel position.
- 3. In either case, determine the total weight that is allowed on the axle. In the case of a STEER axle (using two tires) divide the value by two.
- 4. Compare this value with the following load inflation table, and use the corresponding air pressure.

Also consider operating speeds. Many tire manufacturers recommend maximum speeds for various tire applications. Consult your Sumitomo representative if you have questions.

The SPEED SYMBOL indicates the speed at which the tire can carry a load corresponding to its load index under normal service conditions suggested by Sumitomo.

The LOAD INDEX is a code which reflects the maximum load a tire can carry at the speed indicated by its SPEED SYMBOL, based on the service application suggested by Sumitomo.

## Technical Data

## **Load Inflation Table**

## **SUMITOMO TIRES**

н			ш								ш							
Г	Legend S= Single	PSI	65	70	75	80	85	90	95	100	105	110	115	120	125	127	130	135
	D= Dual														120	127	100	100
	8.25R15	S D		2780 2700	2930 2810	3080 2930	3200 3040	3340	3470 3260	3590 3360	3750 (F)	3860 3635	3970 3745	4080 (G)				
	10.00R15	S		3780	3980	4170	4370	3150 4540 (F)	4715	4890	3525 (F) 5070 (G)	5270	5470	3860 (G) 5675 (H)				
	10.001113	D		3660	3830	3980	4130	4300 (F)	4470	4640	4805 (G)	4990	5175	5355 (H)				
	9R17.5	S		3000	3030	3300	3200	3340	3470	3590	3750 (F)	3860	3970	4080 (G)	4190		4300	4410 (H)
	31117.3	D					3040	3150	3260	3360	3525 (F)	3635	3745	3860 (G)	3970		4080	4190 (H)
	10R17.5	S					3860 (E)	4005	4150	4300 (F)	4235	4390	4540 (G)	3000 (0)	3970		4000	4130 (H)
	101117.5	D					3640 (E)	3785	3930	4080 (F)	4470	4640	4805 (G)					
	11R17.5	S					4370	4540 (F)	4715	4890	5070 (G)	5270	5470	5675 (H)				
	111117.5	D					4130	4300 (F)	4470	4640	4805 (G)	4990	5175	5355 (H)				
	8R19.5	S		2540	2680	2835 (D)	2955	3075	3195 (E)	3305	3415	3525 (F)	3173	3333 (11)				
	01110.5	D		2460	2570	2680 (D)	2785	2890	3000 (E)	3100	3200	3305 (F)						
	8.25R20	S		3370	3560	3730	3890	4080 (E)	4235	4390	4540 (F)	4675	4810	4940 (G)				
	0.231120	D		3270	3410	3550	3690	3860 (E)	4005	4150	4300 (F)	4425	4550	4675 (G)				
	9.00R20	S		4080 (D)	4280	4480	4675 (E)	4850	5025	5205 (F)	5360	5515	5675 (G)	4073 (0)				
	3.001120	D		3860 (D)	4045	4230	4410 (E)	4585	4760	4940 (F)	5080	5220	5355 (G)					
	10.00R20	S		4530	4770	4990	5220	5510 (F)	5730	5950	6175 (G)	6320	6465	6610 (H)				
	10.001120	D		4380	4580	4760	4950	5205 (F)	5415	5625	5840 (G)	5895	5950	6005 (H)				
	11.00R20	S		4940	5200	5450	5690	6005 (F)	6205	6405	6610 (G)	6870	7130	7390 (H)				
	11.001120	D		4940	4990	5190	5390	5675 (F)	5785	5895	6005 (G)	6265	6525	6780 (H)				
	12.00R20	S		5620	5920	6200	6480	6740	7160 (G)	7380	7600	7830 (H)	8050	8270 (J)				
	12.001120	D		5440	5680	5910	6140	6360	6610 (G)	6790	6970	7160 (H)	7390	7610 (J)				
	13/80R20	S		J++0	3000	3310	0140	7085	7340	7570	7815	8045 (J)	7550	7010 (3)				
	14/80R20	S						7595	7860	8110	8365	8610	8850	9095 (J)				
	11.00R22	S		5240	5520	5790	6040	6395 (F)	6650	6910	7160 (G)	7380	7600	7830 (H)				
	11.001122	D		5080	5300	5520	5730	5840 (F)	6095	6350	6610 (G)	6790	6970	7160 (H)				
	11.00R24	S		5570	5860	6140	6420	6780 (F)	7060	7340	7610 (G)	7830	8050	8270 (H)				
	11.001124	D		5390	5630	5860	6090	6175 (F)	6430	6690	6940 (G)	7160	7380	7610 (H)				
	9R22.5	S		3370	3560	3730	3890	4080 (E)	4235	4390	4540 (F)	4675	4810	4940 (G)				
	31122.3	D		3270	3410	3550	3690	3860 (E)	4005	4150	4300 (F)	4425	4550	4675 (G)				
	10R22.5	S		4080	4280	4480	4675 (E)	4850	5025	5205 (F)	5360	5515	5675 (G)	4073 (0)				
	101122.3	D		3860	4045	4230	4410 (E)	4585	4760	4940 (F)	5075	5210	5355 (G)					
	11R22.5	S		4530	4770	4990	5220	5510 (F)	5730	5950	6175 (G)	6320	6465	6610 (H)				
	111122.3	D		4380	4580	4760	4950	5205 (F)	5415	5625	5840 (G)	5895	5950	6005 (H)				
	12R22.5	S		4940	5200	5450	5690	6005 (F)	6205	6405	6610 (G)	6870	7130	7390 (H)				
	121122.3	D		4780	4990	5190	5390	5675 (F)	5785	5895	6005 (G)	6265	6525	6780 (H)				
	11R24.5	S		4820	5070	5310	5550	5840 (F)	6095	6350	6610 (G)	6790	6970	7160 (H)				
	111124.3	D		4660	4870	5070	5260	5510 (F)	5675	5840	6005 (G)	6205	6405	6610 (H)				
	215/75R17.5	S		4000	3375	3540	3695	3860	4010	4065	4225	4385	4545	4705	4805 (H)			
	213/731117.3	D			3200	3350	3500	3650	3800	3840	3995	4145	4295	4445	4540 (H)			
	235/75R17.5	S			0200	4200	4410	4615	4820	5025	5225	5420	5620	5810	6005 (J)			
	200,701117.0	D				3970	4170	4365	4555	4745	4935	5125	5310	5495	5675 (J)			
	245/70R17.5	S	3330	3505	3735	3915	4175	4310	4495	4685	4850	5070	5225	5410	5575 (0)	5675		
	210/101117.3	D	3570	3760	4000	5190	4430	4610	4815	5015	5190	5425	5600	5800		6005		
	225/70R19.5	S	3370	2895	3040	3195 (E)	3315	3450	3640 (F)	3715	3845	3970 (G)	4100	4190 (H)		5005		
	LLO, FUTTO.J	D		2720	2860	3000 (E)	3115	3245	3415 (F)	3490	3615	3750 (G)	3855	3970 (H)				
	245/70R19.5	S	3085	3265	3425	3640	3740	3890	4080 (F)	4190	4335	4540 (G)	4620	4805 (H)				
	210/701110.3	D	2910	3070	3220	3415	3515	3655	3860 (F)	3940	4075	4340 (G)	4345	4540 (H)				
	265/70R19.5	S	3415	3650	3830	3970	4180	4355	4540	4685	4850	5070 (G)	10-10	1040 (11)				
	203/101113.3	D D	3195	3430	3600	3750	3930	4095	4340	4405	4415	4675 (G)						
	245/75R22.5	S	3133	3470	3645	3860	3975	4140	4300	4455	4610	4675 (G)						
	LTO/ FULLE.U	D D		3160	3315	3525	3615	3765	3970	4055	4195	4300 (G)						
	255/70R22.5	S		3100	0010	4190	4370	4550	4675	4895	5065	5205 (G)	5400	5510 (H)				
	233/101122.3	D D				3970	4110	4275	4410	4455	4610	4675 (G)	4915	5070 (H)				
	275/70R22.5	S				3970	7110	4270	5400	5630	5850	6070	6290	6510	6730		6940 (H)	
	213/101122.3	D D							4980	5180	5390	5590	5800	6000	6200		6395 (H)	
	295/75R22.5	S		4500	4725	4940	5155	5370	5510 (F)	5780	5980	6175 (G)	6370	6610 (H)	0200		0000 (H)	
	233/13NZZ.3	D D		4095														
	215/90D22 5			4095	4300	4540	4690 6415	4885	5070 (F)	5260 7100	5440	5675 (G)	5795	6005 (H)	9600		0000 (1.)	
	315/80R22.5	S			5875	6175	6415	6670	6940 (G)	7190	7440	7610 (H)	7920	8270 (J)	8690		9090 (L)	
	205/65D22 5	D		6200	5345 6720	5675	5840 7250	6070	6395 (G)	6545	6770 9510	6940 (H)	7210	7610 (J)	7910		8270 (L)	
	385/65R22.5	S		6380	6720	6940	7350	7650	8050	8230	8510	8820 10500 / IV	9050	9370 (J)				
	425/65R22.5	S		7590	7990	8270	8740	9100	9370	9790	10100	10500 (J)	10700	11400 (L)				
	445/65R22.5	S		8230	8660	9090	9480	9870	10200 (H)	10600	11000	11400	11700	12300 (L)				
L	285/75R24.5	S			4770	4940	5210	5450	5675 (F)	5835	6040	6175 (G)	6440	6780 (H)				
		D			4340	4540	4740	4930	5205 (F)	5310	5495	5675 (G)	5860	6175 (H)				

## **Truck Tire Warnings!**

Important: Be sure to read this safety information. Make sure that everyone who services tires or vehicles in your outlet has read and understands these warnings.

## SERIOUS INJURY OR DEATH CAN RESULT FROM FAILURE TO FOLLOW SAFETY WARNINGS.

No matter how well any tire is constructed, punctures, impact damage, improper inflation, improper maintenance or service factors may cause serious tire failure creating a risk of property damage and serious or fatal injury to you, and/or your customer.

Encourage your customers to examine their tires frequently for snags, bulges, excessive treadwear, separations or cuts. If such conditions appear, advise them to demount the tire, use the spare and see you immediately. If you spot any of the above conditions bring them to the customer's attention immediately. For safety, comply with the following warnings.

Tire and rim servicing can be dangerous and must be done only by trained personnel using proper tools and procedures. Failure to read and comply with all procedures may result in serious injury or death to you or others.

Reinflation of any type of tire/rim assembly that has been operated in a run-flat or under-inflated condition (80% or less of recommended pressure) can result in serious injury or death. The tire may be damaged on the inside and can explode while you are adding air. The rim parts may be worn, damaged or dislodged and can explosively separate.

Use of starting fluid, ether, gasoline or any other flammable material to lubricate, seal or seat the beads of a tubeless tire can cause the tire to explode or can cause the explosive separation of the tire/rim assembly resulting in serious injury or death. The use of any flammable material during tire servicing is absolutely prohibited.

Any inflated tire mounted on a rim contains explosive energy. The use of damaged, mismatched or improperly assembled tire/rim parts can cause the assembly to burst apart with explosive force. If you are struck by an exploding tire, rim part or the air blast, you can be seriously injured or killed.

Re-assembly and the inflation of mismatched parts can result in serious injury or death. Just because parts come in together does not mean that they belong together. Check for proper matching on all rim parts before putting any parts together.

Mismatching tire and rim diameters is dangerous. A mismatched tire and rim assembly may explode and can result in serious injury or death. This warning applies to 14", 14.5", 16" and 16.5" tires and rims as well as other similarly mismatched size combinations. Never assemble a tire and rim unless you have positively identified and correctly matched the parts.

If the tire is 20% below the recommended operating pressure it must be considered flat. The tire must be removed, dismounted and inspected for punctures or other damage.

#### **Mounting And Demounting**

A tire cannot perform properly unless it is mounted properly on the correct size rim or wheel. The following are general instructions for demounting and mounting tube-type and tubeless tires. For detailed instructions on mounting and demounting truck tires on particular types of rims and wheels, refer to the instructions of the rim and wheel manufacturer or the Rubber Manufacturer Association (RMA) wall charts.

#### 1. SELECTION OF PROPER COMPONENTS AND MATERIALS:

- a. All tires must be mounted with the proper tube and flap (if required) and rim or wheel as indicated in the application data books.
- b. Make certain that rim/wheel components are properly matched and of the correct dimensions for the tire.
- c. Always fit new tube in a new mounting. Since the tube will exhibit growth in size through normal use, an old tube used in a new mounting increases the possibility of tube creasing and chafing, possibly resulting in failure.

- d. Always install a new flap in a new mounting. A flap through extended use becomes hard and brittle. After limited time, it will develop a set to match the tire and rim in which it is fitted. Therefore, it will not exactly match a tire/rim combination.
- e. Always install new valve cores, and metal or hard plastic valve caps containing plastic or rubber seals. On tubeless truck tire valve stems, replace the rubber grommet. For tires requiring 'O' Rings, be sure to install a new one at every tire change.
- f. Always use a safety device such as an inflation cage or other OSHA-approved device when inflating. Never stand over tire or in front of a tire when inflating. Always use a clip-on valve chuck with hose extension and stand to the side when inflating.

#### 2. TIRE AND RIM LUBRICATION:

It is essential that an approved vegetable oil base soap solution tire lubricant be used for mounting of tubeless and tube-type tires. The lubricant serves the following purposes:

- Minimizes the possibility of damage to the tire beads from the mounting tools.
- Eases the insertion of the tire onto the rim by lubricating all contacting surfaces.
- Assists proper bead seating (tire/rim centering) and helps prevent eccentric mountings.
- A. TUBELESS TIRES Apply lubricant to all surfaces of the bead area of the tire. When applying lubricant to the rim, lubricate the entire rim surface from flange to flange.
- B. TUBE-TYPE TIRES Apply clean lubricant to all portions of the tire bead area and the exposed portion of the flap using sufficient but sparing quantities of lubricant. Also lubricate the entire rim surface. Avoid using excessive amounts of lubricant which can become trapped between the tire and tube can, resulting in tube damage and rapid air loss.

**CAUTION**: It is important that tire lubricant be clean and free of dirt, sand, metal shavings or other hard particles. The particles may lodge between the tube and the flap edges, resulting in splits in the tube. The following practice is recommended:

- Use a fresh supply of tire lubricant each day, drawing from a clean supply and placing the lubricant in a clean portable container.
- b. Provide a cover for the portable container and/or other means to prevent contamination of the lubricant when not in use.

We suggest the following method, which has proven to be successful in minimizing contamination and preventing excess lubricant from entering the tire casing: Provide a special cover for the portable container that has a funnel-like device attached. The small opening of the funnel should be sized so that when a swab is inserted through the opening into the reserve of lubricant and then withdrawn, the swab is compressed, removing excess lubricant. This allows the cover to be left in place, providing added protection. A mesh false bottom in the container is a further safeguard against contaminants. The tire should be mounted, and inflated promptly before lubricant dries.

#### 3. PREPARATION OF WHEELS, RIMS AND TIRES:

Never weld or apply heat to a rim or wheel on which a tire is mounted.

- a. Always wear safety goggles or face shields when buffing or grinding rims or wheels.
- b. Inspect wheel/rim assemblies for cracks, distortion, deforming of flanges, side rings, lock rings, etc. Using a file and/or emery cloth, smooth all burrs, welds, dents, etc. that are present on the tire side of the rim. Inspect the condition of bolt holes on the wheels.
- c. Remove rust with a wire brush and apply rust inhibiting paint.
- d. Remove any accumulation of rubber or grease which might be stuck to the tire, being careful not to damage it. Wipe the beads down with a dry rag.
- e. Make sure there is no water, dirt or foreign material inside the tire before inserting the tube.

## Medium Truck Range of Sizes & Load Range

		CT700CE	670.4065		CT710CE						67707								
	SIZE	ST788SE ST778+ SE	ST938	ST710SE	ST709SE ST709SE	ST909	ST908	ST718	ST918	ST719	ST717	ST528	ST518	ST508	ST520	ST720	ST770	ST900	ST901
8	25R15										G								
10.	.00R15										G								
9	R17.5										G								
10	DR17.5										Н								
11	1R17.5										G								
215/	/75R17.5									Н									
235/	/75R17.5									J									
245/	/70R17.5									J									
8	R19.5							F											
225/	/70R19.5					G			F/G	F/G									
245/	/70R19.5					Н			G	G/H									
265/	/70R19.5									Н									
8.:	25R20										G								
9.0	00R20										F								
10.	.00R20						Н				Н		Н					H*	
11.	.00R20										Н		Н						
12.	.00R20										J			J					
13/	/80R20										J								
14/	/80R20										J								
11.	.00R22													Н					
9	R22.5										G								
10	R22.5					G					G								
11	IR22.5	H/H	H/H	G	H/H	Н	Н				Н	Н						H*	Н
12	2R22.5					Н					Н		Н					H*	
315/	/80R22.5						J			L		L							
295/	75R22.5	H/G	G/G	G	H/G	Н	G												
245/	75R22.5									G									
255/	70R22.5					Н	Н			Н									
275/	70R22.5									J									
385/	65R22.5														J	J	J		
425/	/65R22.5														L	L			
445/	65R22.5														L	L			
11.	.00R24													Н					
11	IR24.5	H/H	H/H	G	H/H	Н					Н	Н						H*	Н
285/	75R24.5	H/G	G/G	G	H/G	G													

<sup>\*</sup> Speed Restricted to 55 mph.