

ALL PARTS ARE TO BE INSTALLED BY A CERTIFIED ASE TECHNICIAN



**2007-2009 Mercedes-Benz GL320**  
**2010-2012 Mercedes-Benz GL350**  
**2007-2012 Mercedes-Benz GL450**  
**2008-2012 Mercedes-Benz GL550**  
**2010-2011 Mercedes-Benz GLK350**  
**2007-2009 Mercedes-Benz ML 320**  
**2005-2011 Mercedes-Benz 350**  
**2010-2011 Mercedes-Benz ML 450**  
**2005-2009 Mercedes-Benz ML 500**  
**2008-2011 Mercedes-Benz ML 550**  
**2007-2011 Mercedes-Benz ML63 AMG**



Airmatic Suspension Air Springs Rear

## **129M-15-R**


### **Installation Guide**

BEFORE YOU BEGIN THE REMOVAL OR INSTALLATION, PLEASE READ ALL OF THE INSTRUCTIONS THOROUGHLY!


THE WARRANTY WILL BE VOID IF INSTRUCTIONS ARE NOT FOLLOWED EXACTLY. DO NOT WORK UNDER A VEHICLE SUPPORTED BY A JACK.

ALWAYS SUPPORT THE VEHICLE ON SAFETY STANDS.


## 1. Raise vehicle on lifting platform.



## 2. Remove cover (#5) and unscrew four plastic nuts (Arrows B).




## 3. Unscrew threaded connections of air suspension pressure line (#6) from the air spring (#3).



## 4. Carefully pull the air spring (#3) downwards at its upper plastic frame (Arrows C) until the air spring (#3) detaches from retaining clip.






- 5. Carefully push the air spring (#3) together (Arrow D), in the process press the air spring centering (#4) out of the spring control arm (#7) from below.**



- 6. Remove air spring (#3) downwards at an angle (Arrow E).**



- 7. Install new retaining spreader clip (#6) on frame floor.**
- 8. Install rear air spring in reverse order.**