



FAQ

What will I still need that is not included in this kit?

The 15000 is the “Core” kit that requires one or more of the optional adapter kits (Which are not included). You also need a 10,000 PSI pump to run the hydraulic ram (Ram is included in the kit). You can either purchase one of our pumps or use your own.

Check out the collection of pullers and installers we offer.