

## Application Instructions:

**1** Minimum environmental temperature 65 degrees. Use Acetone to fully remove all oil and dust. Repeat this process as many as 10 times or more until dirt and oils are no longer picked up.

**2** Gently clean back of decal(s) with acetone.

**3** Moderately apply Flexement Adhesive to the backside of each decal. Excess Flexement will cause oozing and shortage of glue.

Note: Applying three to four letters at a time is recommended to ensure adequate time and pressure can be applied in Step 4.

**3A** Use nozzle tip to spread adhesive evenly on all areas of the decal.

**4** Use fingertips to apply firm pressure from the center of each letter/shape outward for 30-40 seconds.

Repeat steps 3-4 for all decals.

**5** Once fully applied, allow decal to rest for 10 minutes. Carefully remove transfer film. **Use flexement to seal edges of each letter.**

**6** Once all the edges are sealed, allow decals to sit for a minimum of 1 hour before driving or washing.



## Cleaning:

We do not recommend the use of tire shine products. If Tire Stickers are exposed to tire shine, immediately clean tire shine from surface. Decals can be cleaned using **Tire Stickers Cleaning Solution**.

## Repair:

If decals begin to show signs of peeling due to application problems, difficult sidewall surfaces or damage from abrasion, repeat application steps #3-4.

## Removal:

1. For each decal, peel up an edge and clamp with pliers.
2. Once removed, clean up the remaining adhesive with acetone and a light sanding pad (220 grit).

