



RED	TO COIL POSITIVE ⊕ 12 VOLTS
ORANGE/YELLOW/BROWN	TO COIL NEGATIVE ⊖
BLACK	TO ENGINE GROUND

**WARNING:** This distributor is not compatible with stock points distributor coil, must use high output coil. Must bypass ballast resistor if applicable.