







WARNING: This distributor is not compatible with stock points distributor coil, must use high output coil. Must bypass ballast resistor if applicable.

READY TO RUN DISTRIBUTOR INSTALLATION

