

Deluxe Ergo Comfort Rest[™]



User's Manual

We are constantly improving our products so specifications are subject to change without notice.

DIAGRAM



Thank you for purchasing the Deluxe Ergo Comfort Rest[™] by HealthMate Products[™]. With normal care and proper treatment, it will provide years of reliable service. Please read all operating instructions carefully before use.

IMPORTANT-READ ALL DIRECTIONS BEFORE USING

- This appliance is designed for personal, non-professional use only.
- DO NOT use this product as a substitute for medical attention.
- Failure to unplug the unit while the vehicle is off may deplete your vehicle's battery.

▲ NOT SUITABLE FOR PERSONS WITH THE FOLLOWING CONDITIONS

- DO NOT use on an infant.
- DO NOT use on a disabled, sleeping, or unconscious person.
- This product should NEVER be used by any individual suffering from any physical
 ailment that would limit the user's capacity to operate the controls or who has sensory
 deficiencies in the lower half of their body.
- **DO NOT** use on insensitive skin or on a person with poor blood circulation.
- **NEVER** use this product directly on swollen or inflamed areas or skin lesions.
- Individuals with pacemakers should consult a doctor before use.
- If you have any concerns regarding your health, consult your doctor before using this product.

OPERATION

WARNINGS

- Close supervision is necessary when this appliance is used by, on, or near children or disabled persons.
- NEVER use while sleeping or fall asleep while using the product.
- **DO NOT** operate under a blanket or pillow. Excessive heating can occur and cause fire, electrocution, or injury to persons.
- If excessive heating should occur, discontinue use and allow the unit to cool before operating. Extensive use could lead to the product's excessive heating and shorten the product's life.
- **DO NOT** use this product for more than 20 minutes at a time.
- **NEVER** use pins or other metallic fasteners with this appliance.
- The unit should NEVER be left unattended when plugged in. Unplug the power cord from the electrical outlet or vehicle cigarette lighter socket immediately after using.
- Keep dry-DO NOT operate in a wet, moist environment, or around water.
- DO NOT reach for an appliance that has fallen into water. Unplug it immediately.

- DO NOT operate where aerosol (spray) products are being used or where oxygen is being administered.
- Use this appliance only for its intended use as described in this manual.

NOTE: This cushion has been built with an internal pressure-sensitive safety switch. After plugging the DC cord into a power source, you will need to sit on the cushion in order to activate the heating elements.

Massage Speeds	
High	
Off	0
Low	

Heat/Massage Selection Modes	
Heat	<u>}</u>
Heat & Massage	-777 1
Massage	J



CARE & MAINTENANCE

- 1. Always unplug the unit before cleaning and allow it to cool.
- 2. Wipe with a soft cloth. DO NOT use abrasive cleaners, solvents, or harsh detergents. Never submerge the unit in any liquid.
- 3. Place massager in a safe, dry, and cool place. Avoid contact with sharp edges or pointed objects which might cut or puncture the surface.

WARNINGS

- DO NOT insert or probe with any object into any opening.
- **NEVER** operate this appliance if it has a damaged cord or plug.
- To avoid damaging internal components, DO NOT wrap the power cord around the unit or place heavy objects on any part of the unit that my crush its mechanisms.
- Keep cord away from heated surfaces.

