

INSTALLATION INSTRUCTIONS MODEL 803-LV

- 1. Using the screws provided mount the lanyard valve in a convenient location so that the chain can easily be reached.
- Connect the 1/4" air hoses to the lanyard valve as shown in Fig. 1. NOTE: To avoid air leaks do not over tighten the air hose compression fittings.

