



INSTALLATION INSTRUCTIONS

MODEL 001, 002 & 003 – MUSIC TIME®

Properly installed “Music Time” will provide years of high quality sound. Give your installation the same care and attention that went into making this fine product. Once installed Music Time requires no maintenance.

MOUNTING THE MUSICAL SPEAKER

Carefully select a position in the engine compartment that will keep the speaker and the electronics dry. Equally as important, protect the plastic speaker housing by not allowing it to come in contact with hot engine parts.

With the mounting position located, use the musical speaker as a template, and mark the location of the four mounting holes. Drill 4 holes using a 7/32-drill bit. Remove the mounting bracket from the speaker and fasten the bracket to the vehicle using the hardware provided. Secure the speaker to the mounting bracket, tilting speaker housing slightly downward to prevent water from collecting in speaker cone.

WIRING

Music Time will be ready to work after making only two electrical connections. Connect the fuse wire to any electrical circuit that is powered when the ignition is “on”. Secure the wire with the ring terminal under a speaker-mounting bolt or to any convenient body bolt.

CONTROLLER

Four buttons on the key chain transmitter provides Music Time with full control of all sound functions. Button functions: The “Large” button turns the system on and off. “Red and Blue” buttons select songs, and volume button adjusts the sound level.