



### Notes

1. Relay may be keyed to vehicle connector. Check part photo for connector view.

### Symbol Key



= Coil Winding



= Voltage Suppressing Resistor



= Diode/Voltage Suppression-  
Arrow Points To B+