



Notes

1. Relay may be keyed to vehicle connector. Check part photo for connector view.

Symbol Key



= Coil Winding



= Voltage Suppressing Resistor



= Diode/Voltage Suppression-
Arrow Points To B+