

Input	Max Power	Bulb
Voltage	Output	Warranty
9-32V DC	24 watt	1 year

Additional Disclaimer Terms

Please check your local and state laws for the proper use of this product.

- Improper installation of electrical products such as lighting may cause damage to any vehicle or device to which the improperly handled or installed lighting is attached.
- Improperly installed product may cause electrical injury to persons.
- It is recommended that the kit should be installed by a licensed professional.
- XKGLOW assumes no liability for the installation of the product.
- Warranty or liability will not exceed the product purchase price, which shall be buyer's sole and exclusive remedy.

Mounting Instructions

Our Ignite Series LED Bulbs have been precisely designed to be a direct replacement for their halogen counterparts utilizing the same plugs and sockets to meet industry standards. Installation is just as replacing a halogen bulb and should not require any modification to the plugs or sockets in *most* applications.

- 1. **Unplug and remove halogen bulb:** Carefully unplug and remove the halogen bulb from the housing. In some applications, it may be required to remove a plastic dust cover to gain access to the headlight bulb.
- 2. Install LED bulb: Replace the halogen bulb with new LED bulb. In some applications where retaining clips are used, it may be easiest to remove the collar from the bulb and install separately. Simply twist the collar on the bulb counter-clockwise and remove the collar. After the collar is installed, reinsert the bulb into the collar and twist clockwise to lock into place. Plug in bulb.
- 3. If applicable, reinstall plastic dust cover or rubber grommets that were removed during install.