Installation Instructions

T-Connector

Acura RDX

A

B

C

DRAW·TITE®

TOOLS REQUIRED:

10mm Socket & Ratchet or 10mm Wrench, Drill (3/32" Drill Bit), 1/4" Socket, Test-probe

1. Open the vehicle's rear tailgate. Locate the grey tow plug by opening the access panel inside of the storage compartment **Ⓐ** **Ⓑ**.

2. Insert the T-Connector harness into the vehicle's Tow-Plug harness and lock into place.

⚠ **WARNING**
All connector surfaces should be clean and free of dirt. Be careful not to damage the locking tabs and be sure that connectors are fully inserted with locking tabs in place.

3. Locate a suitable grounding point. Drill a 3/32" hole and secure the **white** wire using the eyelet and screw provided. Do not drill into any exposed surfaces.

4. Mount the T-Connector black box using double-sided tape provided.

⚠ **WARNING**
The black box-module is intended to be mounted ONLY in the INTERIOR of the vehicle. Mounting on the exterior or areas exposed to the elements or moisture could cause serious damage to the vehicle and module.

5. Open vehicle hood, and locate the fuse box on the driver side near the front of the vehicle. Unlatch the fuse door to access the fuse area. Locate position labeled (20A) Trailer. Insert the 20 amp fuse included with the T-Connector package in this position and latch the fuse box **Ⓒ**.

⚠ **WARNING**
All connections must be complete for the T-Connector to function properly. Test and verify installation with a test light or trailer once installed. For initial test, reset vehicle electrical system by temporarily removing the key from the ignition.

6. Store 4-Flat connector in rear cargo area when not in use.

🔥 ⚠ **WARNING**
Overloading circuit can cause fires. DO NOT exceed lower of towing manufacturer rating or:
• Max. stop/turn light: 2 per side (4.2 amps)
• Max. tail lights: (7.5 amps)
Read vehicle's owners manual & instruction sheet for additional information.

Check out the collection of trailer hitches and towing we offer.