CLASSIC™ ACCESSORIES

The Togiak

Float Tube

O W N E R ' S M A N U A L



IMPORTANT SAFETY INFORMATION

⚠ WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

Never exceed the maximum capacity of 300 lbs for yourself and gear.
- You MUST wear an approved personal flotation device (PFD).
- This is not a life saving device.
- This product is not a toy and is not to be used by children under the age of 16 years of age or by any child without adult supervision. Check the laws in your state.
- Use only in still and calm water. Never use in high wind or water with currents.

SAFE FLOATING
- Never float alone.
- Never use this float tube in bad weather.
- Keep sharp objects (knives, fish hooks, etc.) away from the pontoons.
- Do not use under the influence of drugs or alcohol.
- Do not tow this float tube with a person in it.
- Seek shelter from water if there is threat of lightning.
- Your float tube includes a safety flag holder in the back (flag not included). Some states require use of a safety flag.

INFLATION
- Do not use CO_2 or a high pressure air compressor to inflate.
- Follow the inflation instructions listed in this manual.
- Check for leaks before using.
- Remember that air pressure changes with temperature and elevation so always check your inflation level before use.

This manual lists certain recommended practices and provides some basic precautions. However, this list of precautions is not all-inclusive. Users must follow all applicable laws, rules, and regulations and should exercise appropriate caution in the safe operation of this float tube.
REMEMBER - always exercise common sense when using your float tube.

Materials list:

- 1 float tube cover with 2 flotation bladders
- 1 mesh stripping apron with spreader bar sleeve
- 3-piece spreader bar
- 1 bladder repair kit (contains: repair instructions and two PVC patches)
- 1 pair of shoulder straps
- 2 foam seat pieces

How to inflate your float tube bladders

Float tube bladders are designed to be inflated by foot or hand pump.

To inflate:

Turn the valve cap on the valve stem counter-clockwise to open the air way. After inflation close the valve by turning the cap clockwise (Fig. 1).

To Deflate:

DO NOT REMOVE CAP – Turn the valve cap on the valve stem counter-clockwise to open the air way from the bladder.



Fig. 1

Inflating and assembling your float tube

1. Place your float tube flat on the floor with the pockets facing up. Loosen the two compression straps on the outside edge of both pontoons.
2. Insert the two foam inserts (A) into the seat bottom compartment (Fig. 2). (It will be a tight fit.)
3. Pull the flap down over the foam inserts and secure the three rip-and-grip strips under the seat cushion.



Fig. 2

4. Access your valve stem to your pontoon bladders through the inside zipper pocket. If valve stems are not accessible inside the pocket see step 6-7.
5. Inflate the two pontoon bladders about 30%—just enough to hold their shape.
6. Check the bladders by unzipping the pontoons (Fig. 3). The bladders should lie flat, untwisted and centered inside the pontoon Shell.



Fig. 3

7. Make sure the valve stem that attaches to the bladder fits into the access pocket of the pontoon cover (Fig. 4). Zip closed the pontoons. (A twisted bladder will distort the cover when you blow it up.)



Fig. 4

8. Inflate the flotation bladders until most of the wrinkles are out of the cover. If any twists develop stop, deflate the bladder, straighten it within its pocket and re-inflate. Close the valve caps tightly.
9. Connect the three spreader bar pieces by inserting the two long tubes into the shorter coupling tube with the angled ends on both long tube ends facing out. Now place the mesh stripping apron on the floor with the graphics facing up. Slip the spreader bar with the angled ends facing down into the fabric sleeve at one end of the apron. Slip the ends of the apron sleeve into the fabric receptacles on the top left and right pontoons. Secure the quick release buckles.
10. Pull tight the two cinch-tight buckles on the outside edge of each pontoon.
11. There are two backrest support straps sewn to the seat backrest with a side release buckle on either end. Be sure these buckles are clipped to their corresponding parts on the inside pontoon. Adjust the length of the strap for a comfortable seat back angle.
12. Pull tight the single seat back strap, to keep the seat open while in use. Loosen the strap to fold the seat closed.



Lifting the tube in and out of the water

There are two web handles next to the pontoon pockets that can lift the tube in and out of the water easily.

Launching and using your float tube

1. Start with a gentle slope (like a boat ramp).
2. Attach fins to your feet, then place your float tube in knee-high water. Step into your tube from the open side and turn so that your back is facing the backrest.
3. Now just sit down in your float tube, fasten the stripping apron and begin to float. Practice kicking with your fins to go backward or to turn.

Carrying your float tube

Included with your float tube is a pair of backpacking shoulder straps. Attach a shoulder strap to one D-ring located under the seat of your pontoon boat Repeat with the other strap on the opposite D-ring located under the seat.

Care and storage of your float tube

Always partially deflate the bladders before storing your assembled float tube in a vehicle or hot area. The air in the bladders can expand significantly.

If you are not going to use your float tube for an extended period deflate it and store it. To avoid mildew, be sure that your float tube is dry before you pack it and that you store it in a dry place.

CLASSIC® ACCESSORIES

Classic Accessories, Inc.