SPYDER
WWW.SPYDERAUTO.COM

INSTALLATION GUIDE:

ALT-YD-FF15004-LED-(All)

Tools Needed:

- ¼” ratchet
- 10mm socket

1. Remove (2x) 10mm bolts.

2. Unseat tail light.



3. Remove brake light socket and reverse light socket. (Never touch bulb with bare hands)



4. Install brake light socket insert into brake light socket. (Make sure to align black wire of insert to black wire of socket)



5. Install brake light socket and reverse light socket onto Spyder tail light.

6. Seat Spyder tail light.

7. Reinstall (2x) 10mm bolts.

8. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder LED tail lights.

SPYDER
WWW.SPYDERAUTO.COM

For further help with installation, please watch our installation video. Follow the direct link below to our YouTube channel for more information:
http://www.youtube.com/watch

DISCLAIMER

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.