

PART NO.

- 738300T
- 731323T
- 731423T
- 731500T

PRODUCT DESCRIPTION:

LF WINDSHIELD LIGHT FRAME

PRODUCT SAFETY & LEGAL DISCLAIMER

- IMPORTANT READ ALL INSTRUCTIONS CAREFULLY BEFORE INSTALLING, FAILURE TO DO SO MAY CAUSE PERSONAL INJURY OR DAMAGE TO PRODUCT AND/OR PROPERTY.
- **Review the product package and contents prior to beginning the installation.** Take care when opening the packaging and removing items. If a return is needed you will want to return the product in its original packaging if possible.
- This instruction guide is provided as a GENERAL installation guide, some vehicles vary dimensionally and may require additional steps.
- Test fit the product on the vehicle prior to any third party modifications and or finishing. The
 manufacturer and/or distributors do not accept responsibility for third party charges, labor and or
 third part replacement modifications. Some modifications may void the factory warranty.
- Exercise due-diligence when installing this product. The manufacturer and distributors of this product do not accept any responsibility for vehicle damage or personal injury resulting from the installation of this product. Careless installation and operation can result in serious injury or equipment damage.
- This product is for general off-road use. All liability for installation and use rests with the owner/operator.
- INSTALLER: Once installation is complete, please return this guide along with other documentation included in this product back to the consumer for future reference. The manufacturer/distributors of this product do not guarantee this particular version will be available at a later date.



INJURY HAZARD

Please complete a shop and tool inspection prior to beginning the installation.

- Always make sure you have a clean, dry and well lit work area.
- Always remove jewelry, loose fitting clothing and wear protective gloves and eye protection.
- Always use extreme caution when jacking or raising a vehicle for work. Set the emergency brake and use tire/wheel blocks and jack stands. Refer to the vehicle manufacturer hand book. Utilize the vehicle manufacturers designated lifting points.
- Always use appropriate and adequate care in lifting parts during disassembly and installation. Seek help in lifting heavy or large items into place. Utilize jacks and or lifting devices when available.
- Always insure products are secure during disassembly and installation.
- Always wear eye protection and take steps to protect any exposed skin during the installations. Drilling, cutting and grinding plastic and metal may create flying particles that can cause injury.
- Always use extreme caution when drilling, cutting and or grinding on a vehicle. Thoroughly
 inspect the area to be drilled, on both sides of material, prior to modification and relocate any
 objects that may become damaged.
- Always assemble and tighten all fasteners per the installation instructions.
- Always route electrical cables carefully. Avoid moving parts, parts that may become hot and rough or sharp edges.
- Always insulate and protect all exposed wiring and electrical connections.

MAINTENANCE AND CARE

- Always perform regular inspections and maintenance on mounts and related fasteners.
- Periodically check and tighten all fasteners.
- Stripped, fractured, or bent fasteners must be replaced.
- After washing the vehicle make sure to fully dry all surfaces.
- In areas with cold temperatures make sure to wash the product often to remove harmful materials used on road ways.
- Never use abrasive cleaners or polish compounds. Clean with a gentle soap and water. If you use wax use a non-abrasive automotive wax such as pure carnauba wax.


WARNING


Some products have been designed to work together with factory rear sensor systems, factory forward facing sensor systems and factory air bags.

- Installation of some of these products may alter the factory sensor system performance.
- Factory sensors may read shackles or hooks protruding from the fairlead and or tow hooks.
- All sensor testing is completed by Go Rhino Products and or third party testing labs on modified vehicles
- Sensor sensitivity, factory sensor housing, orientation, and operating conditions are all variables that will influence functionality of the sensors.
- Installation of some product may effect the factory air bag systems.
- Some products allow the use of third party products such as winches, shackles, hooks, etc. Follow the respective manufacturers operating instructions for use with our products.
- Make sure to fully understand the product, it's intended use and operation prior to use.
- Above all... be safe!



PARTS INCLUDED IN THIS LIST:





738300T LIGHT FRAME 8 DUALYS			L	731323T LIGHT FRAME 30" E2 & 4 DUALLYS			
ITEM	QUANTITY	DESCRIPTION	ITEM	QUANTITY	DESCRIPTION		
1	12	MB × 45MM LONG BUTTON HEAD SCREW	1	12	MB × 45MM LONG BUTTON HEAD SCREW		
2	6	1/4"-20×3/4" LONG CARRIAGE BOLT	2	6	1/4"-20 x 3/4" LONG CARRIAGE BOLT		
3	6	1/4"-20×3/4" BUTTON HEAD SCREW	3	6	1/4"-20 x 3/4" BUTTON HEAD SCREW		
4	12	5/16" FLAT WASHER	4	12	5/16" FLAT WASHER		
5	12	5/16" PLASTIC WASHER	5	12	5/16" PLASTIC WASHER		
6	6	1/4" PLASTIC WASHER - LARGE	6	6	1/4" PLASTIC WASHER - LARGE		
7	12	1/4" FLAT WASHER	7	12	1/4" FLAT WASHER		
8	12	1/4" PLASTIC WASHER - SMALL	8	12	1/4" PLASTIC WASHER - SMALL		
9	12	1/4" SPLIT LOCK WASHER	9	12	1/4" SPLIT LOCK WASHER		
10	6	1/4"-20 HEX NUT	10	6	1/4"-20 HEX NUT		
11	6	1/4"-20 A CORN CAP NUT	11	6	1/4"-20 ACORN CAP NUT		
12	2	1/4" THICK RUBBER SPACER	12	2	1/4" THICK RUBBER SPACER		
13	4	1/8" THICK RUBBER SPACER	13	4	1/8" THICK RUBBER SPACER		
14	6	3/16" THICK RUBBER SPACER	14	6	3/16" THICK RUBBER SPACER		
15	4	HOLE PLUG	15	4	HOLE PLUG		
16	1	LIGHT PLATE - 8 DUALLYS	16	1	LIGHT PLATE - 30" E2 & 4 DUALLYS		
17	1	PASSENGER SIDES LIGHT FRAME	17	1	PASSENGER SIDES LIGHT FRAME		
18	_	DRIVER SIDE LIGHT FAME	18	1	DRIVER SIDE LIGHT FAME		
19	3	PASSENGER SIDE LIGHT BRACKET	19	3	PASSENGER SIDE LIGHT BRACKET		
20	3	DRIVER SIDE LIGHT BRACKET	20	3	DRIVER SIDE LIGHT BRACKET		
21	2	LOGO PLATE	21	2	LOGO PLATE		
22		DOUBLE SIDED TAPE	22	4	DOUBLE SIDED TAPE		
23	1	DUALLY MOUNTING HARD WARE KIT	23	1	DUALLY MOUNTING HARDWARE KIT		

		731423T		п	731500T GHT FRAME 50" E2
ITEM	QUANTITY	DESCRIPTION			I
1	12	MB × 45MM LONG BUTTON HEAD SCREW	ITEM	QUANTITY	DESCRIPTION
2	6	1/4"-20 × 3/4" LONG CARRIAGE BOLT	1	12	MB × 45MM LONG BUTTON HEAD SCREW
3	6	1/4"-20×3/4" BUTTON HEAD SCREW	2	6	1/4"-20 x 3/4" LONG CARRIAGE BOLT
4	12	5/16" FLAT WASHER	3	6	1/4"-20 x 3/4" BUTTON HEAD SCREW
5	12	5/16" PLASTIC WASHER	4	12	5/16" FLAT WASHER
6	6	1/4" PLASTIC WASHER - LARGE	5	12	5/16" PLASTIC WASHER
7	12	1/4" FLAT WASHER	6	6	1/4" PLASTIC WASHER - LARGE
8	12	1/4" PLASTIC WASHER - SMALL	7	12	1/4" FLAT WASHER
9	12	1/4" SPLIT LOCK WASHER	8	12	1/4" PLASTIC WASHER - SMALL
10	6	1/4"-20 HEX NUT	9	12	1/4" SPLIT LOCK WASHER
11	6	1/4"-20 A CORN CAP NUT	10	6	1/4"-20 HEX NUT
12	2	1/4" THICK RUBBER SPACER	11	6	1/4"-20 ACORN CAP NUT
13	4	1/8" THICK RUBBER SPACER	12	2	1/4" THICK RUBBER SPACER
14	6	3/16" THICK RUBBER SPACER	13	4	1/8" THICK RUBBER SPACER
15	4	HOLE PLUG	14	6	3/16" THICK RUBBER SPAICER
16	1	LIGHT PLATE - 40" E2 & 2 DUALLYS	15	4	HOLE PLUG
17	1	PASSENGER SIDES LIGHT FRAME	16	1	LIGHT PLATE - 50" E2
18	1	DRIVER SIDE LIGHT FAME	17	1	PASSENGER SIDES LIGHT FRAME
19	3	PASSENGER SIDE LIGHT BRACKET	18	1	DRIVER SIDE LIGHT FAME
20	3	DRIVER SIDE LIGHT BRACKET	19	3	PASSENGER SIDE LIGHT BRACKET
21	2	LOGO PLATE	20	3	DRIVER SIDE LIGHT BRACKET
22	4	DOUBLE SIDED TAPE	21	2	LOGO PLATE
23	1	DUALLY MOUNTING HARD WARE KIT	22	4	DOUBLE SIDED TAPE

Go Rhino recommends you, the installer, read this installation instruction manual from front to back before installing the product.


TOOLS NEEDED FOR INSTALLATION:

• 4mm Hex Driver • 5mm Hex Driver • 5/32" Hex Driver • T40 Torx Driver • 7/16" Drive Socket or Wrench

ESTIMATED TIME FOR INSTALLATION:

1 Hour






- Use of side light bracket, items 19 and 20 is optional, additional lights may be mounted to side light brackets.
- Install side light brackets and plastic hole plugs as shown, driver and passenger side.

Driver side shown

Tighten nuts to 70 in/lbs Max. DO NOT OVERTIGHTEN NUTS.


 Once light frame is installed onto vehicle, side light bracket mounting hardware will not be accessible.

GO RHINO &






STEP # 3









STEP # 5

