

BMW 3/4 2012-18 INSTALLATION INSTRUCTIONS

SHIFT BOOT

1. Gently pry on corners of shift boot there are multiple clips which pop loose.



2. After pulling up the boot you should be able to see the cable pictured.



3. Disconnect this it is the cable to supply power for the lights on the shift knob.



4. Now grab the shift knob and pull up. Be careful it is very tight and will come off suddenly. Don't be afraid to pull hard this takes a lot of force.



5. Cut off the old boot right under the shift knob (make sure you don't get the cables cut!) using a retractable blade or an x-acto knife.

Take the boot to a working area. Peel it off the plastic frame. Test-fit RedlineGoods boot around frame, and glue it in. Automotive GOOP, 3M Super 77 and other glues will work great - any epoxy glue will do in fact. Just make sure to take your time, check the curing instructions on the glue container and make sure to not get any glue on the outside of the boot.



Flip the RedlineGoods boot inside-out and slide the shift knob assembly into the collar of the RedlineGoods boot.



Use a zip-tie to secure the boot to the shift knob assembly (put the zip-tie head on the front of the vehicle so that it's not visible to driver or passenger).



6. Plug in cable from shift knob.

7. Tuck cable into appropriate area as shown in picture.

8. Now put shift knob on notched area and push down

9. Push clips on shift boot into the area for the shift boot.



EBRAKE BOOT

10. Pull up on bottom of handbrake boot clips should pop off .



11. Pull boot up around handle as shown in picture.



12. Pull firmly on handbrake handle until it comes off handbrake lever OR cut the zip-tie mounting the boot to the handle.

Take the boot a working table and transplant the bottom frame to the RedlineGoods but, just as described in #5 above for the shift boot.



13. Flip the boot inside-out, slide it on the ebrake handle. Secure with tip-zie.



14. Work the boot down until the frame is again at the bottom, by the center console.



15. Push clips into place around the ebrake boot.



ARMREST COVER

16. First use some sort of plastic pry tool like the one shown to separate the center console into two pieces as shown. Disconnect the lighter power and remove the console piece from vehicle.



17. Grab the spring with pliers as shown and pull up to get the spring in the position shown here.

18. With the spring out of the way push on the silver pins as seen in the picture.



19. With the spring out of the way push on the silver pins as seen in the picture.



20. Now pull the silver pins out with pliers.



21. Take the assembly to a working table. Glue the cover over the factory one (do not remove it!) Since the sliding assembly is not dis-assemblable, the cover will reach all the way to the plastic, but not be pushed underneath it. Since you rarely inspect the armrest from below, this shouldn't be much of an issue. :) For detailed instructions on how to glue the armrest cover on top, refer to this [write-up](#).

Make sure it's glued evenly and wrinkle-free.



22. Now place the gold spring in position as shown on both sides.



23. This additional picture will help you ensure it's located correctly.



24. Now push silver pins into their slots and open the armrest as shown to make setting the spring easier.



25. For this part use two hands to tuck the spring into the slot shown (this takes some force and a couple tries).



26. Reinstall the rear center console piece. Make sure to remember to connect the power to the lighter socket. :)



CONGRATULATIONS - YOU HAVE SUCCESSFULLY INSTALLED YOUR NEW LEATHER BOOTS!

Useful tip

You have installed a product made out of genuine leather. As you know, to maintain a leather product in good condition, you should take care of it. We suggest occasionally (every 4-6 week

for example) applying some leather conditioner/UV protector to keep your leather from drying up in the sun and cracking.

Redline Automotive Accessories Corp. will not be held liable for any labor, incidental or consequential damages of any kind. Proceed at your own risk.