

# INSTALLATION MANUAL

## SK-3562 Arnott New Rear Shock RAM 3500 (D2)



**Engineered to Ride, Built to Last<sup>®</sup>**

# CONGRATULATIONS ON YOUR PURCHASE OF AN ARNOTT® AIR SUSPENSION PRODUCT

WE AT ARNOTT LLC ARE PROUD TO OFFER A HIGH QUALITY PRODUCT WITH ALL THE TECHNICAL SUPPORT YOU NEED.  
THANK YOU FOR YOUR CONFIDENCE IN US AND OUR PRODUCT.

Proper installation is essential to experience and appreciate the benefits of this system. Please take a moment to review these installation instructions before you begin to install these components on your vehicle. The removal and installation of air suspension products should only be performed by a fully qualified and certified automotive professional.

It is equally important to be aware of all necessary safety measures while installing your new Air Suspension System. This includes proper lifting and immobilizing of the vehicle and isolation of any stored energy to prevent personal injury or property damage.

## GENERAL INFORMATION

Reading this manual signifies your agreement to the terms of the general release, waiver of liability, and hold harmless agreement, the full text of which is available at [www.arnottinc.com](http://www.arnottinc.com) and [www.arnotteurope.com](http://www.arnotteurope.com).



### WARNING:

The air suspension system is under pressure (up to 10 bar, or 150 lbf/in). Verify pressure has been relieved and disconnect power to the air suspension system prior to disassembly. Do not allow dirt or grease to enter the system. Always wear standard hand, ear, and eye protection when servicing the air suspension system.

- Not to be stored below 5°F (-15°C) and above 122°F (50°C).
- Avoid damage to air lines and cables.
- Removal and installation is only to be performed by fully qualified personnel.
- Use car manufacturer's diagnostic software.

### CAUTION:

Damage to the vehicle and air suspension system can be incurred if work is carried out in a manner other than specified in the instructions or in a different sequence.

To avoid the possibility of short circuits while working with electric components consult your owner's manual on how to disconnect your battery.

Consult your vehicle owner's manual, service manual, or car dealer for the correct jacking points on your vehicle and for additional care, safety and maintenance instructions. Under no circumstances should any work be completed underneath the vehicle if it is not adequately supported, as serious injuries and death can occur.

For vehicles that contain a "Closed Air Supply System", replacement of components requires proper adherence to procedures set forth within OE servicing literature. Failure to comply with the OE prescribed procedures can result in component damage and/or failure.

## REAR SHOCK REMOVAL

1. Raise the vehicle and remove the lower shock mount bolt and nut. (Figures 1, 2)




FIGURE 1



FIGURE 2

2. Remove the upper shock mount nut and remove the shock from the mounting stud. (Figures 3, 4)



FIGURE 3



FIGURE 4

3. Remove the shock from the vehicle. (Figure 5)




FIGURE 5

4. Removal complete.

## REAR SHOCK INSTALLATION



Tighten all nuts and bolts to manufacturer's specifications during the installation process.

1. Install the Arnott shock on the vehicle. (Figure 6)



FIGURE 6

2. Position the top of the shock on the mounting stud, install the top mounting nut and tighten to manufacturer's specifications. (Figures 7, 8, 9)




FIGURE 7



FIGURE 8




FIGURE 9

3. Install the lower shock mount bolt and nut. Tighten to manufacturer's specifications. (Figures 10, 11)



FIGURE 10



FIGURE 11

4. Installation complete.

# Arnott®

Air Suspension Products

## Arnott US Business Office:

[www.arnottinc.com](http://www.arnottinc.com)

100 Sea Ray Drive  
Merritt Island, FL 32953

**Call:** 800.251.8993  
321.868.3016

**Fax:** 321.868.3703

**Email:** [techassistance@arnottinc.com](mailto:techassistance@arnottinc.com)

## Arnott Europe Business Office:

[www.arnotteurope.com](http://www.arnotteurope.com)

Docterskampstraat 1E/1F, 3  
5222 AM 's-Hertogenbosch (NL)

**NL Phone:** +31 73 7850 580

**DE Phone:** +31 85 2087 438

**UK Phone:** +44 203 3186 124

**BE Phone:** +32 258 846 90


**ES Phone:** +34 91 901 10 56

**FR Phone:** +33 18 626 72 41


**Email:** [info@arnotteurope.com](mailto:info@arnotteurope.com)




**Air Springs**




**Struts**




**Shocks**




**Compressors**




**Dryers**



**Coil Spring  
Conversion Kits**



**Valve Blocks**



**Ride Height  
Sensors**