



KUKKO
Tool factory

since 1919!



Specialized in extractors

Puller guide –

how to choose the right tool





Dear Sir/Madam,

our sector offers with its products an ever-increasing number of tools for carrying out repairs and working in the various sectors of industry, trade and automotive operations.

It is the aim of any trader to guarantee that their customers receive high quality and quick advice at any time. The challenge is to deepen the specialist knowledge needed for sales.

We are happy to help you with this with the new puller basics for the KUKKO brand!

If your customers need a puller, you will usually be faced with the following questions:

- **What principles actually exist for the puller?**
- **Which puller is right for my problem?**
- **How does it work and what do I have to watch out for during use?**
- **Which jaws and spindles are available as an alternative for my KUKKO puller?**

In future, you will be able to answer these questions quickly and easily with the new puller basics. Kukki will reliably guide you through the 4 principles of the puller and provide you with information using product videos, photos, videos and tables.

Thank you for your interest in KUKKO products and enjoy reading and discovering.



Your KUKKO Team!

<p>The 4 puller principles at a glance page 4 - 5</p> <p>Overview: of all series page 6 - 7</p> <p>General overview of the KUKKO line KUKKO-Technologies page 40 - 41</p> <p>Precautionary Notes and Helpful Hints page 42</p> <p>page 43</p>	GENERAL
<p>EXTERNAL-pulling page 8 - 23</p> <p>Selection of the right external puller page 8 - 9</p> <p>Special features of series 20 and 30 page 10 - 11</p> <p>Overview: Puller Jaws page 12 - 17</p> <p>Overview : Spindles page 18 - 23</p>	EXTERNAL
<p>INTERNAL-pulling page 24 - 27</p> <p>Selection of the right internal puller device page 24</p> <p>Special features of series 21 and 22 page 25</p> <p>Overview: Internal pulling with counter stay page 26 - 27</p> <p>Overview: Internal pulling with slide hammer page 26 - 27</p>	INTERNAL
<p>SEPARATING page 28 - 29</p> <p>Selection of the right separating device page 28</p> <p>Special features of series 15, 17 and 18 page 29</p>	SEPARATING
<p>BALL BEARING removal and installation page 30 - 31</p> <p>Selection of the right bearing puller page 30</p> <p>Overview: Ball bearing removal and installation page 31</p>	BALL BEARING
<p>Series 800 page 32 - 35</p> <p>Selection of the right puller page 24</p> <p>Possible combinations of the modular system 800 page 25</p>	SERIES 800
<p>BALL JOINT extracting Seite 36 - 37</p> <p>Selection of the right ball joint extractors Seite 36</p> <p>Overview: ball joint extractors Seite 37</p>	BALL JOINT

EXTERNAL



The part to be removed is on a shaft and is freely accessible from the outside!







For more informations see pages: 6-7; 8-23

INTERNAL



The part to be removed is in a recess!






For more informations see pages: 6-7; 24-27

SEPARATING



The part to be removed is level. It is not possible to use standard puller jaws!





For more informations see pages: 6-7; 28-29

BALL BEARING





Non-contact extraction!

A The ball bearing is in a housing and on a shaft at the same time.



B The ball bearing is inside a casing, but has no shaft for support.



Non-contact extraction!

For more informations see pages: 6-7; 30-31



GENERAL


series									mini bearings micro mechanical work	small bearing precision mechanical work	medium bearings mechanical work	large bearings heavy mechanical work	ball bearings	ALL bearing types	EXTERNAL 	INTERNAL		SEPARATING	BALL BEARING removal	
	mm	mm	mm	mm	mm	mm	mm	mm								mm	mm	mm	mm	mm
20-AV / 11	375-650	200-700	✓	✓	✓	✓	✓	-	-	-	-	✓	✓	✓	✓	-	✓	-	-	-
12	100-650	100-350	-	✓	✓	-	✓	-	-	-	✓	✓	✓	✓	✓	-	-	-	-	-
13	130-280	250	-	✓	✓	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	✓	-	-
14	6-140	85-160	-	✓	-	✓	-	-	-	✓	-	-	✓	✓	✓	-	-	-	-	-
20 / 30	90-750	100-700	✓	✓	✓	✓	✓	-	-	-	✓	✓	✓	✓	✓	-	✓	-	-	-
28	50-250	100-250	-	✓	-	✓	-	-	-	✓	✓	-	✓	✓	✓	-	-	-	-	-
41 / 42	60-180	40-200	-	✓	✓	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	-	-	-
43	60-80	50-80	-	✓	-	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	-	-	-
44 / 45	100-600	100-350	-	✓	-	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	-	-	-
46 / 47	300-500	300-450	-	✓	✓	✓	✓	✓	-	-	✓	-	✓	✓	✓	-	-	-	-	-
48	60	40	-	✓	-	✓	-	-	-	✓	-	-	✓	✓	✓	-	-	-	-	-
110	50-350	50-250	✓	✓	-	✓	-	-	-	✓	✓	-	✓	✓	✓	-	✓	-	-	-
112 / 113	55-185	45-165	-	✓	-	✓	✓	-	-	✓	✓	-	✓	✓	✓	-	-	-	-	-
120 / 130	100-350	100-200	✓	✓	-	✓	✓	-	-	-	✓	-	✓	✓	✓	-	✓	-	-	-
140 / Micro	2,25-5,25	10-20	-	✓	-	✓	-	-	✓	-	-	-	✓	✓	✓	-	-	-	-	-
200	250	80-180	✓	✓	-	✓	-	-	-	-	✓	-	✓	✓	✓	-	✓	-	-	-
201 / 202	100-380	75-300	-	✓	-	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	-	-	-
203	120-400	75-300	-	✓	-	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	-	-	-
204 / 210	50-150	70-325	-	✓	-	✓	-	-	-	✓	✓	-	✓	✓	✓	-	-	✓	-	-
205 / 207	100-550	100-540	-	✓	✓	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	-	-	-
206	100-500	100-540	-	✓	✓	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	-	-	-
208 / 209	20-230	95-190	-	✓	-	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	-	-	-
208-0 / 209-0	100	50-100	-	✓	-	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	-	-	-
482 / 483	15-250	40-250	-	✓	-	✓	✓	-	-	-	✓	-	✓	✓	✓	-	-	-	-	-
486	22-160	55-180	✓	✓	-	✓	✓	✓	-	-	✓	-	✓	✓	✓	-	✓	-	-	-
21	∅ 5-200	-	-	✓	-	-	-	-	-	✓	✓	-	✓	✓	-	✓	✓	-	-	-
22-0	-	-	-	✓	-	-	-	-	-	✓	✓	-	✓	✓	-	✓	✓	-	-	-
22	55-300	120-260	-	✓	-	✓	-	-	-	✓	✓	-	✓	✓	-	✓	-	-	-	-
16	∅ 60-155	-	-	✓	-	-	-	-	-	-	✓	-	✓	✓	-	✓	✓	-	-	-
15	∅ 6-250	-	-	✓	-	-	-	-	-	✓	✓	-	✓	✓	-	-	-	✓	-	-
17	∅ 8-155	-	-	✓	-	-	-	-	-	✓	✓	-	✓	✓	-	-	-	✓	-	-
18	25-440	60-400	-	✓	✓	✓	-	-	-	-	✓	-	✓	✓	-	-	-	✓	-	-
69	-	-	-	✓	-	✓	-	-	-	✓	✓	-	✓	-	-	-	-	-	✓	-
70	-	-	-	✓	-	-	-	-	-	✓	✓	✓	✓	-	-	-	-	-	✓	✓

GENERAL

Selection of the right external puller



1st step: Measuring the space available




2nd step: Selection of the puller type

Requirement:

- The puller is used for various applications.
- The puller must be able to change characteristics e.g. increase the reach etc.

Recommendation of KUKKO

Sliding-arm pullers with constantly parallel jaws



The puller jaws can be moved continuously (even asymmetrically) on the cross-beam, and can be fixed to the cross-beam using a bolt connection or knurled knob.

Series available


11 ; 20; 20+; 20-S; 20+S; 20-S-T; 20-S+T; 30; 30+; 30-S; 30+S; 30-S-T; 30-S+T; 110; 120; 130

Requirement:

- The same removal application is always used.

Recommendation of KUKKO

Puller with self-centering puller jaws (autogrip)



The two puller jaws are connected to each other. The pullers therefore ensure automatic self-tensioning and self-centering of the jaws.

Series available


43; 44; 45; 482; 483; 486; 844; 845

Requirement:

- The same removal application is always used.
- Same application at different depths.

Recommendation of KUKKO

Puller with swivel puller jaws



The jaws and the cross-beam are connected by movable brackets. As the spindle pulls, the jaws tense and tighten firmly. An additional option is swivel-jaws pullers. Reversing the puller jaws expands or reduces the reach.

Series available


41; 42; 46; 47; 201; 203; 205; 206; 207; 208; 209

Requirement:

- The bearing is flush.
- It is especially important that the puller arms do not slip off.

Recommendation of KUKKO

Puller with side tension clamps.




To remove flush parts the puller jaws grab beneath the part to be removed when pulling on the side clamps and loosen the part even before the actual pulling process. The clamp presses the puller jaws securely onto the part to be removed. This ensures that the puller jaws do not slip off.

Series available

204; 210


3rd step: How much force is required?

A normal amount of pressure is required.



Puller with mechanical pressure spindle

High pressure is required because the part to be removed is particularly secure, or rusted.



Puller with long hydraulic spindle

4th step: Select model

The selected pulling tool normally states the necessary power and pulling force. However, in order to be absolutely sure, you should always choose the largest possible model for dimension ranges which cross over.

For example:

diametre: 142 mm / 120 mm / 135 mm
 depth: 135 mm / 120 mm / 220 mm
 available space: unlimited

Specification: There must be pulled various bearings at different depths.
 Target: We are looking for a puller which can be individually adapted.
KUKKO recommended to use pullers with sliding puller arms that are always parallel.

The bearings are on the shaft.
KUKKO recommended to use a puller with a mechanical spindle.

According to the KUKKO website choose the pullers from series 20 and 30 in size 2.


The decision falls to : 30-2+ and 2-V-150-S

Advantage:

- with the 3-jaw model, you have the best possible load distribution and a particularly secure hold.
- You can adjust your puller to the relevant reach by buying the extensions.
- The quick adjusting capability allows the reach to be changed quickly.

EXTERNAL


EXTERNAL



You should always give a 3-jaw puller preference if the access conditions permit. The uniform load distribution guarantees a particularly secure hold on the to be extracted part.


How it works

STANDARD




External pulling is the most common type of pulling. The part to be extracted such as a gear wheel, pulley or ball bearing, is gripped from the outside. The part is loosened from the shaft by the pull of the pressure screw.

as INTERNAL extractor




The external pullers can also be used as internal extractors by turning the jaws. *Important: When used as internal extractors, a fixed center point is required to brace the pressure screw of the products in these series.*

Accessories: Modular extensions




For the 20 and 30 series, we offer modular extensions (combinable with size 1-20). If the part to be removed sits deep inside a shaft, jaw extensions will be needed.

Accessories: Side clamp




The side clamp is available separately (No. 219-1). It is attached to the puller jaw after the puller has been fitted and prevents slippage of the puller jaw under very high forces.

Accessories: Grease hydraulic pressure spindle



The hydraulic spindle ensures controlled and secure operating of 7-20 t. It uses the entire capability of the puller, over and above what can be achieved with a mechanical spindle. When replacing a mechanical spindle with a hydraulic one, there is also a considerable reduction in the drive force which needs to be used. **See also pages: 18, 22-23**

Accessories: auxiliary grease hydraulic rams



For use with mechanical KUKKO pullers from size 3.

The auxiliary grease hydraulic rams are a good tool for significantly increasing the pressure when removing very secure parts. The hydraulic rams are simply secured between the spindle and shaft with the mechanical spindle.

No conversion of the puller is needed!

See also page: 18

Accessories: Puller jaws



Pullers in series 20 and 30 can easily be adjusted using different puller jaws lengths and types.

Which puller jaws are right for which puller?

The puller jaws that start with **1-** → fit all pullers of size **-1** and **-10**

The puller jaws that start with **2-** → fit all pullers of size **-2** and **-20**

The puller jaws that start with **3-** → fit all pullers of size **-3** and **-30**

The puller jaws that start with **3-** → can also use by the pullers of size **-4** and **-40**


Example:

20-2 → has the puller jaws 2-150-P


→ can also use : 2-151-P; 2-152-P; 2-153-P

→ can also use long puller jaws such as: 2-300-P; 2-301-P; 2-302-P; 2-303-P



Safety instructions





The puller must be centrally positioned for center shafts. If the shaft is not centered, pulling with parallel jaws may result asymmetrical pulling.





If there are several parts to be pulled, always remove them one-by-one. Never remove several parts simultaneously.




Jaws must always be positioned directly below the part to be removed.



The jaws of the leg must be set firmly and completely against the cross-beam












If there is adequate free space around the part, we recommend a 3-jaw puller for optimal force distribution.



A 2-jaw puller is always used in situations where there is insufficient space for a 3-jaw puller.



  Pulling jaws for 2-jaw pullers, series 20 and 30

Series	Dimensions of the puller jaws	A mm	B mm	C mm	D mm	E mm	 mm	Art.-No. pair	QUICK adjust TECHNOLOGY	suitable for  KUKKO-pullers:	Art.-No. set	QUICK adjust TECHNOLOGY	suitable for  KUKKO-pullers:
									Art.-No. pair			Art.-No. set	
20 20+ 30 30+		3,0	20	15	31	10	100	1-90-P	1-92-P	20-1; 20-10	1-90-S	1-92-S	30-1; 30-10
		4,0	24	18	40	9	150	2-150-P	2-152-P	20-2; 20-20	2-150-S	2-152-S	30-2; 30-20
		4,0	35	37	67	20	200	3-200-P	3-202-P	20-3; 20-30; 20-4; 20-40	3-200-S	3-202-S	30-3; 30-30; 30-4; 30-40
20 20+ 30 30+		3,0	20	15	31	10	200	1-190-P	1-192-P	20-1; 20-10	1-190-S	1-192-S	30-1; 30-10
		3,0	20	15	31	10	250	1-250-P	1-252-P	20-1; 20-10	1-250-S	1-252-S	30-1; 30-10
		4,0	24	18	40	9	300	2-300-P	2-302-P	20-2; 20-20	2-300-S	2-302-S	30-2; 30-20
		4,0	35	37	67	20	300	3-300-P	3-302-P	20-3; 20-30; 20-4; 20-40	3-300-S	3-302-S	30-3; 30-30; 30-4; 30-40
		4,0	35	37	67	20	400	3-400-P	3-402-P	20-3; 20-30; 20-4; 20-40	3-400-S	3-402-S	30-3; 30-30; 30-4; 30-40
		4,0	35	37	67	20	500	3-500-P	3-502-P	20-3; 20-30; 20-4; 20-40	3-500-S	3-502-S	30-3; 30-30; 30-4; 30-40
20-S 20+S 30-S 30+S		2,6	30	7	14	-	100	1-91-P	1-93-P	20-1; 20-10	1-91-S	1-93-S	30-1; 30-10
		4,0	32	8	19	-	150	2-151-P	2-153-P	20-2; 20-20	2-151-S	2-153-S	30-2; 30-20
		6,5	35	17	52	-	200	3-201-P	3-203-P	20-3; 20-30	3-201-S	3-203-S	30-3; 30-30
20-S 20+S 30-S 30+S		2,6	30	7	14	-	200	1-191-P	1-193-P	20-1; 20-10	1-191-S	1-193-S	30-1; 30-10
		2,6	30	7	14	-	250	1-251-P	1-253-P	20-1; 20-10	1-251-S	1-253-S	30-1; 30-10
		4,0	32	8	19	-	300	2-301-P	2-303-P	20-2; 20-20	2-301-S	2-303-S	30-2; 30-20
		6,5	35	17	40	-	300	3-301-P	3-303-P	20-3; 20-30	3-301-S	3-303-S	30-3; 30-30
		6,5	35	17	40	-	400	3-401-P	3-403-P	20-3; 20-30	3-401-S	3-403-S	30-3; 30-30
		6,5	35	17	40	-	500	3-501-P	3-503-P	20-3; 20-30	3-501-S	3-503-S	30-3; 30-30
20-S-T 20+S-T 30-S-T 30+S-T		3,0	24	7	12	15	100	1-94-P	1-95-P	20-1; 20-10	1-94-S	1-95-S	30-1; 30-10
20-S-T 20+S-T 30-S-T 30+S-T		3,0	24	7	12	15	200	1-194-P	1-195-P	20-1; 20-10	1-194-S	1-195-S	30-1; 30-10
		3,0	24	7	12	15	250	1-254-P	1-255-P	20-1; 20-10	1-254-S	1-255-S	30-1; 30-10



Pulling jaws

Series	Dimensions of the puller jaws	A mm	B mm	C mm	D mm	E mm	C2 mm	E2 mm	Art.-No. pair	suitable for KUKKO-pullers:	Art.-No. set	suitable for KUKKO-pullers:
12-1 - 12-3		3,0	14	13	25	17	-	-	-	-	12-1-100-S	12-1
		3,0	17	13	27	20	-	-	-	-	12-2-125-S	12-2
		4,0	20	15	35	28	-	-	-	-	12-3-180-S	12-3
12-4 - 12-7		4	18	19	63	20	21	30	-	-	12-4-225-E	12-4
		4	18	19	63	20	21	30	-	-	12-5-275-E	12-5
		4	28	22	70	20	21	30	-	-	12-6-300-E	12-6
		4	28	22	70	20	21	30	-	-	12-7-350-E	12-7
14		2,5	21	3,5	8,5	-	-	-	14-1-85-P	14-1	-	-
		4,0	30	4	1-2	-	-	-	14-2-125-P	14-2	-	-
		4,0	30	5	1-3	-	-	-	14-3-160-P	14-3	-	-
		2,5	11	3,5	8,5	-	-	-	14-01-85-P	14-01	-	-
		4,0	30	5	1-3	-	-	-	14-03-160-P	14-03	-	-
41 42		2,0	10	7	15	4	-	-	41-0-40-P	41-0	42-0-40-S	42-0
		2,0	11	8	15	4	-	-	41-1-65-P	41-1	42-1-65-S	42-1
		2,0	11	9	16	5	-	-	41-2-80-P	41-2	42-2-80-S	42-2
		3,0	18	13	22	7,5	-	-	41-3-120-P	41-3	42-3-120-S	42-3
		4,0	24	18	35	9	-	-	41-4-160-P	41-4	42-4-160-S	42-4
		5,0	34	23	35	15	-	-	41-5-200-P	41-5	42-5-200-S	42-5
43 44 45		2,0	11	10	17	5	-	-	43-1-50-P	43-1	43-11-50-S	43-11
		2,0	11	10	17	5	-	-	43-2-70-P	43-2	43-12-70-S	43-12
		2,0	11	11	18,5	5	-	-	43-3-80-P	43-3	43-13-80-S	43-13
		3,0	16	11	20	7	-	-	44-1-100-P	44-1	45-1-100-S	45-1
		3,0	17	14	30	10	-	-	44-2-120-P	44-2	45-2-120-S	45-2
		3,0	20	19	32	12	-	-	44-3-160-P	44-3	45-3-160-S	45-3
		3,0	26	22	17	12	-	-	44-4-200-P	44-4	45-4-200-S	45-4
		4,0	28	24	40	16	-	-	44-5-250-P	44-5	45-5-250-S	45-5
		4,0	28	24	40	16	-	-	44-6-275-P	44-6	45-6-275-S	46-6
		7,0	10	22	60	22	-	-	-	-	45-7-350-S	45-7
46 47		8,0	30	22	50	22	-	-	46-300	46-1-A; 46-1-B 46-2-A; 46-2-B	46-300	47-1-A; 47-1-B 47-2-A; 47-2-B
		6,0	30	24	50	22	-	-	46-450	46-2-A; 46-2-B	46-450	47-2-A; 47-2-B
110		2,5	12	5	15	7	-	-	110-01-50-P	110-01; 110-02	-	-
		5	15	10	25	13	-	-	110-1-100-P	110-1; 110-10	-	-
		6	18	12	30	14	-	-	110-2-150-P	110-2; 110-20	-	-
		9	20	12	35	18	-	-	110-3-200-P	110-3	-	-
		9	20	12	35	18	-	-	110-4-250-P	110-4	-	-
112 113		10°	10	7	12	5	-	-	112-1-45-P	112-1	-	-
		15°	10	7	12	5	-	-	112-10-70-P	112-10	-	-
		15°	15	8	15	6	-	-	112-2-70-P	112-2	-	-
		15°	15	8	15	5,5	-	-	112-20-100-P	112-20	113-20-100-S	113-20
		5°	20	11	20	6,5	-	-	112-3-165-P	112-3	113-3-165-S	113-3
120 130		4	21	15	32	9	-	-	0-100-P	120-1; 120-10	0-100-S	130-10
		4	21	15	32	9	-	-	0-148-P	120-2	0-148-S	130-2
		4	28	18	43	15	-	-	0-150-P	120-20	0-150-S	130-20
		4	28	18	43	15	-	-	0-200-P	120-3; 120-30	0-200-S	130-3

EXTERNAL

EXTERNAL



Pulling jaws

Series	Dimensions of the puller jaws	A mm	B mm	C mm	D mm	E mm	A2 mm	B2 mm	C2 mm	D2 mm	E2 mm		Art.-No. pair	suitable for KUKKO-pullers:	Art.-No. set	suitable for KUKKO-pullers:	suitable for KUKKO-pullers:		
																		mm	
201 202 203 208-0		3,0	11	8	17	6	2	11	5	14	6	-		201-075-P	201-0	202-075-S	202-0	203-0	
		3,0	15	12	25	7	2	9	9	22,5	7	-		201-1-85-P	201-1	202-1-85-S	202-1	203-1	
		4,0	26	20	35	7	3	20	18	33	7	8		201-2-130-P	201-2	202-2-130-S	202-2	203-2	
		5,0	26	20	35	12	4	26	20	35	12	8		201-3-260-P	201-3	202-3-260-S	202-3	203-3	
		8,0	26	21	45	20	8	26	17	40	20	-		201-4-300-P	201-4	202-4-300-S	202-4	203-4	
		7,5	8,5	3,5	11,5	7,5	6	6	3,5	8,5	6	-		201-S-P	201-5	202-S-S	202-5	-	
		5,0	10	9	15	5	5	10	9	20	5	-		208-0-100-P	208-0	209-0-100-S	209-0	-	
208 209		3,5	16	13	26	10	-	-	-	-	-		208-01-125-P	208-01	209-01-125-S	209-01	-		
		4,5	20	20	30	13	-	-	-	-	w-	-		208-02-190-P	208-02	209-02-190-S	209-02	-	
204		4,0	22	12	22	8,5	-	-	-	-	-	-		204-1-90-P	204-1	-	-	-	
		3,5	24	12	25	10	-	-	-	-	-	-	-		204-2-100-P	204-2	-	-	-
		4,0	30	21	35	15	-	-	-	-	-	-	-		204-3-140-P	204-3	-	-	-
204-0		2,5	18	10	20	5	-	-	-	-	-	-		204-0-70-P	204-0	-	-	-	
		3,0	24	9	20	6	-	-	-	-	-	-	-		204-02-100-P	204-02 204-V	-	-	-
210		4,0	25	15	35	11	2	25	5	25	17	-		210-1-170-P	210-1	-	-	-	
		4,0	25	15	40	15	1,5	25	5	36	22	-		210-2-270-P	210-2	-	-	-	
		4,0	25	15	50	15	2,0	25	5	31	22	-		210-3-325-P	210-3	-	-	-	
205 206 207		2,0	14	12	27	7,5	-	-	-	-	-	-		205-00-100-P	205-00	206-00-100-S	206-00; 207-00	-	
		3,0	18	14	41	8	-	-	-	-	-	-	-		205-01-150-P	205-01	206-01-150-S	206-01; 207-01	-
		4,0	24	15	50	18	-	-	-	-	-	-	-		205-02-220-P	205-02	206-02-220-S	206-02; 207-02; 206-02-B; 207-02-B	-
		5,0	30	19	48	18	-	-	-	-	-	-	-		205-1-280-P	205-1	206-1-280-S	206-1; 207-1; 206-1-B; 207-1-B	-
		8,0	30	22	46	20	-	-	-	-	-	-	-		205-2-400-P	205-2	206-2-400-S	206-2; 207-2; 206-2-B; 207-2-B; 209-2-B	-
		4,5	30	22	58	19	-	-	-	-	-	-	-		205-3-540-P	205-3	206-3-540-S	206-3; 207-3; 206-3-B; 207-3-B	-
482 483		2,0	8	8	11	4	-	-	-	-	-	-		482-1-40-P	482-1	-	-	-	
		2,5	8	8	12	5	-	-	-	-	-	-		482-2-90-P	482-2	483-2-90-S	483-2	-	
		3,0	14	8	17	8	-	-	-	-	-	-		482-3-150-P	482-3	483-3-150-S	483-3	-	
		3,5	16	9	22	9	-	-	-	-	-	-		482-4-200-P	482-4	483-4-200-S	483-4	-	
		3,5	16	12	25	10	-	-	-	-	-	-		482-5-250-P	482-5	483-5-250-S	483-5	-	
820 844 845		5,0	30	20	40	8	-	-	-	-	-	-		820-225-P	820-0	-	-	-	
		6,5	25,5	13	40	-	-	-	-	-	-	-		844-100	844-1-B	844-100	845-1-B	-	
		6,5	25,5	13	38	-	-	-	-	-	-	-		844-150	844-2-B	844-150	845-2-B	-	
		6,5	25,5	16	44	-	-	-	-	-	-	-		844-200	844-4-B	844-200	845-4-B	-	
		6,5	25,5	13	42	-	-	-	-	-	-	-		844-250	844-3-B	844-250	845-3-B	-	
		6,5	25,5	13	44	-	-	-	-	-	-	-		844-251	844-5-B	844-251	845-5-B	-	
Y-205 Y-206		5,0	29	25	102	33	-	-	-	-	-	-		Y205-00	Y20-205; Y28-205	Y205-00	Y20-206; Y28-206	-	
		5,0	38,5	30	125	41	-	-	-	-	-	-		Y305-00	Y30-205; Y38-205	Y305-00	Y30-206; Y38-206	-	
		10,0	30	42	155	63	-	-	-	-	-	-		Y505-00	Y50-205; Y58-205	Y505-00	Y50-206; Y58-206	-	
Y-208		4,0	24	15	50	18	-	-	-	-	-	-		-	-	206-02-220-S	Y05-208; Y08-208	-	
		4,5	30	22	58	19	-	-	-	-	-	-		-	-	206-3-540-S	Y10-208; Y18-208	-	

EXTERNAL

EXTERNAL

EXTERNAL

EXTERNAL



Mechanical pressure spindle
For use with KUKKO pullers of all sizes



- KUKKO pressure spindles with milled thread have been specifically engineered for use in KUKKO pullers.
- The pressure spindles are specially coated and therefore guarantee particularly good sliding properties in the thread.
- Optimal adjustment of the spindle to the shaft with 2-sided spindle top.
- The mounted, freely-rotating centering point protects the shaft against damage when applying the pulling force.
- The spindle heads have a band which prevents the wrench from slipping during the pulling process.
- The spindle head and the spindle band (see diagram below) are lasered with the item number.



Long hydraulic spindle
For use with large KUKKO pullers



- Due to their high pressure performance, the hydraulic spindles ensure very secure parts can be removed quickly and effortlessly.
- The hydraulic spindle ensures controlled and safe working.
- It uses the entire capability of the puller, over and above what can be achieved with a mechanical spindle.
- The application of hydraulic pulling force must always be controlled by the use of a torque wrench.



Auxiliary hydraulic ram
For use with mechanical KUKKO pullers from size 3



- The hydraulic rams are a good tool for significantly increasing the pressure when pulling particularly secure parts.
- The hydraulic rams are secured between the spindle and the shaft using the mechanical spindle.
- No conversion of the puller is required!

Care of the puller spindle

Puller spindle maintenance

The spindle must always be kept well lubricated. We recommend the use of KUKKO special sliding grease for pressure spindle (Art. No.: 699915), or KUKKO Bio Multi Oil (Art. No.: 699990). A tube of KUKKO special sliding grease for pressure spindle is free with every order of an original KUKKO puller.



Selection of the right spindle top.




Optimal adjustment of the spindle to the shaft with 2-sided spindle tip (ball and tip).



Mechanical pressure spindles from KUKKO only complete with a safety-first label.

Hang the safety-first label back on the spindle after use of the puller.




Precautionary Notes and Helpful Hints



Always wear suitable personal protective equipment, including protective goggles.



Never use an electric- or pneumatic-powered impact/hammer drill for driving a pulling tool.



Always wrap the pulling tool and the workpiece in a protective blanket as a precaution against the potential effects of sudden release.



Keep the threads of all pressure spindle and cross-beam clean and well oiled.

Mechanical pressure spindle




Description

- KUKKO pressure spindles with milled thread have been specifically engineered for use in KUKKO pullers, in order to achieve particularly high tensile forces.
- The pressure spindles are specially coated and therefore guarantee particularly good sliding properties in the thread.
- Optimal adjustment of the spindle to the shaft with 2-sided spindle tip - 4
- The mounted, freely-rotating centering point 5 protects the shaft against damage when applying the pulling force.
- Only complete with KUKKO safety-first label 6
- A tube of KUKKO special grease KSF-69 included for pressure spindle.

Advantage

- The spindle head 2 and the spindle band 3 are lasered with the item number.
- The spindle heads have a band which prevents the wrench from slipping during the pulling process. 1

The correct determination of a replacement spindle if no item number is available.



a Measure the spindle diameter.



b Measure the thread length to the tip of the spindle.



c Measure the length over three turns of the thread.



d Measure the hexagon of the spindle head.



Art.-No.	Barcode	suitable for	thread	a mm	b mm	c mm	d mm	SW mm	1	2	3	4	5	6	Art.-No.	
608080	-176241	48, 482-1	M 8x1,25	8	80	3,75	-	-	-	X	-	-	-	X	-	
608130	-481086	482-2, 483-2	M 8x1,25	8	130	3,75	-	-	-	X	-	-	-	X	-	
609087	-102493	41-1, 42-1, 43-1, 43-11, 43-12, 43-2	M 9x1,25	9	87	3,75	-	-	-	X	-	-	-	X	-	
609105	-101403	41-2, 42-2, 43-3, 43-13	M 9x1,25	9	105	3,75	-	-	-	X	-	-	-	X	-	
610070	-362446	41-0, 42-0	M 10x1,5	10	75	4,50	13	X	-	-	-	-	-	X	-	
610094	-122118	204-0	M 10x1,5	10	94	4,50	-	-	X	-	-	-	-	X	-	
610110	-433726	208-0, 209-0, 112-1, 112-10	M 10x1,5	10	120	4,50	8	X	-	-	-	-	X	-	-	
610120	-910005	70-01	M 10x1,5	10	120	4,50	13	X	-	-	-	-	X	-	-	
612080	-238468	201-0, 202-0, 203-0	M 12x1,5	12	85	4,50	13	X	-	-	X	X	-	X	612140	
612110	-112881	205-00, 206-00, 207-00	M 12x1,5	12	110	4,50	13	X	-	-	X	X	-	X	612140	
612130	-077081	18-0, 44-1, 45-1, 14-01, 14-1	M 12x1,5	12	130	4,50	13	X	-	-	X	X	-	X	612140	
612150	-790201	41-3, 42-3	M 12x1,5	12	150	4,50	13	X	-	-	X	-	-	-	-	
612200	-480744	482-3, 483-3	M 12x1,75	12	210	5,25	13	X	-	-	X	X	-	X	612140	
614135	-074271	12-1, 30-1, 30-1+, 30-10, 30-10+, 30-1-S, 30-10-S, 30-1+S, 30-10+S, 30-1-S-T, 30-10-S-T, 30-1+S-T, 30-10+S-T, 30-10-P3 30-10SP, 32-1, 33, 34-0, 34-1, 110-1, 110-10, 112-2, 120-1, 120-10, 130-10, 201-1, 202-1, 203-1,	M 14x1,5	14	135	4,50	17	X	-	-	X	X	-	-	X	612140
614160	-112966	14-2, 20-1, 20-10, 20-1-S, 20-10-S, 20-1+S, 20-10+S, 20-1+, 20-10+, 20-1+S-T, 20-10+S-T, 20-1-2, 20-1-2S, 20-1-4, 20-10-2, 20-10-2S, 20-10-4, 20-1-S-T, 20-10-S-T, 20-10-SP, 20-10-P3, 20-10-V, 30-1-2, 30-10-2, 44-2, 45-2, 112-20, 113-20, 120-2, 130-2, 205-01, 206-01, 207-01, 208-01, 209-01	M 14x1,5	14	160	4,50	17	X	-	-	X	X	-	-	-	612140
614200	-838576	14-3, 14-03 41-4, 42-4	M 14x1,5	14	200	4,50	17	X	-	-	X	-	-	-	-	
614250	-306709	K-2030-10, K-2030-10+S, K-2030-10+S+T, 70-2, 201-S, 202-S	M 14x1,5	14	250	4,50	17	X	-	-	X	X	-	-	612140	
616220	-420856	112-3, 113-3	M 16x1,5	16	220	4,50	17	X	-	-	X	-	-	-	-	
616270	-480829	482-4, 483-4	M 16x2,0	16	270	6,00	17	X	-	-	X	-	-	-	-	
616325	-480904	482-5, 483-5	M 16x2,0	16	325	6,00	17	X	-	-	X	-	-	-	-	
618068	-123771	127-3, 128-3, 128-G3	M 18x1,5	18	58	4,50	19	X	-	-	X	-	-	-	-	
618105	-073779	204-1	M 18x1,5	18	105	4,50	19	X	-	-	X	-	-	-	-	
618175	-074356	12-2, 18-1, 32-2, 110-2, 110-20	M 18x1,5	18	175	4,50	19	X	-	-	X	X	-	-	616180	
618210	-113048	44-3, 45-3	M 18x1,5	18	210	4,50	19	X	-	-	X	-	-	-	-	
620172	-817946	28-1, 28-2	M 20x2,5*	20	170	7,50	24	X	X	-	X	X	-	-	620260	
620230	-818028	28-3	M 20x2,5*	20	230	7,50	24	X	X	-	X	-	-	-	-	
620250	-818103	28-4	M 20x2,5*	20	250	7,50	24	X	X	-	X	-	-	-	-	
621130	-124358	204-2, 204-02	G 1/2" / 14"	20,955	130	5,40	22	X	-	-	X	-	-	-	-	
621170	-067181	18-2	G 1/2" / 14"	20,955	170	5,40	22	X	-	-	X	X	-	-	620260	
621220	-268373	20-2, 20-20, 20-2+, 20-2+S, 20-20+S, 20-20+, 20-2-S, 20-20+, 20-2-S, 20-20-S, 20-2-3, 20-20-3, 20-20SP, 20-20-P2, 30-2, 30-20, 30-2+, 30-20+, 30-2+S, 30-20+S, 30-2-S, 30-20-S, 30-2-3, 30-20-3, 30-20SP, 30-20-P2, 31-1, 31-2, 124-20-A, 124-20-1, 200-U, 201-2, 202-2, 203-2, 205-02, 206-02, 207-02, 208-02, 209-02, 210-1	G 1/2" / 14"	20,955	220	5,40	22	X	-	-	X	X	-	-	-	620260
621300	-765346	41-5, 42-5, 110-3, 110-4	G 1/2" / 14"	20,955	300	5,40	22	X	-	-	X	X	-	-	620260	
621355	-236228	70-4, 112-4, 113-4	G 1/2" / 14"	20,955	355	5,40	22	X	-	-	X	-	-	-	-	
623150	-018961	128-4, 128-5, 128-T-4	G 5/8" / 14"	22,911	150	5,40	24	X	-	-	X	-	-	-	-	
623170	-124501	120-20, 130-20, 204-3, 204-30	G 5/8" / 14"	22,911	170	5,40	24	X	-	-	X	X	-	-	620260	
623230	-074684	12-3, 120-3, 120-30, 130-3	G 5/8" / 14"	22,911	230	5,40	24	X	-	-	X	X	-	-	620260	
623260	-113123	44-4, 45-4	G 5/8" / 14"	22,911	260	5,40	24	X	-	-	X	X	-	-	620260	
623325	-125263	44-5, 45-5, 113-5, 210-2, 210-3	G 5/8" / 14"	22,911	325	5,40	24	X	-	-	X	-	-	-	-	
623360	-814976	44-6, 45-6	G 5/8" / 14"	22,911	400	5,40	24	X	-	-	X	-	-	-	-	
623450	-832796	45-7	G 5/8" / 14"	22,911	450	5,40	24	X	-	-	X	-	-	-	-	
626300	-765360	18-3, 20-3, 20-30, 20-3+, 20-30+, 20-3-S, 20-30-S, 20-3+S, 20-30+S, 20-3-2S, 20-30-3, 20-30-3+, 20-30-3-S, 20-30-3-S, 20-30-3-S, 20-30-P3, 20-30SP, 30-3, 30-30, 30-3+, 30-30+, 30-3-S, 30-3+S, 30-3-2S, 30-3-3, 30-30-3, 30-30-3+, 30-30-3-S, 30-30-5, 30-3-P3, 30-3SP, 201-3, 201-4, 202-3, 202-4, 203-3, 203-4, 205-1, 206-1, 207-1	G 3/4" / 14"	26,441	300	5,40	27	X	-	-	X	X	-	-	-	620260
626400	-125423	20-40, 20-40-4, 20-40-5, 12-4, 205-2, 205-3, 206-2, 206-3, 207-2, 207-3, 10-M,	G 3/4" / 14"	26,441	400	5,40	27	X	-	-	X	-	-	-	-	-
626500	-765377	12-5	G 3/4" / 14"	26,441	500	5,40	27	X	-	-	X	-	-	-	-	
633400	-765384	11-0, 18-4, 20-4, 46-1, 47-1	G 1" / 14"	33,249	400	6,90	36	X	-	-	X	-	-	-	-	
633500	-893452	20-AV, 46-2-A, 47-2-A	G 1" / 14"	33,249	500	6,90	36	X	-	-	X	-	-	-	-	
633600	-866388	12-6, 12-7	G 1" / 14"	33,249	600	6,90	36	X	-	-	X	-	-	-	-	
637350	-893469	11-1, 11-2, 30-40, 30-5	G 1 1/8" / 14"	37,897	350	6,90	41	X	-	-	X	-	-	-	-	
637500	-893469	15-E	G 1 1/8" / 14"	37,897	500	6,90	41	X	-	-	X	-	-	-	-	
637600	-169236	18-5, 20-5, 205-65, 205-80, 205-95, 207-65, 207-80, 207-95	G 1 1/8" / 14"	37,897	600	6,90	41	X	-	-	X	-	-	-	-	

EXTERNAL

Backfitting 2- and 3-jaw pullers from mechanic up to hydraulic spindle



When using pullers with hydraulic spindles, the application of hydraulic pulling force must always be controlled, i.e., by the use of a torque wrench.

Art. No.	+	max.		max. Nm	
		t	kN		
20-2+	8-01	7	70	150	12
20-20	8-01	7	70	150	12
20-20+	8-01	7	70	150	12
20-2-3	8-01	7	70	150	12
20-20-3	8-01	7	70	150	12
20-3	8-02	8,5	85	300	14
20-3+	8-02	8,5	85	300	14
20-30	8-02	8,5	85	300	14
20-30+	8-02	8,5	85	300	14
20-3-3	8-02	8,5	85	300	14
20-3-4	8-02	8,5	85	300	14
20-3-5	8-02	8,5	85	300	14
20-30-3	8-02	8,5	85	300	14
20-30-4	8-02	8,5	85	300	14
20-30-5	8-02	8,5	85	300	14
20-4	8-1-B	15	150	400	45
20-4-3	8-1-B	15	150	400	45
20-4-5	8-1-F	15	150	400	45
20-40	8-1-B	15	150	400	45
20-40-4	8-1-B	15	150	400	45
20-40-5	8-1-F	15	150	400	45
20-5	8-2-M	15	200	650	30
30-2	8-01	7	70	150	12
30-2+	8-01	7	70	150	12
30-20	8-01	7	70	150	12
30-20+	8-01	7	70	150	12
30-2-3	8-01	7	70	150	12
30-20-3	8-01	7	70	150	12
30-3	8-02	10	100	250	15
30-3+	8-02	10	100	250	15
30-3-3	8-02	10	100	250	15
30-3-4	8-02	10	100	250	15
30-3-5	8-02	10	100	250	15
30-3-5	8-02	10	100	250	15

2- and 3-jaw puller with hydraulic spindle



20-2	8-01	7,0 to / 70 kN	12 Nm
20-2+	8-01	7,0 to / 70 kN	12 Nm
20-20	8-01	7,0 to / 70 kN	12 Nm
20-20+	8-01	7,0 to / 70 kN	12 Nm
20-2-3	8-01	7,0 to / 70 kN	12 Nm
20-20-3	8-01	7,0 to / 70 kN	12 Nm
20-3	8-02	8,5 to / 85 kN	14 Nm
20-3+	8-02	8,5 to / 85 kN	14 Nm
20-30	8-02	8,5 to / 85 kN	14 Nm





When using pullers with hydraulic spindles, the application of hydraulic pulling force must always be controlled, i.e., by the use of a torque wrench.

Art. No.	+	max.		max. Nm
		t	kN	
20-2-B	8-01	7	70	12
20-20-B	8-01	7	70	12
20-3-B	8-02	10	100	15
20-30-B	8-02	10	100	15
20-4-B	8-1-B	15	150	45
20-40-B	8-1-B	15	150	45
20-2-3-B	8-01	7	70	12
20-20-3-B	8-01	7	70	12
20-3-3-B	8-02	10	100	15
20-3-4-B	8-02	10	100	15
20-3-5-B	8-02	10	100	15
20-30-3-B	8-02	10	100	15
20-30-4-B	8-02	10	100	15
20-30-5-B	8-02	10	100	15
20-4-3-B	8-1-B	15	150	45
20-4-4-B	8-1-B	15	150	45
20-4-5-B	8-1-B	15	150	45
20-40-4-B	8-1-B	15	150	45
20-40-5-B	8-1-B	15	150	45
20-2+B	8-01	7	70	12
20-20+B	8-01	7	70	12
20-3+B	8-02	10	100	15
20-30+B	8-02	10	100	15
30-2-B	8-01	7	70	12
30-20-B	8-01	7	70	12
30-3-B	8-02	10	100	15
30-2-3-B	8-01	7	70	12
30-20-3-B	8-01	7	70	12
30-3-3-B	8-02	10	100	15
30-3-4-B	8-02	10	100	15
30-3-5-B	8-02	10	100	15
30-2+B	8-01	7	70	12
30-20+B	8-01	7	70	12
30-3+B	8-02	10	100	15


EXTERNAL

EXTERNAL

Selection of the right internal puller type



1st step: What is the interior diameter of the ball bearing




2nd step: Selection of the internal puller

<p>2 a 2- and 3-shell Internal extractors</p> <p>5-200 mm</p>	<p>2 b Segmented internal extractors for small spaces</p> <p>5-78 mm</p>	<p>2 c Needle bearing extractors</p> <p>9,6-25 mm</p>
--	---	--

3rd step: What is access like?

<p>3 a Supporting surface present → Counter stay</p>	<p>3 b NO supporting surface present → slide hammer</p>
---	--

Combinations of internal pullers with counter stays and slide hammers




Counter stays and slide hammers can be combined with internal extractors of various sizes. The appropriate thread adapters are delivered with orders for counter stays and slide hammers. See also pages: 26-27

How it works


For pulling internal ball bearings, ball bearing outer rings and bushings. The bearings are securely grasped by the internal puller, in the inner ring, and quickly removed using the clamping effect. In order to be able to remove a bearing with an internal puller, a counter support or a slide hammer from series 22 will always be required.

Accessories: Extensions



Many of the KUKKO internal extractors in the 21 series (not 21-E) can be expanded using an extension (series 21-V) for extracting parts set deep inside a bushing.

Accessories: Thread adapters



The KUKKO slide hammers can be used in combination with the thread adapters 22-1-AS anywhere where the threaded pin can be screwed directly into the part that needs to be removed.

Safety instructions for internal pulling

<p>When using a counter stay, ensure that the jaws of the counter stay do not block the part being removed.</p>	<p>Note: the internal extractors must grip firmly underneath the part to be removed.</p>	<p>If there is too little space in the bushing below the part to be removed, an internal extractor from series 21-E may be used.</p>		
---	--	--	--	--

Reversible jaws allow for both external and internal extractions.



The external pullers can also be used as internal extractors by turning the jaws. Important: When used as internal extractors, a fixed center point is required to brace the pressure screw of the products in these series.




This puller is designed to be used with a counter-stay, when a shaft is present or with a slide hammer, when no shaft is present.

INTERNAL



INTERNAL



Combination of counter stay with internal extractors, series 21




Combination of counter stay with segmented internal extractors, series 21-E





INTERNAL

INTERNAL

Combination of slide hammer with internal extractors, series 21




Combination of slide hammer with segmented internal extractors, series 21-E




Selection of the right separator



The part to be removed is level. It is not possible to use standard puller jaws!



1st step: What is the diameter of the flush bearing?



2nd step: Choice of the separator blade

2 (a) Separator series 15




2 (b) Separator with quick clamping pressure spindle, series 17



TIP: One-hand operation due to quick-tension spindle

3rd step: Choice of the pulling device

3 pulling device series 18



4th step: Combination of the separating blade with the pulling device

4 (a) Separator



series 15 + series 18


4 (b) Separator with quick clamping pressure spindle




series 17 + series 18

Mode of operation


For pulling tight parts such as ball bearings, roller bearings, inner rings and similar. The sharp, wedge-shaped blades are pressed behind the parts to be removed and, in this process, push between the bearing and the seat. For pulling, the tension bolts on the pulling device (series 18) must be screwed into the separator.



Normally, a separator blade is used in combination with a puller device.




If the separating jaws are screwed into the pulling device the other way round, then pulling can be carried out flush and gently.




In some cases, an appropriate puller from the 20 series can be used instead of the puller bar.

Accessories: Extensions




It is also possible to extend the puller bar for jobs involving longer shafts.

Accessories: long hydraulic spindles




For particularly secure parts, in the larger models (from 18-2), the mechanical pressure spindle can be swapped for a hydraulic pressure spindle.

More Separators




The extensive KUKKO line also supplies separators with side clamps, such as the 204 and 210 Cobra series.



Safety instructions for separating




The adjusting nuts on the separator must be tightened in alternating and equal turns. Otherwise, the separator blade may tilt on the bolt or the thread may be damaged.



When pulling the separator blade, ensure that before the pulling device is pulled upwards the blade is firmly seated up to the stop under the part to be removed.




The side bolts of the pulling device must always be spindled into the separator blade until they stop.






Selection of the right ball bearing extractor




1st step: What is the ISO number of the ball bearing?



2nd step: Reusing of the ball bearing



3rd step: Choice of the right ball bearing puller




TIP! For unusually tight-fitting ball bearings on a shaft, we recommend the use of our inductive ball bearing heater, T-AW.


BALL BEARING removal

A The ball bearing is in a housing and on a shaft at the same time.

B The ball bearing is inside a casing, but has no shaft for support.



BALL BEARING installation



The KUKKO 800 modular system is a pull-apart system, which consists of single parts that can be put together individually from finished pullers or complete sets.

ONE for ALL

All pullers have the same hydraulic spindle and consist of easily exchangeable single parts that can be combined in many different ways.

High pull-off force



The short KUKKO hydraulic spindle means that little manual effort is required for maximum pulling performance. No additional drive tools are needed.

Versatility


The modular system allows for a large number of different pulling options.

Selection of the right puller series 800


EXTERNAL






INTERNAL






SEPARATING




1st step: Measuring the space available



2nd step: Selection of the puller type



Simple operation of the hydraulic spindle with a T-handle.



The hydraulic spindle allows for controlled and safe working. It uses the entire performance potential of the puller.

If necessary, a wrench can be used on the hexagonal profile for counterholding. The grooved handle facilitates adjustment when applied to the workpiece.

The spindle nut has a groove that grabs the noses of the puller hooks. The puller pressure deployed pushes the nut deeper into the cross-beam, thereby tightening the puller hooks onto the part being pulled out.



The stable cross-beam enables fast replacement of the various puller hooks.

The fine threads of the hydraulic spindle allow for exact adjustment.

Additional spindle extensions are available in 3 different lengths.



The powerful puller hooks are made of grade tool steel.

With increasing spindle pressure, the puller hooks clasp the part being pulled out with automatically increasing force.












The part to be pulled lies only on the large support surfaces of the puller hooks and is pulled off gently.

Assembly of the hydraulic puller






COMBINATION






Choice of the correct ball joint puller / extractor

1st step: What is the installation situation?




2nd step: How big is the ball joint?



3rd step: Choice of the ball joint extractor type

Series 135



18-45 mm

- Simple, economical method
- For tight spaces
- Hammer required
- Possibility of damage to the rubber cuff


Series 128



18-50 mm



- Bell-shaped design
- Direct pressure on the ball pin
- Ideal if enough space is available
- Working without damage
- A torque wrench is recommended for the drive

Series 129



18-50 mm

- Leverage
- Very forceful
- Work area is shifted outside
- Ideal in tight spaces
- Hydraulic variants for very high power requirements
- Working without damage
- A torque wrench is recommended for the drive





Workshop tool trolley, K-CubeBoxx

that can be combined with drawers for the proven KUKKO L-BOXX system.

The new KUKKO workshop car system is an ideal complement to the traditional wall panel. The stability of the trolley is due to the base frame. Additional advantages include its mobile use for repairs directly on the vehicle or using it for orderly, central storage of pulling tools in the operation. The system can be individually combined with Sortimo boxes from the KUKKO product range or from other manufacturers.



Description:

- Tilt-resistant with stable design.
- Smooth and stable load castors, including two with brakes.
- Simple loading of extracts with KUKKO-L-Boxx cases.
- Fully assembled prior to delivery, including black rubber mat in the storage compartment.

Advantage:

- Ideal work height for use in workshops and industry.
- Smooth-running extracts and self-closing mechanism for the drawers.
- KUKKO L-BOXX - quickly and easily adjustable with quick locking mechanism.
- Simply remove the drawers to use the large L-BOXX separately.



drawer

K-Cube-SF



INCLUSIV

rubber mat

K-Cube-GM



drawer

unlocking

KUKKO L-Boxxen **not** included.

EXTERNAL pulling



INTERNAL pulling



SEPARATING




BALL BEARING removal and installation





GENERAL



GENERAL



	<p>The geometry of the cross-beam and sliding parts has been optimized to ensure particularly easy movement of the extractor jaws along the cross-beam.</p>	
	<p>A manual adjustment knurl allows rapid loosening and adjusting of the extractor jaws on the cross-beam without using a wrench.</p>	
	<p>The cross-hooks guarantee maximum stability due to the mounting of the puller jaws in the sliding part.</p>	
	<p>The operating nut is easy to turn thanks to a built in pressure bearing. Resistance from friction is reduced to a minimum.</p>	
	<p>Smooth-running, self-adjusting spring-back jaws.</p>	
	<p>Automatic tensioning and centering of the extractor jaws.</p>	
	<p>By turning the locking bolt the jaws are centered and tensioned and therefore firmly grip the piece to be pulled off. This prevents the jaws moving or slipping off.</p>	
	<p>Optimal adjustment of the spindle to the shaft with 2-sided spindle tip (ball and tip).</p>	
	<p>Unique, simple pullback of the nut splitter chisel to remove it from deformed or split nuts. The chisel does not get stuck in the nut.</p>	
	<p>Tools with hydraulic function.</p>	

Precautionary Notes and Helpful Hints

All tools must always be used for the intended purposes under the envisioned conditions and within their postulated limitations.

	<p>Check the condition of your tools at regular intervals, and replace any damaged or worn parts.</p>		
	<p>Keep the threads of all pressure spindle and cross-beam clean and well oiled. (KUKKO special sliding grease for pressure spindle Art. 699999)</p>		
	<p>Before you start work, acquaint yourself with the proper use of the tool or tools in question, with due attention to pertinent safety measures.</p>		
	<p>If anything at all is unclear about any of the above, it is best to call the factory for some firsthand advice.</p>		
	<p>Prior to starting work, make sure that the pulling tool is in good working order.</p>		
	<p>Double-check the tool for correct mounting, and monitor the forces incidental to the pulling process.</p>		
	<p>Never violate the maximum load data prescribed for the tool in question. Use a torque wrench (for mechanical/pressure-screw-driven tools) or a pressure gauge (hydraulic/pump-driven tools) to keep tabs on the applied forces.</p>		
	<p>Always wear suitable personal protective equipment, including protective goggles.</p>		
	<p>Always wrap the pulling tool and the workpiece in a protective blanket as a precaution against the potential effects of sudden release.</p>		
	<p>If the tool appears to be overloaded, works sluggishly, or is otherwise negatively conspicuous, interrupt the pulling process, and replace the tool with a larger model.</p>		
	<p>Never use an electric- or pneumatic-powered impact/hammer drill for driving a pulling tool.</p>		
	<p>Never use extensions to increase the applied torque.</p>		
	<p>Never alter a pulling tool or related product in any way.</p>		
	<p>Since heat detracts from the thermal properties of steel, and since some parts require heating to facilitate their removal, remember to never heat the pulling tool along with the part.</p>		