

2001-2004 FORD ESCAPE 3.0L REAR MANIFOLD

Warning: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

Step 1:(Carefully read all instructions before installation) To remove the OEM rear manifold converter, first you must remove the "Y" pipe assembly. (See diagram 1) Next you must remove both the EGR and O2 sensor from the converter assembly. (See diagram 2) Next you must unbolt the alternator. Do this by first removing the plastic covering on the passenger side. (See diagram 3) Next loosen the belt tensioner bolt. (See diagram 4) Now remove the alternator bolts and remove the alternator. (See diagram 5) Once the alternator has been removed, you're now ready to remove the manifold bolts and carefully remove the converter.



"Y" PIPE



DIAGRAM 1

2001-2004 FORD ESCAPE 3.0L REAR MANIFOLD



Warning: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

DIAGRAM 2



DIAGRAM 3

2001-2004 FORD ESCAPE 3.0L REAR MANIFOLD




DIAGRAM 4

Warning: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.



DIAGRAM 5