

Please read and save these instructions. Read through this owner's manual carefully before using product. Protect yourself and others by observing all safety information, warnings, and cautions. Failure to comply with instructions could result in personal injury and/or damage to product or property. Please retain instructions for future reference.



DIGITAL REFRIGERANT SCALE

UNPACKING

After unpacking unit, inspect carefully for any damage that may have occurred during transit. Check for loose, missing, or damaged parts. If any damage is observed, a shipping damage claim must be filed with carrier. Do not use the OEMTOOLS® Digital Refrigerant Scale if broken, bent, cracked or damaged parts (including labels) are noted. Any Digital Refrigerant Scale that appears damaged in any way, operates abnormally or is missing parts should be removed from service immediately. If you suspect that the Digital Refrigerant Scale was subjected to shock load (a load that was dropped suddenly, unexpectedly, etc.) immediately discontinue use until it has been checked by a factory authorized service center.



⚠ WARNING

The following safety information is provided as a guideline to help you operate your Digital Refrigerant Scale under the safest possible conditions. Any tool or piece of equipment can be potentially dangerous to use when safety or safe handling instructions are not known or not followed. The following safety instructions are to provide the user with the information necessary for safe use and operation. Please read and retain these instructions for the continued safe use of your service system. Failure to follow instructions listed below may result in serious injury. In addition, make certain that anyone that uses the equipment understands and follows these safety instructions as well.

Explanation of Safety Signal Words

⚠ WARNING: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

CAUTION: Used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

NOTES: Provide clarity and helpful information.

Thank you very much for choosing an OEMTOOLS Product!

For future reference, please complete the owner's record below:

Model: _____ **Purchase Date:** _____

Save the receipt, warranty and these instructions. It is important that you read the entire manual to become familiar with this product before you begin using it. This machine is designed for certain applications only. OEMTOOLS cannot be responsible for issues arising from modification. We strongly recommend this machine is not modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the machine until you have first contacted OEMTOOLS to determine if it can or should be performed on the product.



DIGITAL REFRIGERANT SCALE



IMPORTANT INSTRUCTIONS AND SAFETY RULES

1. Know your tool. Read this manual carefully. Learn the tool's applications and limitations, as well as, potential hazards specific to it.
2. Keep work area clean and well lit. Cluttered or dark work areas invite accidents.
3. Keep children away. All children should be kept away from the work area. Never let a child handle a tool without strict adult supervision.
4. Do not operate this tool if under the influence of alcohol or drugs. Read warning labels on prescriptions to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not attempt to operate.
5. Use safety equipment. Eye protection should be worn at all times when operating this tool. Use ANSI approved safety glasses. Everyday eyeglasses are NOT safety glasses. Dust mask, non-skid safety shoes, hard hat or hearing protection should be used in appropriate conditions.
6. Wear proper apparel. Loose clothing, gloves, neck-ties, rings, bracelets or other jewelry may present a potential hazard when operating this tool. Keep all apparel clear of the tool.
7. Don't overreach. Keep proper footing and balance at all times when operating this tool.
8. Check for damage. Check your tool regularly. If part of the tool is damaged it should be carefully inspected to make sure that it can perform its intended function correctly. If in doubt, the part should be repaired. Refer all servicing to a qualified technician. Consult your dealer for advice.
9. Store idle tools out of the reach of children and untrained persons. Tools may be dangerous in the hands of untrained users.
10. Maintain tools with care.
11. Keep tools dry and clean.
12. Do not use a damaged tool. Tag damaged tools "Do not use" until repaired.
13. Use only accessories that are recommended by the manufacturer for your model. Accessories that may be suitable for one tool may become hazardous when used on another tool.
14. Tool service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel could result in a risk of injury.
14. When servicing a tool, use only identical replacement parts. Use of unauthorized parts or failure to follow maintenance instructions may create a risk of injury.
16. Maintain a safe working environment. Keep the work area well lit. Make sure there is adequate surrounding workspace. Keep the work area free of obstructions, grease, oil, trash, and other debris. Do not use this product in a damp or wet location.
17. Maintain labels and nameplates on this product. These carry important information. If unreadable or missing, contact OEMTOOLS for a replacement.
18. Before use, read and understand all warnings, safety precautions, and instructions as outlined in the vehicle manufacturer's service manual. It is beyond the scope of this manual to properly describe the correct procedure and test data for each vehicle.
19. Always perform vehicle service in a properly ventilated area. Never run an engine without proper ventilation for its exhaust. Stop work and take necessary steps to improve ventilation in the work area if you develop momentary eye, nose, or throat irritation as this indicates inadequate ventilation.

WARNING

20. Engine parts that are in motion and unexpected movement of a vehicle can injure or kill. When working near moving engine parts, wear snug fit clothing and keep hands and fingers away from moving parts. Keep hoses and tools clear of moving parts. Always stay clear of moving engine parts. Hoses and tools can be thrown through the air if not kept clear of moving engine parts. The unexpected movement of a vehicle can injure or kill. When working on vehicles always set the parking brake or block the wheels.
21. Avoid accidental fire and/or explosion. Do not smoke near engine fuel and battery components.
22. For safety purposes and the prevention of damage to expensive components it is advised that the user have an understanding of basic automotive repair and a working knowledge of automotive systems.
23. We believe the information contained herein to be reliable. However, general technical information is given by us without charge and the user shall employ such information at his own discretion and risk. We assume no responsibility for results or damages incurred from the use of such information in whole or in part. Always refer to specific instructions and technical information supplied by vehicle manufacturer.

NOTE: The manufacturer declines any and all responsibility for damage to vehicles or components if said damage is the result of unskillful handling by the operator or of failure to observe the basic safety rules set forth in the instruction manual.

WARNING

Read Rules for Safe Operation and Instructions Carefully.

IMPORTANT SAFETY INSTRUCTIONS

The warnings, precautions, and instructions discussed in this manual cannot cover all possible conditions and situations that may occur. The operator must understand that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

DISPOSAL

At the end of the useful life of the Digital Refrigerant Scale, dispose of the components according to all state, federal, and local regulations



DIGITAL REFRIGERANT SCALE

PURPOSE

The OEM Digital Weight Scale is ideal for servicing HVAC and Automotive A/C systems. Refrigerant can be measured in standard and metric units and has a built in alarm to indicate when the Scale Capacity has been exceeded.

PRODUCT SPECIFICATIONS

Capacity	240 Lbs./110 Kg
Resolution	+/- 0.40z/0.02 Lbs./10g
Operating Temp	32° to 122° F
Accuracy	+/-0.5% of Reading
Platform Size	23 cm x 23 cm

The 1990 amendments to the United States Clean Air Act mandate that all personnel who service refrigerant systems must be trained and certified. Fines are in place for violations and compliance is now being monitored by the U.S. EPA.




Do Not Vent Refrigerant to the Atmosphere. Use Appropriate Recovery Equipment.

Confirm system refrigerant type before servicing vehicle. Cross contamination of refrigerants can cause damage to A/C system, service tools and equipment. Do not blend refrigerants in a system or in the same container.

FEATURES

1. High-visibility .75" x 2.5" LCD Backlit Display
2. Three units of measure. (kg/oz/Lbs.)
3. Automatic Shut-off after 10 minutes, backlight will shut off after 3 minutes.
4. Fully enclosed and removable metal scale platform enables use of product in or out of the protective case.
5. The hand held remote Control Head incorporates a 6ft coil cord and a fold out stand for easy viewing.
6. Compact, portable, battery operated.
7. "FULL" Display when weights exceeds the Scale capacity

SETUP

1. Place the unit on a firm and level surface. The platform and Control Head can be used the case or outside the case.
2. Remove the Battery Cover from the rear of the Control Head by compressing the tab at the base of the Battery Cover.
3. Insert 9V Battery. Replace the Battery Cover by aligning tabs and snap into place.
4. Turn the unit on by pressing the ON/OFF  Button.
5. Select the unit of measure by selecting the UNIT  Button.
6. Press the LAMP  Button to activate and deactivate the backlight.

NOTE: To prevent damage, remove batteries from the Control Head if unit is to be stored for an extended period of time. **Do Not Leave Dead Batteries in the Unit**

Replace the battery if the battery indicator flashes in the top right hand corner of the display.

Never Exceed the rated capacity



If the display reads "FULL" immediately remove the object being weighed from the Scale to prevent damage.

STATIC DISCHARGE: Climates in some parts of the world are conducive to creating static electric build up (ESD). Your scale has been designed to eliminate the damaging effects of ESD. In some extreme cases, ESD will be apparent on your scale by a lack of response or an inability to turn off the unit. In the rare case that this occurs, simply disconnect the battery, wait 1 minute and reconnect the battery. The scale will "reboot" itself and operate normally once the unit is turned on.

⚠ CAUTIONS

If the platform is used in the case, make certain nothing touches the case, Control Box or platform as false readings can occur.

OPERATION


1. Press the Z/T  Button to clear and zero the Scale.
2. Center the Cylinder on the Platform.
3. Start the charging process by opening the Cylinder and Manifold Gauge Valves
4. When charging is complete, close the Cylinder and Manifold Gauge Valves.
5. Remove the Cylinder from the Scale and press the ON/Off  Button.

MAINTENANCE

1. Always store the Digital Refrigerant Scale Set in a well-protected area where it will not be exposed to inclement weather, corrosive vapors, abrasive dust, or any other harmful elements.
2. Keep the Digital Refrigerant Scale clean for better and safer performance.
3. Replace 9V Battery as necessary.



DIGITAL REFRIGERANT SCALE



NOTE: Not all components of the Digital Refrigerant Scale are replacement items, but are illustrated as a convenient reference for location and position in the assembly sequence.

Figure	Description	Quantity
A	Scale Platform	1
B	Control Head	1
C	Control Head Cable	1
Not Shown	Blow Mold Case	1
Not Shown	Battery Cover	1