



CARGO CARRIER



- STEP 1: Inspect cargo carrier for any missing straps or damages. Straps must be free from tears and buckles must be free from cracks.
- Position the front of the cargo carrier in the same forward direction as the vehicle. The front of the cargo carrier is the area without the zipper. Carefully place the cargo carrier onto top of the vehicle with the grey side down. Making sure at all times that the front of the carrier is facing the same direction as vehicle travel. Make sure that the cargo carrier is placed in the center of the side rails and cross bars. Do not place the cargo carrier on top of the crossbars or rails.
- **STEP 3:** Open the pack and you can now proceed to load your items.

WARNING! Do not exceed the weight limit of your vehicle's roof. Read owners manual to find maximum weight limit.

- **STEP 4:** Once packing is complete you can now secure straps to the vehicle:
 - 1) Run one end of strap under the rail and back to the buckle.
 - 2) See Fig.2 for attaching strap to buckle.
 - 3) Tighten straps equally on all four sides.



CAUTION! Do not pull the strap to the point where the buckle may break.

STEP 5: Once all buckles have been secured, check the cargo carrier by moving it forward and back and side to side. If cargo carrier can be easily moved after it has been straped to the rails and or if items in cargo carrier are moving excessively, continue to tighten the straps until movement has minimized.

CAUTION! Do not pull the strap to the point where the buckle may break.