





YAKIMA

MEGA WARRIOR EXTENSION



LOAD LIMITS:



▲
**45 lbs.
(21 kg)**

▲
basket
contents

**DO NOT
EXCEED
YOUR
RACK'S
weight limit!**



**DISTRIBUTE YOUR LOAD EVENLY
INSIDE THE BASKET.**



**DO NOT EXCEED
BASKET CONTENT WEIGHT LIMIT:
115 LBS. (52 KG)**

*Always tie down long loads at
front and rear.*


US

1 IF YOU ALREADY HAVE A MEGAWARRIOR INSTALLED:

- Remove it from your car.
- Disassemble the brackets and set them aside.
- Separate the two basket halves by removing the screws at the joints.



2 INSERT THE EXTENSION.



3

Insert screws and washers into each of the 8 joints and tighten.



4 • IF YOU HAVE FIXED BARS:



IF YOU HAVE "Q TOWERS"
OR BARS THAT CANNOT MOVE...


Continue to STEP 5.



**Q TOWER OWNERS:
NEVER REPOSITION THE Q TOWERS!**

• IF YOUR BARS MOVE:

IF YOU HAVE BARS THAT CAN BE MOVED...
Move the bars apart to a minimum of 36".



**TIGHTEN YOUR CROSSBARS
IF YOU LOOSENED THEM.**

5 ATTACH FAIRING.



Pry open the SnapArounds, attach them to the LOWER FRONT BAR.



- Insert bolts through washers, fairing and SnapArounds.
- Attach knobs and TIGHTEN.

NOTE: The fairing can fold down when carrying long slender loads.



6 LOAD BASKET ONTO RACKS. Center basket over your rack's crossbars.




A friend would make this easier.



DO NOT ATTACH BRACKETS TO UNSTABLE POINTS.



Do not attach brackets at these locations.



Reassemble attachment hardware and secure the Extended MegaWarrior — OR — continue with step 5 of the MegaWarrior instructions.