## QMHD05


ltem	Component Name	Qty	Part No.
1	M6 Channel Nut	2	N002
2	Quick Mount Leg HD Bar Spacer	2	M709
3	M6x40 Socket HD Cap Screw	2	B047
4	Instructions	1	R569

## \*Note:

RLT600 Parts as seperate.

Fix the Quick Mount Spacer to the Leg using the hardware in the leg kit. The bolts found in the spacer kit will replace the original in the leg kit.

## **Tools Required:** 5mm Allen Key



1 2. \* 3. Note: Max Spacer height

Accept no compromises, choose only quality roof racks.

30mm