

AMERICAN CAR CRAFT INSTRUCTION

2005-2009 MUSTANG BRUSHED STAINLESS DOORSILLS PART#271007 patent pending



PARTS INCLUDED:

2-STAINLESS OUTER DOORSILLS 2-STAINLESS INNER SILL PLATES 2-STRIPS CHROME TRIM 2-ADHESIVE PROMOTER PACKS

<u>Your new doorsills come to you with a protective liner</u>. Do not remove liner until installation is complete.

Scrub the top and side of the factory doorsill and top of the inner doorsill first
with soap and water to remove any loose dirt, and then scrub the areas to be
mounted with household rubbing alcohol. Be sure to wipe off any and all
residues. Once your surfaces have been prepared carefully swipe the same areas
once using the adhesive promoter provided.

- 2. Once your surface is properly prepared place the new outer doorsill into position and make note of its position at this time also check to see if any minor adjustments need to be made so that your doorsill conforms to the shape of the factory sill. PLEASE REFER TO PICTURE FOR PROPER SILL PLACEMENT. If adjustments are necessary simply form by hand so that your new sill fits into the factory doorsill without forcing. Once you have achieved a nice contoured fit simply remove the release liner from the attachment tape on the underside of the sill and firmly press into position.
- 3. You have been provided with a length of fine chrome trim. Use this trim to close the gap at the top edge of the new stainless sill and the factory sill. Start to peel the liner from the chrome molding placing the molding directly to the factory sill against the new stainless sill peeling the liner as your press firmly to set the trim along the length. Cut away any excess trim with a razor blade being careful not to cut the plastic sill.
- 4. You have been provided with a brushed stainless inner sill plate. Gently and accurately form this sill by hand so that it conforms to the top shape of the factory sill. Once this sill has been properly shaped simply peel the release liner and press firmly into position. Remove the protective liner and repeat steps 1-4 for the opposite side.

Note: Care must be taken when cleaning your doorsills. It is a good idea to lightly dust your sills with a clean soft cloth first in order to prevent any particles from scratching them. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

Thank you and enjoy your new purchase.