

DR_x Beasley's™

Your Detailing Prescription

Application Instructions

1. Ensure fabric surfaces are clean and dry before application.
2. If your fabric has a fibrous texture, use a brush to push the fibers in one direction. Shake the Fabric Coating Prep bottle, then spray onto the fabric surface holding bottle six inches away. Brush the fibers in the opposite direction, then spray again.
3. Gently wipe surface with clean, dry microfiber towel.
4. Shake the Fabric Coating bottle, then spray onto the fabric surface holding bottle six inches away. Brush the fibers in the opposite direction, then spray again. Apply evenly to ensure full coverage.
5. Let cure undisturbed for at least 1 hour.
6. To test the success of the application, sprinkle a few drops of water onto the coated fabric surface. If the droplets soak in rather than beading on top, repeat steps 2-5.

Dr. Beasley's Suggests:

Test for compatibility by applying a small amount to an inconspicuous area.

After Care Guide

Proper maintenance must be practiced to ensure Fabric Coating lasts the full duration of its lifespan. This maintenance entails regular vacuuming and cleaning.

Regular Cleaning

To ensure Fabric Coating continues to repel liquids, contaminants must be removed frequently so they cannot layer on top. In order to prevent this build-up, we recommend cleaning the fabric once every two weeks (or as needed) with a vacuum and Dr. Beasley's Carpet & Upholstery Cleanser.