

HOW TO USE:



Step 1:

Spray sufficient amount of lubricant on the paint or glass surface.

NOTE: Do not allow the lubricant to run dry on the surface.



Step 2:

Slide Autoscrub across the lubricated surface in a back and forth motion with light to medium pressure.

NOTE: Work in a 12" x 12" area at a time. Do not allow lubricant to dry on the surface.



Step 3:

Wipe and buff dry residual lubricant off the surface using light pressure.

FOLD AUTOSCRUB TO KEEP CLEAN UNTIL NEXT USE

