



Equipped with AEM® Dryflow™ Filter
No Oil Required!

INSTALLATION INSTRUCTIONS

PART NUMBER: 21-8013

2001-2004	CHEVROLET	Silverado 2500 HD	V8-6.6L DSL	C.A.R.B. E.O. # D-670-2
2001-2004	CHEVROLET	Silverado 3500	V8-6.6L DSL	C.A.R.B. E.O. # D-670-2
2001-2004	GMC	Sierra 2500 HD	V8-6.6L DSL	C.A.R.B. E.O. # D-670-2
2001-2004	GMC	Sierra 3500	V8-6.6L DSL	C.A.R.B. E.O. # D-670-2

Make note that not all 2004 model year vehicles are equipped with the LB7 engine type. 21-8013 will only fit 2004 model year vehicles with LB7 engine types. 2004 model year vehicles with the LB7 engine type can be identified by VIN number. The 8th number of the VIN will be "1" on 2004 model year vehicles with the LB7 engine type.

PARTS LIST

Description	Qty.	Part Number
Air Filter Assy. 3.50 X 9" Dry Ele.	1	21-2049DK
Heat Shield	1	20-8013
Inlet Pipe	1	2-80131
Hose, Silicone 3.50x3" Blk.	1	5-350
Grommet, 1/2"	1	784634
Mount, Rubber 1" X 8mm	1	1228560
Wrench; Torx T20 T/R, L-Key	1	69801
Bolt, Socket 8-32 X 5/16 SS	2	1-2023
Washer, 8mm Soft Mount	2	559960
Nut, M8 Hex Serrated	2	444.460.08
1/2" Bnd. Hose Clamp, 3.15"-4.00"	3	9456

Read and understand these instructions **BEFORE** attempting to install this product. Failure to follow installation instructions and not using the provided hardware may damage the intake tube, throttle body and engine.

1. Preparing Vehicle

- a. Make sure vehicle is parked on level surface.
- b. Set parking brake.
- c. If engine has run in the past two hours, let it cool down.
- d. Disconnect negative battery terminal.
- e. Do not discard stock components after removal of the factory system.

2. Removal of stock system




a. On 2001 models, loosen the bolt securing the engine cover, then remove the engine cover. Proceed to step 2d.




b. 2002 and on models, remove the bolt securing the top of the intake resonator.



c. Loosen the hose clamp securing the intake resonator to the air intake tube. Remove the intake resonator from the engine bay.




d. Unplug the wire harness from the mass air flow (MAF) sensor. Remove the two screws retaining the MAF sensor with the supplied tamper-resistant Torx tool. Carefully remove the MAF sensor and set aside in a safe area.



e. Loosen the hose clamp at the air box side of the air intake tube.



f. Loosen the hose clamp at the turbo inlet side of the air intake tube. Remove the air intake tube from the engine bay.




g. Remove the air box by pulling straight up. Remove the air box mounting tray by removing the five bolts. Save the bolts for use during the installation of the AEM® heat shield.



h. Remove the air filter restriction gauge from the factory air box. Make sure the rubber grommet stays in the air box. Reset the gauge by pressing the button on the top.

3. Installation of AEM® intake system.

a. When installing the intake system, do not completely tighten the hose clamps or mounting hardware until instructed to do so.



b. Install the supplied rubber mount onto the AEM® heat shield using one each of the supplied washers and locknuts. Center the rubber mount in the slot until the intake is adjusted for final fitment later in the installation.

c. Install the AEM® heat shield, using three of the original air box mounting tray bolts from step 2(g).



d. Assemble the AEM® inlet pipe, air filter and coupler as shown. The air filter goes on the end of the pipe nearest the mounting bracket.

e. Install the MAF sensor using the supplied 8-32 screws. Use caution to avoid damaging the o-ring.




f. Install the supplied rubber grommet into the AEM® inlet pipe. Insert the air filter restriction gauge into the grommet, being careful not to push the grommet all of the way through the hole.



g. Install the open end of the reducer coupler on to the turbo inlet.



h. The mounting bracket on the AEM® inlet pipe will line up with the rubber mount installed in step 3b. Loosely secure the bracket with the remaining washer and locknut. Refer to the diagram for proper rubber mount installation.



i. Diagram for proper rubber mount installation.



j. Reconnect the MAF sensor wire harness.



Factory air box system installed



AEM® intake system installed

4. Reassemble Vehicle

- Position the inlet pipes for the best fitment. Be sure that the pipes or any other components do not contact any part of the vehicle. Tighten the rubber mount, all bolts, and hose clamps.
- Check for proper hood clearance. Re-adjust pipes if necessary and re-tighten them.
- Inspect the engine bay for any loose tools and check that all fasteners that were moved or removed are properly tightened.
- Reconnect negative battery terminals and start engine. Let the vehicle idle for 3 minutes. Perform a final inspection before driving the vehicle.

5. CARB Sticker Placement

- The C.A.R.B. exemption sticker, (attached), must be visible under the hood so that an emissions inspector can see it when the vehicle is required to be tested for emissions. California requires testing every two years, other states may vary.
- Most General Motors trucks (including Chevrolet) have the Vehicle Emissions Certification Information (VECI) label affixed to the air filter box. In order to be compliant with California emissions laws, the label **MUST** remain in the engine compartment. If the Vehicle Emission Control Information label is removed during modification, a new replacement label must be obtained and installed in a readily visible position in the engine compartment. The label shall not be affixed to any equipment which is easily detached from the vehicle. We recommend that the label is affixed to the underside of the hood adjacent to the hood latch. The label is Vehicle Identification Number dependent and can be ordered from the vehicle dealership. In order to receive the proper decal please bring your VIN with you. Failure to have the VECI under the hood may result in failure of a pre-registration smog test.

6. Service and Maintenance

- a. It is recommended that you service your AEM® Dryflow™ filter every 20,000 miles for optimum performance. Use AEM Dryflow cleaning kit part # 21-110.
- b. Use aluminum polish to clean your polished AEM® intake tube.
- c. Use window cleaner to clean your powder coated AEM® intake tube. **(NOTE: DO NOT USE aluminum polish on powder coated AEM intake tubes).**