



advanced FLOW engineering

Instruction Manual P/N: 54-12848-B / 54-12848-C

Make: **Ford** Model: **Edge** Year: **2011-2014** Engine: **V6-3.5L (Non-EcoBoost)**
Make: **Ford** Model: **Explorer** Year: **2011-2017** Engine: **V6-3.5L (Non-EcoBoost)**
Make: **Ford** Model: **Taurus** Year: **2010-2018** Engine: **V6-3.5L (tt) EcoBoost**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.



Retain factory parts for future use.

Label	Qty.	Description	Part Number
A1	1	Cover, Vaccum Formed	05-12842B3
A2	1	Cover, Vacuum Formed	05-12842C1

Installation will require the following tools:
None

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.

A1



A2





Figure A

Refer to Figure A for Step 1

Step 1: Remove trim seal.

INSTALL



Figure B

Refer to Figure B for Steps 2-3

Step 2: Install the new aFe cover over the aFe housing by slipping the three tabs in first. Then aligning the two holes over the dimples on the housing.

Step 3: Your installation is now complete! Thank you for choosing aFe POWER!

Check out the collection of performance air intake systems we offer.